

# Operating Instructions

**Radar sensor for continuous level  
measurement of liquids and bulk solids**

## VEGAPULS 6X

Two-wire 4 ... 20 mA/HART



Document ID: 66190



# VEGA

## Contents

<b>1</b>	<b>About this document .....</b>	<b>5</b>
1.1	Function .....	5
1.2	Target group .....	5
1.3	Symbols used.....	5
<b>2</b>	<b>For your safety .....</b>	<b>6</b>
2.1	Authorised personnel .....	6
2.2	Appropriate use.....	6
2.3	Warning about incorrect use.....	6
2.4	General safety instructions .....	6
2.5	Modes for worldwide use.....	7
2.6	Installation and operation in the USA and Canada .....	7
<b>3</b>	<b>Product description .....</b>	<b>8</b>
3.1	Configuration.....	8
3.2	Principle of operation.....	9
3.3	Packaging, transport and storage.....	10
3.4	Accessories.....	11
<b>4</b>	<b>Mounting.....</b>	<b>13</b>
4.1	General instructions .....	13
4.2	Housing features .....	13
4.3	Mounting preparations, mounting strap .....	15
4.4	Mounting versions, plastic horn antenna .....	17
4.5	Mounting instructions .....	19
4.6	Measuring rigs - bypass .....	37
4.7	Measurement setup - Flow .....	39
<b>5</b>	<b>Connecting to power supply.....</b>	<b>42</b>
5.1	Preparing the connection .....	42
5.2	Connecting.....	43
5.3	Wiring plan, single chamber housing.....	44
5.4	Wiring plan, double chamber housing .....	45
5.5	Wiring plan - version IP66/IP68, 1 bar .....	46
5.6	Switch-on phase.....	46
<b>6</b>	<b>Access protection.....</b>	<b>47</b>
6.1	Bluetooth radio interface .....	47
6.2	Protection of the parameterization.....	47
6.3	Storing the codes in myVEGA .....	48
<b>7</b>	<b>Functional safety (SIL) .....</b>	<b>49</b>
7.1	Objective .....	49
7.2	SIL qualification.....	49
7.3	Application area .....	49
7.4	Safety concept of the parameterization .....	50
7.5	First setup .....	51
7.6	Function test.....	52
7.7	Parameter adaptations after the first setup.....	54
<b>8</b>	<b>Set up with the display and adjustment module .....</b>	<b>55</b>
8.1	Insert display and adjustment module .....	55

8.2	Adjustment system .....	56
8.3	Measured value indication - Selection of national language .....	57
8.4	Parameterization .....	57
8.5	Save parameter adjustment data .....	79
<b>9</b>	<b>Set up with Smartphone/tablet .....</b>	<b>80</b>
9.1	Preparations .....	80
9.2	Connecting .....	80
9.3	Parameterization .....	81
<b>10</b>	<b>Set up with PC/notebook .....</b>	<b>83</b>
10.1	Preparations (Bluetooth) .....	83
10.2	Connecting (Bluetooth) .....	83
10.3	Connect the PC (VEGACONNECT) .....	85
10.4	Parameterization .....	85
10.5	Save parameter adjustment data .....	87
<b>11</b>	<b>Menu overview .....</b>	<b>88</b>
11.1	Display and adjustment module .....	88
11.2	VEGA Tools app and PACTware/DTM .....	91
11.3	Special parameters .....	95
<b>12</b>	<b>Set up with other systems .....</b>	<b>98</b>
12.1	DD adjustment programs .....	98
12.2	Field Communicator 375, 475 .....	98
<b>13</b>	<b>Diagnosis, asset management and service .....</b>	<b>99</b>
13.1	Maintenance .....	99
13.2	Measured value and event memory .....	99
13.3	Asset Management function .....	100
13.4	Rectify faults .....	103
13.5	Exchanging the electronics module .....	107
13.6	Software update .....	108
13.7	How to proceed if a repair is necessary .....	109
<b>14</b>	<b>Dismount .....</b>	<b>110</b>
14.1	Dismounting steps .....	110
14.2	Disposal .....	110
<b>15</b>	<b>Certificates and approvals .....</b>	<b>111</b>
15.1	Radio licenses .....	111
15.2	Approvals for Ex areas .....	111
15.3	Approvals as overfill protection .....	111
15.4	Food and pharmaceutical certificates .....	111
15.5	EU conformity .....	111
15.6	NAMUR recommendations .....	111
15.7	IT - Security .....	112
15.8	Safety Integrity Level (SIL) .....	112
15.9	Environment management system .....	112
<b>16</b>	<b>Supplement .....</b>	<b>113</b>
16.1	Technical data .....	113
16.2	Radio astronomy stations .....	129
16.3	Dimensions .....	130
16.4	Industrial property rights .....	143

16.5 Licensing information for open source software ..... 143

16.6 Trademark ..... 143



**Safety instructions for Ex areas:**

Take note of the Ex specific safety instructions for Ex applications. These instructions are attached as documents to each instrument with Ex approval and are part of the operating instructions.

Editing status: 2022-01-12



# 1 About this document

## 1.1 Function

This instruction provides all the information you need for mounting, connection and setup as well as important instructions for maintenance, fault rectification, the exchange of parts and the safety of the user. Please read this information before putting the instrument into operation and keep this manual accessible in the immediate vicinity of the device.

## 1.2 Target group

This operating instructions manual is directed to trained personnel. The contents of this manual must be made available to the qualified personnel and implemented.

## 1.3 Symbols used



### Document ID

This symbol on the front page of this instruction refers to the Document ID. By entering the Document ID on [www.vega.com](http://www.vega.com) you will reach the document download.



**Information, note, tip:** This symbol indicates helpful additional information and tips for successful work.



**Note:** This symbol indicates notes to prevent failures, malfunctions, damage to devices or plants.



**Caution:** Non-observance of the information marked with this symbol may result in personal injury.



**Warning:** Non-observance of the information marked with this symbol may result in serious or fatal personal injury.



**Danger:** Non-observance of the information marked with this symbol results in serious or fatal personal injury.



### Ex applications

This symbol indicates special instructions for Ex applications.



### List

The dot set in front indicates a list with no implied sequence.



### Sequence of actions

Numbers set in front indicate successive steps in a procedure.



### Battery disposal

This symbol indicates special information about the disposal of batteries and accumulators.

## 2 For your safety

### 2.1 Authorised personnel

All operations described in this documentation must be carried out only by trained, qualified personnel authorised by the plant operator.

During work on and with the device, the required personal protective equipment must always be worn.

### 2.2 Appropriate use

VEGAPULS 6X is a sensor for continuous level measurement.

You can find detailed information about the area of application in chapter " *Product description*".

Operational reliability is ensured only if the instrument is properly used according to the specifications in the operating instructions manual as well as possible supplementary instructions.

### 2.3 Warning about incorrect use

Inappropriate or incorrect use of this product can give rise to application-specific hazards, e.g. vessel overfill through incorrect mounting or adjustment. Damage to property and persons or environmental contamination can result. Also, the protective characteristics of the instrument can be impaired.

### 2.4 General safety instructions

This is a state-of-the-art instrument complying with all prevailing regulations and directives. The instrument must only be operated in a technically flawless and reliable condition. The operator is responsible for the trouble-free operation of the instrument. When measuring aggressive or corrosive media that can cause a dangerous situation if the instrument malfunctions, the operator has to implement suitable measures to make sure the instrument is functioning properly.

The safety instructions in this operating instructions manual, the national installation standards as well as the valid safety regulations and accident prevention rules must be observed by the user.

For safety and warranty reasons, any invasive work on the device beyond that described in the operating instructions manual may be carried out only by personnel authorised by the manufacturer. Arbitrary conversions or modifications are explicitly forbidden. For safety reasons, only the accessory specified by the manufacturer must be used.

To avoid any danger, the safety approval markings and safety tips on the device must also be observed.

The low transmitting power of the radar sensor is far below the internationally approved limits. No health impairments are to be expected with intended use. The band range of the measuring frequency can be found in chapter " *Technical data*".

## 2.5 Modes for worldwide use

Country specific settings for the radar signals are determined via the mode. The operating mode must be set in the operating menu via the respective operating tool at the beginning of the setup.



**Caution:**

Operating the device without selecting the appropriate country group constitutes a violation of the regulations of the radio approvals of the respective country.

## 2.6 Installation and operation in the USA and Canada

This information is only valid for USA and Canada. Hence the following text is only available in the English language.

Installations in the US shall comply with the relevant requirements of the National Electrical Code (ANSI/NFPA 70).

Installations in Canada shall comply with the relevant requirements of the Canadian Electrical Code

A Class 2 power supply unit has to be used for the installation in the USA and Canada.

## 3 Product description

### 3.1 Configuration

#### Scope of delivery

The scope of delivery encompasses:

- Radar sensor, possibly with accessories
  - Disc springs (for flange version with plastic plating) <sup>1)</sup>
  - Hexagon socket wrench (for instruments with swivel holder)
  - Optional accessory
- Information sheet "*PINs and Codes*" (with SIL, IT security, Bluetooth versions) with:
  - Bluetooth access code
  - Device code
- Information sheet "*Access protection*" (with SIL, IT security, Bluetooth versions) with:
  - Bluetooth access code
  - Emergency Bluetooth unlock code
  - Device code
  - Emergency device code
- Documentation
  - Quick setup guide VEGAPULS 6X
  - Instructions for optional instrument components
  - Ex-specific "*Safety instructions*" (with Ex versions)
  - Safety Manual (with SIL version)
  - Radio licenses
  - If necessary, further certificates



#### Note:

Optional instrument features are also described in this operating instructions manual. The respective scope of delivery results from the order specification.

#### Scope of this operating instructions

This operating instructions manual applies to the following instrument versions:

- Hardware version from 1.0.0
- Software version from 1.0.0

#### Type label

The type label contains the most important data for identification and use of the instrument:

<sup>1)</sup> Use see chapter "Mounting instructions, sealing to the process"




Fig. 1: Layout of the type label (example)

- 1 Device type, order number
- 2 Field for approvals, product code
- 3 Technical data
- 4 QR-code for VEGA Tools app
- 5 Reminder to observe the instrument documentation

## Serial number - Instrument search

The type label contains also the serial number of the instrument. With it you can find the following instrument data on our homepage:

- Product information
- Device configuration
- Related documentation
- Further documents

Move to "[www.vega.com](http://www.vega.com)" and enter in the search field the serial number of your instrument.

Alternatively, you can access the data via your smartphone:

- Download the VEGA Tools app from the "*Apple App Store*" or the "*Google Play Store*"
- Scan the QR-code on the type label of the device or
- Enter the serial number manually in the app

## 3.2 Principle of operation

The VEGAPULS 6X is a radar sensor for continuous level measurement of liquids as well as bulk solids under different process conditions.

The small threaded fittings offer particular advantages in small tanks or tight mounting spaces. The very good signal focusing ensures the use in vessels with many installations such as stirrers and heating spirals.

The flange connections are ideal for level measurement in very high silos, large bunkers and segmented vessels. The very good signal focussing ensures easy setup and reliable measurement.

## Application area

## Antenna systems

The instrument is available with different antenna systems:




Fig. 2: Antenna systems VEGAPULS 6X

- 1 Plastic horn antenna
- 2 Thread with integrated antenna system
- 3 Flange with plastic plating
- 4 Hygienic fitting
- 5 Flange with lens antenna

## Functional principle

The instrument emits a continuous, frequency-modulated radar signal through its antenna. The emitted signal is reflected by the medium and received by the antenna as an echo with modified frequency. The frequency change is proportional to the distance and is converted into the level.

## 3.3 Packaging, transport and storage

### Packaging

Your instrument was protected by packaging during transport. Its capacity to handle normal loads during transport is assured by a test based on ISO 4180.

The packaging consists of environment-friendly, recyclable cardboard. For special versions, PE foam or PE foil is also used. Dispose of the packaging material via specialised recycling companies.

### Transport

Transport must be carried out in due consideration of the notes on the transport packaging. Nonobservance of these instructions can cause damage to the device.

### Transport inspection

The delivery must be checked for completeness and possible transit damage immediately at receipt. Ascertained transit damage or concealed defects must be appropriately dealt with.

## Storage

Up to the time of installation, the packages must be left closed and stored according to the orientation and storage markings on the outside.

Unless otherwise indicated, the packages must be stored only under the following conditions:

- Not in the open
- Dry and dust free
- Not exposed to corrosive media
- Protected against solar radiation
- Avoiding mechanical shock and vibration

## Storage and transport temperature

- Storage and transport temperature see chapter " *Supplement - Technical data - Ambient conditions*"
- Relative humidity 20 ... 85 %

## Lifting and carrying

With instrument weights of more than 18 kg (39.68 lbs) suitable and approved equipment must be used for lifting and carrying.

## 3.4 Accessories

The instructions for the listed accessories can be found in the download area on our homepage.

### PLICSCOM

The display and adjustment module is used for measured value indication, adjustment and diagnosis.

The integrated Bluetooth module (optional) enables wireless adjustment via standard adjustment devices.

### VEGACONNECT

The interface adapter VEGACONNECT enables the connection of communication-capable instruments to the USB interface of a PC.

### VEGADIS 81

The VEGADIS 81 is an external display and adjustment unit for VEGA plics® sensors.

### VEGADIS 82

VEGADIS 82 is suitable for measured value indication and adjustment of sensors with HART protocol. It is looped into the 4 ... 20 mA/HART signal cable.

### PLICSMOBILE T81

The PLICSMOBILE T81 is an external GSM/GPRS/UMTS radio unit for transmission of measured values and for remote parameter adjustment of HART sensors.

### PLICSMOBILE 81

PLICSMOBILE 81 is an internal GSM/GPRS/UMTS radio unit for HART sensors for transmitting measured values and for remote parameterization.

## Welded socket, threaded and hygienic adapter

Welded sockets are used to connect the devices to the process.

Threaded and hygienic adapters enable simple adaptation of devices with standard threaded fittings to process-side hygiene connections.

## **Flanges**

Screwed flanges are available in different versions according to the following standards: DIN 2501, EN 1092-1, BS 10, ASME B 16.5, JIS B 2210-1984, GOST 12821-80.



## 4 Mounting

### 4.1 General instructions

#### Protection against moisture

Protect your instrument against moisture ingress through the following measures:

- Use a suitable connection cable (see chapter " *Connecting to power supply*")
- Tighten the cable gland or plug connector
- Lead the connection cable downward in front of the cable entry or plug connector

This applies mainly to outdoor installations, in areas where high humidity is expected (e.g. through cleaning processes) and on cooled or heated vessels.



#### Note:

Make sure that during installation or maintenance no moisture or dirt can get inside the instrument.

To maintain the housing protection, make sure that the housing lid is closed during operation and locked, if necessary.

#### Process conditions



#### Note:

For safety reasons, the instrument must only be operated within the permissible process conditions. You can find detailed information on the process conditions in chapter " *Technical data*" of the operating instructions or on the type label.

Hence make sure before mounting that all parts of the instrument exposed to the process are suitable for the existing process conditions.

These are mainly:

- Active measuring component
- Process fitting
- Process seal

Process conditions in particular are:

- Process pressure
- Process temperature
- Chemical properties of the medium
- Abrasion and mechanical influences

#### Second Line of Defense

As a standard feature, the VEGAPULS 6X is separate from the process through its plastic antenna encapsulation.

Optionally, the instrument is available with a Second Line of Defense (SLOD), a second process separation. It is located as gas-tight leadthrough between the process component and the electronics.

This means additional safety against penetration of the medium from the process into the instrument.

### 4.2 Housing features

#### Filter element

The filter element in the housing is used for ventilation of the housing.

For effective ventilation, the filter element must always be free of deposits. Therefore, mount the device so that the filter element is protected against deposits.



**Note:**

Do not use a high-pressure cleaner to clean housings in standard types of protection. The filter element could be damaged and moisture could penetrate the housing.

For applications with high-pressure cleaners, the device is available with the appropriate IP69K housing protection.




Fig. 3: Position of the filter element depending on housing

- 1 Filter element
- 2 Plastic single chamber
- 3 Aluminium single chamber, stainless steel single chamber (precision casting)
- 4 Stainless steel single chamber (electropolished)
- 5 Plastic double chamber
- 6 Aluminium, stainless steel double chamber housing (precision casting)

For devices in protection class IP66/IP68 (1 bar), ventilation is provided by a capillary in the fixed cable. In these devices, a blind plug is installed in the housing instead of the filter element.

## Housing orientation

The housing of VEGAPULS 6X can be rotated completely through 360°. This allows the display to be read optimally and the device to be aligned for easy cable insertion.<sup>2)</sup>

Depending on the version and housing material, the locking screw on the housing neck must be loosened. The housing can then be turned to the correct position. As soon as this position is reached, tighten the locking screw. Use an hexagon spanner size 3.

<sup>2)</sup> No limitation by a rotation stop




Fig. 4: Position of the locking screw depending on housing

- 1 Locking screw
- 2 Aluminium single chamber, stainless steel single chamber (precision casting)
- 3 Aluminium, stainless steel double chamber housing (precision casting)



**Note:**

For the housing orientation, observe the information on polarization in chapter "Mounting instructions".

**Cover catch**

The housing lid on housings made of aluminium and stainless steel (fine-cast) can be secured by a screw. This protects the instrument from unauthorised opening of the lid.

The locking screw has two holes drilled through the head which allow it also to be sealed.




Fig. 5: Position of the safety screw depending on housing

- 1 Safety screw
- 2 Single chamber housing
- 3 Double chamber housing

### 4.3 Mounting preparations, mounting strap

The mounting strap is supplied unassembled (optionally) as accessory part of the plastic horn antenna and must be screwed to the sensor before setup with three hexagon socket screws M5 x 10 and spring washers. Max. torque, see chapter "Technical data". Required tools: Allen wrench size 4.

There are two different variants of screwing the strap to the sensor, see following illustration:




Fig. 6: Mounting strap for screwing to the sensor

- 1 For angle of inclination in steps
- 2 For angle of inclination, infinitely variable

Depending on the selected variant, the sensor can be rotated in the strap:

- Single chamber housing
  - Angle of inclination in three steps 0°, 90° and 180°
  - Angle of inclination 180°, infinitely variable
- Double chamber housing
  - Angle of inclination in two steps 0° and 90°
  - Angle of inclination 90°, infinitely variable




Fig. 7: Adjustment of the angle of inclination




Fig. 8: Turning by fastening in the centre

## Mounting strap

### 4.4 Mounting versions, plastic horn antenna

The optional mounting strap allows simple mounting of the instrument on a wall, ceiling or boom. Especially in the case of open vessels, this is a simple and effective way to align the sensor to the surface of the bulk solid material.

The following versions are available:

- Length 300 mm
- Length 170 mm

## Mounting strap - Ceiling mounting

The instrument is normally mounted vertically with a bracket on the ceiling.

This allows swivelling the sensor up to 180° for optimal orientation and rotating for optimal connection.




Fig. 9: Ceiling mounting via the mounting strap with length 300 mm

## Mounting strap - Wall mounting

As an alternative the strap mounting is carried out horizontally or obliquely.




Fig. 10: Wall mounting horizontally via the mounting strap with length 170 mm




Fig. 11: Wall mounting with inclined wall via the mounting strap with length 300 mm

## Flange

Two versions are available for mounting the instrument on a nozzle:

- Combi compression flange
- Adapter flange

### Combi compression flange:

The combi compression flange is suitable for different vessel flanges DN 80, ASME 3" and JIS 80. It comes not sealed against the radar sensor and can thus only be used unpressurized. It can be retrofitted on instruments with single chamber housing, retrofitting to a double chamber housing is not possible.




Fig. 12: Combi compression flange

1 Combi compression flange

### Adapter flange:

The adapter flange is available from DN 100, ASME 3" and JIS 100. It is permanently connected with the radar sensor and sealed.




Fig. 13: Adapter flange

- 1 Connection screw
- 2 Adapter flange
- 3 Process seal

## 4.5 Mounting instructions

### Polarisation

Radar sensors for level measurement emit electromagnetic waves. The polarization is the direction of the electrical component of these waves.

The polarization direction is marked by a nose on the housing, see following drawing:




Fig. 14: Position of the polarisation

- 1 Nose for marking the direction of polarisation

Turning the housing changes the polarisation and thus the effect of false echoes on the measured value.



### Note:

Therefore, pay attention to the position of the polarisation when mounting or when making subsequent changes. Fix the housing to prevent a change in the metrological properties (see chapter "Housing features").

### Mounting position - liquids

When mounting the device, keep a distance of at least 200 mm (7.874 in) from the vessel wall. If the device is installed in the center of dished or round vessel tops, multiple echoes can arise. However, these can be suppressed by an appropriate adjustment (see chapter "Setup").

**Note:**

If you cannot maintain this distance, you should carry out a false signal suppression during setup. This applies especially if buildup on the vessel wall is to be expected.<sup>3)</sup>




Fig. 15: Mounting of the radar sensor on round vessel tops

In vessels with conical bottom it can be advantageous to mount the device in the centre of the vessel, as measurement is then possible down to the bottom.




Fig. 16: Mounting of the radar sensor on vessels with conical bottom

### Mounting position - bulk solids

Mount the instrument at least 200 mm (7.874 in) away from the vessel wall.

<sup>3)</sup> In this case, it is recommended to repeat the false signal suppression at a later time with existing buildup.






Fig. 17: Mounting the radar sensor on the vessel top



**Note:**

If you cannot maintain this distance, you should carry out a false signal suppression during setup. This applies especially if buildup on the vessel wall is to be expected.<sup>4)</sup>

**Reference plane**

The measuring range of the VEGAPULS 6X physically begins with the antenna end.

However, the min./max. adjustment begins mathematically with the reference plane, which is located differently depending on the sensor version.

**Plastic horn antenna:**

The reference plane is the sealing surface on the lower side.

**Thread with integrated antenna system:**

The reference plane is the sealing surface at the bottom of the hexagon.

**Flange with plastic plating:**

The reference plane is the lower side of the flange plating.

**Hygienic fitting:**

The reference plane is the highest contact point between sensor process fitting and welded socket.

**Flange with lens antenna:**

The reference plane is the lower side of the flange.

The following graphic shows the position of the reference plane with different sensor versions.

<sup>4)</sup> In this case, it is recommended to repeat the false signal suppression at a later time with existing buildup.




Fig. 18: Position of the reference plane

- 1 Reference plane
- 2 Plastic horn antenna
- 3 Threaded fittings
- 4 Flange connections
- 5 Hygienic fittings
- 6 Flange with lens antenna

#### Inflowing medium - liquids

Do not mount the instruments in or above the filling stream. Make sure that you detect the medium surface, not the inflowing product.




Fig. 19: Mounting of the radar sensor with inflowing medium

#### Inflowing medium - bulk solids

The instrument should not be mounted too close to the inflowing medium, as the radar signal could be disrupted.

##### Silo with filling from top:

The optimal mounting position is opposite the filling aperture. To avoid heavy soiling, the distance to any filter or dust exhauster should be as large as possible.




Fig. 20: Mounting of the radar sensor with inflowing medium

#### **Silo with lateral filling:**

In bulk solids silos with lateral pneumatic filling the instrument should not be mounted above the filling stream, as the radar signal will be disrupted. The optimal mounting position is to the side of the filling aperture. To avoid heavy soiling, the distance to any filter or dust exhauster should be as large as possible.




Fig. 21: Mounting of the radar sensor with inflowing medium

#### Socket mounting - short nozzles

For nozzle mounting, the nozzle should be as short as possible and its end rounded. This reduces false reflections from the nozzle.

With threaded connection, the antenna end should protrude at least 5 mm (0.2 in) out of the nozzle.




Fig. 22: Recommended socket mounting with different versions of VEGAPULS 6X

- 1 Plastic horn antenna
- 2 Thread with integrated antenna system
- 3 Flange with plastic plating
- 4 Flange with lens antenna

### Socket mounting - longer nozzles

If the reflective properties of the medium are good, you can mount VEGAPULS 6X on sockets longer than the antenna. The socket end should be smooth and burr-free, if possible also rounded.



#### Note:

When mounting on longer nozzles, we recommend carrying out a false signal suppression (see chapter "Parameter adjustment").

You will find recommended values for socket heights in the following illustration or the tables. The values come from typical applications. Deviating from the proposed dimensions, also longer sockets are possible, however the local conditions must be taken into account.




Fig. 23: Socket mounting with deviating socket dimensions with different versions of VEGAPULS 6X

- 1 Plastic horn antenna
- 2 Thread with integrated antenna system
- 3 Flange with plastic plating
- 4 Flange with lens antenna

#### Thread with integrated antenna system

Socket diameter "d"		Socket length "h"	
40 mm	1½"	≤ 150 mm	≤ 5.9 in
50 mm	2"	≤ 200 mm	≤ 7.9 in
80 mm	3"	≤ 300 mm	≤ 11.8 in
100 mm	4"	≤ 400 mm	≤ 15.8 in
150 mm	6"	≤ 600 mm	≤ 23.6 in

#### Plastic horn antenna

Socket diameter "d"		Socket length "h"	
80 mm	3"	≤ 400 mm	≤ 15.8 in
100 mm	4"	≤ 500 mm	≤ 19.7 in
150 mm	6"	≤ 800 mm	≤ 31.5 in

### Flange with plastic plating

Socket diameter "d"		Socket length "h"	
50 mm	2"	≤ 200 mm	≤ 7.9 in
80 mm	3"	≤ 400 mm	≤ 15.8 in
100 mm	4"	≤ 500 mm	≤ 19.7 in
150 mm	6"	≤ 800 mm	≤ 31.5 in

### Flange with lens antenna

Socket diameter "d"		Socket length "h"	
100 mm	4"	≤ 500 mm	≤ 19.7 in
150 mm	6"	≤ 800 mm	≤ 31.5 in

### Sealing to the process

The VEGAPULS 6X with flange and encapsulated antenna system, the PTFE washer of the antenna encapsulation serves also as process seal.




Fig. 24: VEGAPULS 6X with flange and encapsulated antenna system

- 1 PTFE washer
- 2 Antenna encapsulation



#### Note:

PTFE-plated flanges, however, have a preload loss over time with large temperature changes. This can negatively influence the sealing properties.

To avoid this, use disc springs during assembly. The disc springs suitable for the flange screws are included in the scope of delivery.

To seal effectively, the following requirements must be fulfilled:

1. Make sure the number of flange screws corresponds to the number of flange holes
2. Use of disc springs as previously described




Fig. 25: Use of disc springs

- 1 Disc spring
- 2 Sealing surface

3. Tighten screws with the necessary torque (see chapter "Technical data", "Torques")<sup>5)</sup>

**Note:**

To maintain the sealing properties of the antenna encapsulation against the process, we recommend retightening the screws at regular intervals depending on the process pressure and temperature. For the recommended torque see chapter "Technical data", "Torques".

**Exchange, flange plating**

The PTFE washer can be exchanged by the user in case of wear or damage.

Proceed as follows while dismantling:

1. Dismount and clean the instrument, note chapters "Dismounting steps" and "Maintenance"
2. Unscrew and remove the PTFE disc by hand, protecting the thread against dirt.




Fig. 26: VEGAPULS 6X - Loosening the PTFE washer

3. Remove the sealing and clean the sealing groove
4. Insert the supplied new sealing, place the PTFE washer onto the thread and tighten it manually
5. Mount the sensor, tighten the flange screws (torque see chapter "Technical data", "Torques")

**Note:**

To maintain the sealing properties of the antenna encapsulation against the process, we recommend retightening the screws at regular intervals depending on the process pressure and temperature.

<sup>5)</sup> The torques specified in the technical data only apply to the plating shown here in the area of the sealing surface. For plating up to the outer diameter, the values are for orientation only; the torque values actually required are application-specific.



For the recommended torque see chapter " *Technical data*", " *Torques*".

# **Mounting, PTFE threaded adapter**

PTFE threaded adapters are available for VEGAPULS 6X with thread G1½ or 1½ NPT. Due to this, only PTFE is in contact with the medium. Mount the PTFE threaded adapter in the following way:




Fig. 27: VEGAPULS 6X with PTFE threaded adapter

- 1 Sensor
- 2 O-ring seal (sensor side)
- 3 PTFE threaded adapter
- 4 Flat seal (process side)
- 5 Welded socket

1. Remove existing Klingersil flat seal on the thread of VEGAPULS 6X
2. Insert the supplied O-ring seal (1) into the threaded adapter
3. Place the supplied flat seal (4) onto the thread of the adapter



## **Note:**

For the threaded adapter in NPT version, there is no flat seal required on the process side.

4. Screw the threaded adapter on the hexagon into the welded socket. Torque see chapter " *Technical data*", " *Torques*".
5. Screw VEGAPULS 6X on the hexagon into the threaded adapter. Torque see chapter " *Technical data*", " *Torques*".

### Mounting in the vessel insulation

Instruments for a temperature range up to 250 °C have a spacer for temperature decoupling between process fitting and electronics housing.



#### Note:

The temperature decoupling can become ineffective due to incorrect installation. Damage to the electronics can be the result.

Hence ensure effective temperature decoupling by including the spacer in the vessel insulation only up to max. 40 mm, see the following figure.




Fig. 28: Mounting the instrument on insulated vessels.

- 1 Electronics housing
- 2 Spacer
- 3 Vessel insulation

### Vessel installations

The mounting location of the radar sensor should be a place where no other equipment or fixtures cross the path of the radar signals.

Vessel installations, such as e.g. ladders, limit switches, heating spirals, struts, etc., can cause false echoes and impair the useful echo. Make sure when planning your measuring point that the radar sensor has a "clear view" to the measured product.

In case of existing vessel installations, a false signal suppression should be carried out during setup.

If large vessel installations such as struts or supports cause false echoes, these can be attenuated through supplementary measures. Small, inclined sheet metal baffles above the installations "scatter" the radar signals and prevent direct interfering reflections.




Fig. 29: Cover flat, large-area profiles with deflectors

## Alignment - Liquids

In liquids, direct the device as perpendicular as possible to the medium surface to achieve optimum measurement results.




Fig. 30: Alignment in liquids

## Orientation - Bulk solids

In a cylindrical silo with conical outlet, the mounting is carried out on a third up to the half of the vessel radius from outside (see following drawing).




Fig. 31: Mounting position and orientation

Direct the device in such a way that the radar signal reaches the lowest vessel level. Hence it is possible to detect the complete vessel volume.



### Tip:

The easiest way to align the device is with the optional swivelling holder. Determine the suitable inclination angle and check the alignment with the alignment aid in the VEGA Tools app on the device.

Alternatively, the angle of inclination can be determined using the following drawing and table. It depends on the measuring distance "d" and the distance "a" between vessel centre and mounting position.

Check the alignment with a suitable level or water level.




Fig. 32: Determination of the angle of inclination for alignment of VEGAPULS 6X

Distance d (m)	2°	4°	6°	8°	10°
2	0.1	0.1	0.2	0.3	0.4
4	0.1	0.3	0.4	0.6	0.7
6	0.2	0.4	0.6	0.8	1.1
8	0.3	0.6	0.8	1.1	1.4
10	0.3	0.7	1.1	1.4	1.8
15	0.5	1	1.6	2.1	2.6
20	0.7	1.4	2.1	2.8	3.5
25	0.9	1.7	2.6	3.5	4.4
30	1	2.1	3.2	4.2	5.3
35	1.2	2.4	3.7	4.9	6.2
40	1.4	2.8	4.2	5.6	7.1
45	1.6	3.1	4.7	6.3	7.9
50	1.7	3.5	5.3	7	8.8
60	2.1	4.2	6.3	8.4	10.5
70	2.4	4.9	7.3	9.7	12.2

Distance d (m)	2°	4°	6°	8°	10°
80	2.8	5.6	8.4	11.1	13.9
90	3.1	6.3	9.4	12.5	15.6
100	3.5	7	10.5	13.9	17.4
110	3.8	7.7	11.5	15.3	19.1
120	4.2	8.4	12.5	16.7	20.8

### Example:

In a vessel 20 m high, the installation position of the device is 1.4 m from the vessel centre.

The necessary angle of inclination of 4° can be read out from this table.

Proceed as follows to adjust the angle of inclination with the swivelling holder:

1. Loosen the terminal screws of the swivel holder by one turn. Use a hexagon socket wrench, size 5.




Fig. 33: VEGAPULS 6X with swivelling holder

1 Terminal screws (6 pieces)

2. Align the device, check angle of inclination



### Note:

The max. angle of inclination of the swivelling holder is approx. 10°

3. Re-tighten the terminal screws, max. torque see chapter "Technical data".

## Agitators

Agitators in the vessel can reflect the measurement signal and thus lead to undesired incorrect measurements.



### Note:

To avoid this, a false signal suppression should be carried out with the agitators in motion. This ensures that the interfering reflections from the agitators are saved with the blades in different positions.




Fig. 34: Agitators

### Foam generation

Through the action of filling, stirring and other processes in the vessel, compact foams which considerably damp the emitted signals may form on the medium surface.



#### Note:

If foams lead to measurement errors, you should use the biggest possible radar antennas or as an alternative, sensors with guided radar.

### Material heaps

Large material heaps are best measured with several instruments, which can be mounted on e.g. traverse cranes. For this type of application it is advantageous to orient the sensor perpendicular to the bulk solid surface.

The sensors do not influence each other.



#### Information:

Keep in mind that for these applications, the sensors are designed for relatively slow level changes. If the sensor is used on a movable boom, the max. measuring rate must be observed (see chapter "Technical data").




Fig. 35: Radar sensors on traverse crane

### Mounting in multiple chamber silo

The separating walls in multi-chamber silos are often constructed from trapezoidal sheets to ensure the required stability.



#### Note:

If the radar sensor is mounted very close to a highly structured vessel wall, considerable interfering reflections may occur. To avoid this, the sensor should be installed at the greatest possible distance from the separating walls.

The best mounting location is on the outer wall of the silo, with the sensor pointing towards the discharge opening in the silo centre. This can be accomplished, for example, with the mounting strap.




Fig. 36: Installation and orientation in multiple chamber silos




Fig. 37: Installation and orientation in multiple chamber silos

#### Dust deposits - Rinsing air connection

To avoid heavy buildup and dust on the antenna, the device should not be mounted close to the dust exhauster inside the vessel.

To protect the device against buildup, particularly in case of strong condensation, air rinsing is recommended.

#### Flange with lens antenna:

The VEGAPULS 6X with metal-jacketed lens antenna is equipped with a rinsing air connection as a standard feature, see following graphics.




Fig. 38: Metal-jacketed lens antenna

1 Rinsing air connection

#### Plastic horn antenna:

The VEGAPULS 6X with plastic horn antenna is optionally available with a rinsing air connection. The mechanical configuration differs according to the flange version, see following graphics.






Fig. 39: Plastic horn antenna with compression flange

1 Rinsing air connection




Fig. 40: Plastic horn antenna with adapter flange

1 Rinsing air connection

You can find details on the rinsing air connection in chapter "Technical data".

## Measurement in the bypass tube

### 4.6 Measuring rigs - bypass

A bypass consists of a stand pipe with lateral process connections which can be mounted on the outside of a container as a communicating vessel.

The VEGAPULS 6X in 80 GHz technology is suitable as standard for non-contact level measurement in such a bypass.



#### Note:

For standpipe lengths > 3 m (9.842 ft) a special standpipe version is available in the configurator.

## Configuration bypass




Fig. 41: Configuration bypass

- 1 Radar sensor
- 2 Polarisation marking
- 3 Instrument flange
- 4 Distance sensor reference plane to upper tube connection
- 5 Distance of the tube connections
- 6 Ball valve with complete opening

## Instructions and requirements, bypass

**Instructions of orientation of the polarisation:**

- Note marking of the polarisation on the sensor
- With threaded versions, the marking is on the hexagon, with flange versions between two flange holes
- The marking must be in one plane with the tube connections to the vessel

**Instructions for the measurement:**

- The 100 % point may not be above the upper tube connection to the vessel
- The 0 % point may not be below the lower tube connection to the vessel
- Min. distance, sensor reference plane to upper edge of upper tube connection > 200 mm
- The antenna diameter of the sensor should correspond to the inner diameter of the tube
- For stand pipe lengths > 3 m the "Application stand pipe > 3 m" must be selected for the parametrisation
- For stand pipe lengths > 3 m, the antenna diameter must be chosen as large as possible, but at least 80 mm/3"

- A false signal suppression with the installed sensor is recommended but not mandatory
- The measurement through a ball valve with unrestricted channel is possible
- The deviation can increase in the area of the connecting tube to the container  $\pm 200$  mm

#### Constructional requirements on the bypass pipe:

- Material metal, smooth inner surface
- In case of an extremely rough tube inner surface, use an inserted tube (tube in tube) or a radar sensor with tube antenna
- Flanges are welded to the tube according to the orientation of the polarisation
- Gap size with junctions  $\leq 1$  mm, for example, when using a ball valve or intermediate flanges with single pipe sections
- Diameter should be constant over the complete length

## 4.7 Measurement setup - Flow

### Mounting

In general, the following must be observed while mounting the device:

- Mounting the sensor on the upstream or inlet side
- Installation in the centre of the flume and vertical to the liquid surface
- Distance to the overfall orifice or Venturi flume
- Min. distance to the max. height of the orifice or flume for optimum accuracy: 250 mm (9.843 in) <sup>6)</sup>
- Requirements from approvals for flow measurement, e.g. MCERTS

### Flume

Every flume generates a different level of backwater depending on its type and version. The specifications of the following flumes are available in the instrument:

#### Predefined curves:

A flow measurement with these standard curves is very easy to set up, as no dimensional information of the flume is required.

- Palmer-Bowlus flume ( $Q = k \times h^{1.86}$ )
- Venturi, trapezoidal weir, rectangular flume ( $Q = k \times h^{1.5}$ )
- V-Notch, triangular overfall ( $Q = k \times h^{2.5}$ )

#### Dimensions (ISO standard):

When selecting these curves, the dimensions of the flume must be known and entered via the assistant. As a result, the accuracy of the flow measurement is higher than with the specified curves.

- Rectangular flume (ISO 4359)
- Trapezoidal flume (ISO 4359)
- U-shaped flume (ISO 4359)
- Triangular overfall thin-walled (ISO 1438)
- Rectangular flume thin-walled (ISO 1438)

<sup>6)</sup> At smaller distances the measuring accuracy is reduced, see "Technical data".

- Rectangular weir broad crown (ISO 3846)

**Flow formula:**

If the flow formula of your flume is known, you should select this option, as the accuracy of the flow measurement is highest here.

- Flow formula:  $Q = k \times h^{\exp}$

**Manufacturer definition:**

If you use a Parshall flume from the manufacturer ISCO, this option must be selected. This gives you a high accuracy of flow measurement with easy configuration.

Alternatively, you can also take over Q/h table values provided by the manufacturer here.

- ISCO-Parshall-Flume
- Q/h table (assignment of height with corresponding flow in a table)

Detailed project planning data can be found at the channel manufacturers and in the technical literature.

The following examples serve as an overview for flow measurement.

**Rectangular overflow**




Fig. 42: Flow measurement with rectangular flume:  $h_{\max.} = \max.$  filling of the rectangular flume

- 1 Overflow orifice (side view)
- 2 Upstream water
- 3 Tailwater
- 4 Overflow orifice (view from tailwater)

# Khafagi-Venturi flume




Fig. 43: Flow measurement with Khafagi-Venturi flume:  $h_{max} = \max$ , filling of the flume; B = tightest constriction in the flume

- 1 Position sensor
- 2 Venturi flume

## 5 Connecting to power supply

### 5.1 Preparing the connection

#### Safety instructions

Always keep in mind the following safety instructions:

- Carry out electrical connection by trained, qualified personnel authorised by the plant operator
- If overvoltage surges are expected, overvoltage arresters should be installed



#### Warning:

Only connect or disconnect in de-energized state.

#### Voltage supply

The data for power supply are specified in chapter " *Technical data*".



#### Note:

Power the instrument via an energy-limited circuit (power max. 100 W) acc. to IEC 61010-1, e.g.

- Class 2 power supply unit (acc. to UL1310)
- SELV power supply unit (safety extra-low voltage) with suitable internal or external limitation of the output current

Keep in mind the following additional factors that influence the operating voltage:

- Lower output voltage of the power supply unit under nominal load (e.g. with a sensor current of 20.5 mA or 22 mA in case of fault signal)
- Influence of additional instruments in the circuit (see load values in chapter " *Technical data*")

#### Connection cable

The instrument is connected with standard two-wire cable without shielding. If electromagnetic interference is expected which is above the test values of EN 61326-1 for industrial areas, shielded cable should be used.

Use cable with round cross section for instruments with housing and cable gland. Use a cable gland suitable for the cable diameter to ensure the seal effect of the cable gland (IP protection rating).

Shielded cable generally necessary in HART multidrop mode.

#### Cable glands

#### Metric threads:

In the case of instrument housings with metric thread, the cable glands are screwed in at the factory. They are sealed with plastic plugs as transport protection.



#### Note:

You have to remove these plugs before electrical connection.

#### NPT thread:

In the case of instrument housings with self-sealing NPT threads, it is not possible to have the cable entries screwed in at the factory. The free openings for the cable glands are therefore covered with red dust protection caps as transport protection.



**Note:**

Prior to setup you have to replace these protective caps with approved cable glands or close the openings with suitable blind plugs.

On plastic housings, the NPT cable gland or the Conduit steel tube must be screwed into the threaded insert without grease.

Max. torque for all housings, see chapter " *Technical data*".

**Cable screening and grounding**

If shielded cable is required, the cable screening must be connected on both ends to ground potential. In the sensor, the cable screening is connected directly to the internal ground terminal. The ground terminal on the outside of the housing must be connected to the ground potential (low impedance).



In Ex systems, the grounding is carried out according to the installation regulations.

In electroplating plants as well as plants for cathodic corrosion protection it must be taken into account that significant potential differences exist. This can lead to unacceptably high currents in the cable screen if it is grounded at both ends.



**Information:**

The metallic parts of the instrument (process fitting, sensor, concentric tube, etc.) are connected with the internal and external ground terminal on the housing. This connection exists either directly via the conductive metallic parts or, in case of instruments with external electronics, via the screen of the special connection cable.

You can find specifications on the potential connections inside the instrument in chapter " *Technical data*".

## 5.2 Connecting

**Connection technology**

The voltage supply and signal output are connected via the spring-loaded terminals in the housing.

Connection to the display and adjustment module or to the interface adapter is carried out via contact pins in the housing.

**Connection procedure**

Proceed as follows:

1. Unscrew the housing lid
2. If a display and adjustment module is installed, remove it by turning it slightly to the left
3. Loosen compression nut of the cable gland and remove blind plug
4. Remove approx. 10 cm (4 in) of the cable mantle, strip approx. 1 cm (0.4 in) of insulation from the ends of the individual wires
5. Insert the cable into the sensor through the cable entry




Fig. 44: Connection steps 5 and 6

- 1 Single chamber housing
- 2 Double chamber housing

6. Insert the wire ends into the terminals according to the wiring plan



**Note:**

Fixed conductors and flexible conductors with ferrules can be inserted directly into the terminal openings. In the case of flexible conductors for opening the terminals, use a screwdriver (3 mm blade width) to push the actuator lever away from the terminal opening. When released, the terminals are closed again.

- 7. Check the hold of the wires in the terminals by lightly pulling on them
- 8. Connect the shielding to the internal ground terminal, connect the external ground terminal to potential equalisation
- 9. Tighten the compression nut of the cable entry gland. The seal ring must completely encircle the cable
- 10. Reinsert the display and adjustment module, if one was installed
- 11. Screw the housing lid back on

The electrical connection is finished.

### 5.3 Wiring plan, single chamber housing



The following illustration applies to the non-Ex as well as to the Ex-ia version.



## Electronics and connection compartment




Fig. 45: Electronics and connection compartment - single chamber housing

- 1 Voltage supply, signal output
- 2 For display and adjustment module or interface adapter
- 3 For external display and adjustment unit
- 4 Ground terminal for connection of the cable screening

## 5.4 Wiring plan, double chamber housing



The following illustrations apply to the non-Ex as well as to the Ex-ia version.

## Electronics compartment




Fig. 46: Electronics compartment - double chamber housing

- 1 Internal connection to the connection compartment
- 2 For display and adjustment module or interface adapter

## Connection compartment




Fig. 47: Connection compartment - double chamber housing

- 1 Voltage supply, signal output
- 2 For display and adjustment module or interface adapter
- 3 For external display and adjustment unit
- 4 Ground terminal for connection of the cable screening

## Wire assignment, connection cable




Fig. 48: Wire assignment in permanently connected connection cable

- 1 Brown (+) and blue (-) to power supply or to the processing system
- 2 Shielding

## 5.6 Switch-on phase

After connection to the power supply, the device carries out a self-test:

- Internal check of the electronics
- Output signal is set to failure

The current measured value is then output on the signal cable.

## 6 Access protection

### 6.1 Bluetooth radio interface

Devices with a Bluetooth radio interface are protected against unwanted access from outside. This means that only authorized persons can receive measured and status values and change device settings via this interface.

#### Bluetooth access code

A Bluetooth access code is required to establish Bluetooth communication via the adjustment tool (smartphone/tablet/notebook). This code must be entered once when Bluetooth communication is established for the first time in the adjustment tool. It is then stored in the adjustment tool and does not have to be entered again.

The Bluetooth access code is individual for each device. It is printed on the device housing and is also supplied with the device in the information sheet "PINs and Codes". It can be changed by the user after the first connection has been established. If the Bluetooth access code has not been entered correctly, a new entry can only be made after a waiting period has elapsed. The waiting time increases with each additional incorrect entry.

#### Emergency Bluetooth unlock code

The emergency Bluetooth access code enables Bluetooth communication to be established in the event that the Bluetooth access code is no longer known. It can't be changed. The emergency Bluetooth access code can be found in information sheet "Access protection". If this document is lost, the emergency Bluetooth access code can be retrieved from your personal contact person after legitimation. The storage and transmission of Bluetooth access codes is always encrypted (SHA 256 algorithm).

### 6.2 Protection of the parameterization

The settings (parameters) of the device can be protected against unwanted changes. The parameter protection is deactivated on delivery, all settings can be made.

#### Device code

To protect the parameterization, the device can be locked by the user with the aid of a freely selectable device code. The settings (parameters) can then only be read out, but not changed. The device code is also stored in the adjustment tool. However, unlike the Bluetooth access code, it must be re-entered for each unlock. When using the adjustment app or DTM, the stored device code is then suggested to the user for unlocking.

#### Emergency device code

The emergency device code allows unlocking the device in case the device code is no longer known. It can't be changed. The emergency device code can also be found on the supplied information sheet "Access protection". If this document is lost, the emergency device code can be retrieved from your personal contact person after legitimation. The storage and transmission of the device codes is always encrypted (SHA 256 algorithm).

### 6.3 Storing the codes in myVEGA

If the user has a "myVEGA" account, then the Bluetooth access code as well as the device code are additionally stored in his account under "*PINs and Codes*". This greatly simplifies the use of additional adjustment tools, as all Bluetooth access and device codes are automatically synchronized when connected to the "myVEGA" account

## 7 Functional safety (SIL)

### 7.1 Objective

#### Background

In case of dangerous failures, processing facilities and machines can cause risks for persons, environment and property. The risk of such failures must be judged by the plant operator. Dependent thereon are measures for risk reduction through error prevention, error detection and fault control.

#### Plant safety by risk reduction

The part of plant safety depending on the correct functioning of safety-related components for risk reduction is called functional safety. Components used in such safety-instrumented systems (SIS) must therefore execute their intended function (safety function) with a defined high probability.

#### Standards and safety levels

The safety requirements for such components are described in the international standards IEC 61508 and 61511, which set the standard for uniform and comparable judgement of instrument and plant (or machine) safety and hence contribute to worldwide legal certainty. We distinguish between four safety levels, from SIL1 for low risk to SIL4 for very high risk (SIL = Safety Integrity Level), depending on the required degree of risk reduction.

### 7.2 SIL qualification

#### Properties and requirements

When developing instruments that can be used in safety-instrumented systems, the focus is on avoiding systematical errors as well as determining and controlling random errors.

Here are the most important characteristics and requirements from the perspective of functional safety according to IEC 61508 (Edition 2):

- Internal monitoring of safety-relevant circuit parts
- Extended standardization of the software development
- In case of failure, switching of the safety-relevant outputs to a defined safe state
- Determination of the failure probability of the defined safety function
- Reliable parameterization with non-safe user environment
- Proof test

#### Safety Manual

The SIL qualification of components is specified in a manual on functional safety (Safety Manual). Here, you can find all safety-relevant characteristics and information the user and the planner need for planning and operating the safety-instrumented system. This document is attached to each instrument with SIL rating and can be also found on our homepage via the search.

### 7.3 Application area

The instrument can be used for point level detection or level measurement of liquids and bulk solids in safety-instrumented systems (SIS)

according to IEC 61508 and IEC 61511. Take note of the specifications in the Safety Manual.

The following output is permissible for this:

- Current output (I) - 4 ... 20 mA/HART



**Note:**

The second current output (II) does not fulfil the requirements of safety instrumented systems (SIS). In this context, it is for informational use only.

### Tool for operation and parameterization

## 7.4 Safety concept of the parameterization

The following tools are permitted for parameterization of the safety function:

- Adjustment app
- DTM suitable for the device in conjunction with an adjustment software according to the FDT/DTM standard, e. g. PACTware



**Note:**

For operation of the VEGAPULS 6X an actual adjustment app or DTM Collection is required. The modification of safety-relevant parameters is only possible with active connection to the instrument (online mode).

### Safe parameterization

To avoid possible errors during parameter adjustment in a non-safe user environment, a verification procedure is used that makes it possible to detect parameter adjustment errors reliably. For this, safety-relevant parameters must be verified after they are stored in the device. In normal operating condition, the instrument is also locked against parameter changes through unauthorized access.

### Safety-relevant parameters

The set parameters must be protected against accidental access to prevent unwanted or unauthorized adjustment. For this reason, the instrument is delivered in the locked state with SIL version.

When shipped with a specific parameter adjustment, the instruments are accompanied by a list with the values deviating from the default setting.

All safety-relevant parameters must be verified after a change.

The following parameters are safety-relevant:

- Type of medium
- Application
- Distance A (max. value)
- Distance B (min. value)
- Damping
- Current output
- Reaction when malfunctions occur
- False signal suppression
- Behaviour with echo loss

The parameter settings of the measuring point must be documented. A list of the safety-relevant parameters can be stored and printed additionally by the PACTware/DTM.

#### Unlock adjustment

For each parameter change, the device must be unlocked via the device code (see chapter " *Parameter adjustment, setup steps - Lock adjustment*"). The device status is indicated in the respective adjustment tool by the symbol of an unlocked or locked padlock.

#### Unsafe device status



##### Warning:

If adjustment is enabled, the safety function must be considered as unreliable. This applies until the parameterisation is terminated correctly. If necessary, other measures must be taken to maintain the safety function.

#### Change parameters

All parameters changed by the operator are automatically stored temporarily so that they can be verified in the next step.

#### Incomplete process



##### Warning:

If the described process was not carried out completely or correctly (e.g. due to interruption or voltage loss), the instrument remains in an unlocked, and thus unsafe, status.

#### Instrument reset



##### Warning:

When the device is reset to default settings, all of the safety-relevant parameters are reset. Therefore, these must be checked or readjusted afterwards.

## 7.5 First setup

### 7.5.1 Overview

The initial setup serves to check the device version and the current parameters under the existing measurement conditions. This determines whether this constellation is suitable for providing qualified measurement data for safety-related instrumentation.



To fulfil the requirements for SIL conformity, we recommend carrying out the first setup via the function " *Verify and lock (inclusive setup assistant)*". This function is available in the adjustment app as well as PACTware/DTM (see previous chapter " *Safety concept of the parameter adjustment, tools for adjustment and parameterisation*").

The central part of the initial setup is the function test. When running through the setup assistant, the device decides on the basis of its evaluation results which options of the function test are available in the individual case. See the following chapter " *Setup procedure*".

### 7.5.2 Setup process

#### Operating sequence

A parameter change with SIL qualified instruments must always be carried out as follows:

- Unlock adjustment
- Change parameters
- Function test if necessary

- Lock adjustment and verify modified parameters

The meaning and handling of the individual steps are described in the chapter " *Security concept for parameter adjustment*".

## Function test

The VEGAPULS 6X basically offers the following function test options:

- Without medium - empty vessel
- With medium - current level
- With medium - move to defined levels

The individual options are described in the following chapter.

## 7.6 Function test

### 7.6.1 Function test without medium - empty vessel

#### Description

Here, the user must start a measurement to determine the echo quality in an empty vessel. Based on these data, the device calculates over the entire measuring range whether an adequate output signal is available for every level when filling with medium later.

#### Procedure

The process is run by the setup wizard in the adjustment app or PACTware/DTM.

### 7.6.2 Function test with medium - any level

#### Description

Here, the user must start a measurement to evaluate the echo quality of the medium at the current level. Based on these data, the device calculates over the entire measuring range whether an adequate output signal is available for every other level.

#### Procedure

The process is run by the setup wizard in the adjustment app or PACTware/DTM.

### 7.6.3 Function test with medium - move to defined levels

#### Description

Here, the user must active perform a function test by moving to defined levels. Is then checking by several measurements whether the respective output signal corresponds to the actual level.



#### Note:

This option is always available regardless of the result of the check by the device.

#### Procedure

In this function test, you test the safety function of the device when it is installed in the vessel with original medium.

For this purpose, you should know the current filling height of the vessel as well as the min. and max. levels respectively for 4 and 20 mA. You then can calculate the respective output current.

Measure the output current of the device with a suitable multimeter and compare the measured output current with the calculated output current.

#### Interruption



If you have to interrupt the function test, you can leave the device in the respective situation. As long as the device is supplied with volt-



age, the display and adjustment module remains in the currently set adjustment menu.

If you carry out the function test by means of the "PACTware" software, you can store the previously performed tests and continue from there later on.

## Completion

If you click "Complete" the function test is completed, the parameters are verified and the operation of the device is blocked.



### Note:

When operated via PACTware/DTM, a setup protocol with the test results is provided for your system documentation.

## Function test

Proceed as follows:

### Mode of operation - monitoring of upper limit value:

1. Raise the level to directly below the switching point
2. Observe holding time of 1 minute, compare measured value with the calculated current value
3. Lower the level to directly above the switching point
4. Observe holding time of 1 minute, compare measured value with the calculated current value

### Mode of operation - monitoring of lower limit value:

1. Lower the level to directly above the switching point
2. Observe holding time of 1 minute, compare measured value with the calculated current value
3. Raise the level to directly below the switching point
4. Observe holding time of 1 minute, compare measured value with the calculated current value

### Mode "Range monitoring":

1. Move to level immediately above the upper range limit
2. Observe holding time of 1 minute, compare measured value with the calculated current value
3. Move to three levels within the range limits (upper, middle, lower value)
4. Observe holding time respectively of 1 minute, compare measured values with the calculated current values
5. Move to level immediately below the lower range limit
6. Observe holding time of 1 minute, compare measured value with the calculated current value

### Result:

The measured output current must in all cases correspond to the output current calculated for the respective level.



### Note:

You have to determine the permissible deviation of the values yourself. This deviation depends on the the accuracy requirements of your

measurement loop. For this, determine the permissible tolerance for the deviation.

## 7.7 Parameter adaptations after the first setup



### Note:

In the case of further parameter adaptations after the initial setup, the device checks the current checksum (CRC) of the parameters in each case.

If this is identical to the last checksum, the setup assistant no longer needs to be run through. In this case, the parameter adjustment is completed by simply "*Verify and lock*".

## 8 Set up with the display and adjustment module

### 8.1 Insert display and adjustment module

The display and adjustment module can be inserted into the sensor and removed again at any time. You can choose any one of four different positions - each displaced by 90°. It is not necessary to interrupt the power supply.

Proceed as follows:

1. Unscrew the housing lid
2. Place the display and adjustment module on the electronics in the desired position and turn it to the right until it snaps in.
3. Screw housing lid with inspection window tightly back on

Disassembly is carried out in reverse order.

The display and adjustment module is powered by the sensor, an additional connection is not necessary.



*Fig. 49: Installing the display and adjustment module in the electronics compartment of the single chamber housing*




Fig. 50: Installing the display and adjustment module in the double chamber housing

- 1 In the electronics compartment
- 2 In the connection compartment



#### Note:

If you intend to retrofit the instrument with a display and adjustment module for continuous measured value indication, a higher lid with an inspection glass is required.

## 8.2 Adjustment system




Fig. 51: Display and adjustment elements

- 1 LC display
- 2 Adjustment keys

### Key functions

- **[OK]** key:
  - Move to the menu overview
  - Confirm selected menu
  - Edit parameter
  - Save value
- **[>]** key:
  - Change measured value presentation
  - Select list entry
  - Select menu items
  - Select editing position
- **[+]** key:
  - Change value of the parameter

- **[ESC]** key:
  - Interrupt input
  - Jump to next higher menu

### Adjustment system

The instrument is operated via the four keys of the display and adjustment module. The individual menu items are shown on the LC display. You can find the function of the individual keys in the previous illustration.

### Time functions

When the **[+]** and **[>]** keys are pressed quickly, the edited value, or the cursor, changes one value or position at a time. If the key is pressed longer than 1 s, the value or position changes continuously.

When the **[OK]** and **[ESC]** keys are pressed simultaneously for more than 5 s, the display returns to the main menu. The menu language is then switched over to "English".

Approx. 60 minutes after the last pressing of a key, an automatic reset to measured value indication is triggered. Any values not confirmed with **[OK]** will not be saved.

## 8.3 Measured value indication - Selection of national language

### Measured value indication

With the **[>]** key you move between three different indication modes:



With the "OK" key you move to the menu overview.




#### Note:

During the first setup, you move with the "OK" key to the selection menu "Menu language".

### Menu language

In this menu item, you can select the menu language for further parameterization.



#### Information:

A later change of the selection is possible via the menu item "Setup, display, menu language".


With the "OK" key you move to the menu overview.

## 8.4 Parameterization

### 8.4.1 Lock/Unlock adjustment

### Lock/Unlock adjustment

In this menu item you safeguard the sensor parameters against unauthorized or unintentional modifications.



When the adjustment is blocked, only the following adjustment functions are possible without entering the device code:

- Select menu items and show data
- Read data from the sensor into the display and adjustment module

Releasing the sensor adjustment is also possible in any menu item by entering the PIN.



#### Caution:

When the adjustment is blocked, the adjustment via PACTware/DTM and other systems is also blocked.

### Lock/Unlock adjustment (SIL)

In this menu item you safeguard the sensor parameters against unauthorized or unintentional modifications.


To avoid possible errors during parameterization in a non-safe user environment, a verification procedure is used that makes it possible to detect parameterization errors reliably. For this, safety-relevant parameters must be verified before they are stored in the device. In normal operating condition, the instrument is also locked against parameter changes through unauthorized access.

For this reason, the device is delivered in a blocked state.



#### Information:

If the device code has been changed and forgotten, the enclosed information sheet "Access Protection" provides an emergency device code.




#### Character string comparison and serial number:

You first have to carry out the character string comparison. This is used to check the character representation.


Confirm if the two character strings are identical. The verification texts are provided in German and in the case of all other menu languages, in English.

Afterwards you confirm that the serial number of your instrument was carried over correctly. This is used to check device communication.



In the next step, the instrument checks the data of the measurement and decides by means of the evaluation results if a functions test

is required. If a function test is necessary, the following message is displayed.



In this case, you have to carry out a function test.

#### Function test:


During a function test, you have to test the safety function of the instrument in the vessel with the original medium.



You can find the detailed sequence of the function test in chapter "Functional safety (SIL)" of the operating instructions.

#### Verify parameter:

All safety-relevant parameters must be verified after a change. After the function test, all modified, safety-relevant parameters will be listed. Confirm the modified values one after the other.



If the described process of parameter adjustment was run through completely and correctly, the instrument will be locked and hence ready for operation.



Otherwise the instrument remains in the released and hence unsafe condition.


### 8.4.2 Setup

#### Measurement loop name

Here you can assign a suitable measurement loop name.

You can enter names with max. 19 characters. The character set comprises:

- Capital letters from A ... Z
- Numbers from 0 ... 9
- Special characters + - / \_ blanks



#### Distance unit

In this menu item you select the distance unit of the device.

Setup Measurement loop name <b>Distance unit</b> Type of medium Application Vessel height	Distance unit mm <input checked="" type="checkbox"/> <b>m</b> in ft
--	---

## Type of medium

This menu item allows you to adapt the sensor to the different measuring conditions of the media "Liquid" or "Bulk solid".





The corresponding application is selected in the following menu item "Application".

Setup Measurement loop name Distance unit <b>Type of medium</b> Application Vessel height	Type of medium Liquids	Type of medium <input checked="" type="checkbox"/> <b>Liquids</b> Bulk solid
--	---------------------------	--








## Application - liquid

With "Liquid", the applications are based on the following features, to which the measuring characteristic of the sensor is adjusted in particular:

Setup Distance unit Type of medium <b>Application</b> Vessel height Distance A (max. value)	Application <input checked="" type="checkbox"/> <b>Storage tank</b> Stirred vessel Dosing vessel Stilling tube Vessel/Collecting basin	Application Plastic tank Mobile plastic tank (IBC) <input checked="" type="checkbox"/> <b>Gauge measurement</b> Flow flume Pumping station
--	---	---

Application	Vessel	Process/measurement conditions	Further recommendations
Storage tank 	Large volume Upright cylindrical, horizontal round	Slow filling and emptying Smooth medium surface Multiple reflections from dished vessel ceiling Condensation	-
Stirrer vessel 	Large agitator blades of metal Installations like flow breakers, heating spirals Nozzle	Frequent, fast to slow filling and emptying Strongly agitated surface, foam and strong vortex generation Multiple reflections through dished vessel ceiling Condensation, buildup on the sensor	False signal suppression with running agitator
Dosing vessel 	Small vessels	Frequent and fast filling/emptying Tight installation situation Multiple reflections through dished vessel ceiling Product buildup, condensate and foam generation	-
Vessel/Collecting basin 	Large volume Upright cylindrical or rectangular	Slow filling and emptying Smooth medium surface Condensation	-



Application	Vessel	Process/measurement conditions	Further recommendations
Plastic tank (measurement through the vessel top) 		Measurement through the tank top, if appropriate to the application Condensation on the plastic ceiling In outdoor facilities, water and snow on vessel top possible	False signal suppression when measuring through the tank top When measuring through the tank top in outdoor areas protective roof for the measuring point
Transportable plastic tank (IBC) 	Small vessels	Material and thickness different Measurement through the vessel top, if appropriate to the application Changed reflection conditions as well as jumps in measured values when changing vessels	False signal suppression when measuring through the tank top When measuring through the tank top in outdoor areas protective roof for the measuring point
Gauge measurement in waters 		Slow gauge change Extreme damping of output signal in case of wave generation Ice and condensation on the antenna possible Floating debris sporadically on the water surface	-
Flow measurement flume/Overflow 		Slow gauge change Smooth to agitated water surface Measurement often from a short distance with the demand for accurate measurement results Ice and condensation on the antenna possible	-
Pumping station/ Pump shaft 		Partly strongly agitated surface Installations such as pumps and ladders Multiple reflections through flat vessel ceiling Dirt and grease deposits on shaft wall and sensor Condensation on the sensor	False signal suppression
Overflow basin (RÜB) 	Large volume Partly installed underground	Partly strongly agitated surface Multiple reflections through flat vessel ceiling Condensation, dirt deposits on the sensor Flooding of the sensor antenna	-
Demonstration 	Applications that are not typical level measurements, e.g. device tests	Instrument demonstration Object recognition/monitoring Fast position changes of a measuring plate during functional test	-






**Application - bulk solid**


With "Bulk solid", the applications are based on the following features, to which the measuring characteristic of the sensor is adjusted in particular:

Setup
Distance unit
Type of medium
<b>Application</b>
Vessel height
Distance A (max. value)

Anwendung
✓ Silo (schlank und hoch)
Bunker (großvolumig)
Brucher
Halde
Demonstration

Anwendung
✓ Silo (schlank und hoch)
Bunker (großvolumig)
Brucher
Halde
Demonstration


Application	Vessel	Process/measurement conditions	Further recommendations
	Slim and high Upright cylindrical	<p>Interfering reflections due to weld seams on the vessel</p> <p>Multiple echoes/diffuse reflections due to unfavourable pouring positions with fine grain</p> <p>Varying pouring positions due to outlet funnel and filling cone</p>	<p>False signal suppression</p> <p>Alignment of the measurement to the silo outlet</p>
	Large volume	<p>Large distance to the medium</p> <p>Steep angles of repose, unfavourable pouring positions due to outlet funnel and filling cone</p> <p>Diffuse reflections due to structured vessel walls or internals</p> <p>Multiple echoes/diffuse reflections due to unfavourable pouring positions with fine grain</p> <p>Changing signal conditions when large amounts of material slip off</p>	False signal suppression via adjustment app or DTM
		<p>Large distance to the medium</p> <p>Fast level changes e. g. by truck filling</p> <p>Steep angles of repose, unfavourable pouring positions due to outlet funnel and filling cone</p> <p>Interfering reflections from fixtures or protective devices</p>	False signal suppression via adjustment app or DTM
		<p>Measured value jumps and varying pouring positions, e.g. due to truck filling</p> <p>Fast reaction time</p> <p>Large distance to the medium</p> <p>Interfering reflections from fixtures or protective devices</p>	False signal suppression via adjustment app or DTM
	Large volume Upright cylindrical or rectangular	<p>Measured value jumps, e.g. through heap profile and traverses</p> <p>Large angles of repose, varying pouring positions</p> <p>Measurement near the filling stream</p> <p>Sensor mounting on movable conveyor belts</p>	-

Application	Vessel	Process/measurement conditions	Further recommendations
Demonstration 	Applications that are not typical level measurements, e.g. device tests	Instrument demonstration Object recognition/monitoring Measured value verification with higher measuring accuracy with reflection without bulk solids, e.g. via a measuring plate	-

### Tube inner diameter


With standpipe applications, the running time of the radar signal within the tube must be considered.

Hence the inner diameter of the respective sensor is entered in this menu item.



### Vessel height

Through this selection the operating range of the sensor is adapted to the vessel height. Hence the measurement reliability is increased considerably under different basic conditions.



#### Note:

Regardless of this, the min. adjustment must also be carried out (see following section).

### Adjustment

Since the radar sensor is a distance measuring instrument, it is the distance from the sensor to the medium surface that is measured. To indicate the actual level, the measured distance must be assigned to a certain height percentage (min./max. adjustment).

During adjustment, enter the respective measuring distance when the vessel is full and empty (see the following examples):


**Liquids:**

Fig. 52: Parameterisation example min./max. adjustment - liquids

- 1 Min. level = max. meas. distance (distance B)
- 2 Max. level = min. meas. distance (distance A)
- 3 Reference plane


**Bulk solids:**

Fig. 53: Parameterisation example min./max. adjustment - bulk solids

- 1 Min. level = max. meas. distance (distance B)
- 2 Max. level = min. meas. distance (distance A)
- 3 Reference plane

If these values are not known, and adjustment can for example be carried out with the distances of 10 % and 90 %.

The starting point for these distance specifications is always the reference plane, i.e. the sealing surface of the thread or flange. Information


on the reference plane can be found in chapter " *Technical data*". The actual filling height is then calculated on the basis of these entries.

The actual product level during this adjustment is not important, because the min./max. adjustment is always carried out without changing the product level. These settings can be made ahead of time without the instrument having to be installed.


### Distance A (max. value)

Proceed as follows:


1. Select with **[>]** the menu item Distance A (max. value) and confirm with **[OK]**.



2. Edit the percentage value with **[OK]** and set the cursor to the requested position with **[>]**.



3. Set the requested percentage value with **[+]** and save with **[OK]**. The cursor jumps now to the distance value.




4. Enter the corresponding distance value in meters for the full vessel.
5. Save settings with **[OK]** and move with **[ESC]** and **[>]** to Min. adjustment.


### Distance B (min. value)

Proceed as follows:


1. Select with **[>]** the menu item "Distance B (min. value)" and confirm with **[OK]**.



2. Edit the percentage value with **[OK]** and set the cursor to the requested position with **[>]**.



3. Set the requested percentage value with **[+]** and save with **[OK]**. The cursor jumps now to the distance value.






4. Enter the suitable distance value in m for empty vessel (e.g. distance from the sensor to the vessel bottom) corresponding to the percentage value.

### 8.4.3 Extended settings




#### Temperature unit

In this menu item you select the temperature unit of the device.






#### Damping

To damp process-dependent measured value fluctuations, set an integration time of 0 ... 999 s in this menu item.



#### Current output - Output value

In this menu item you determine which measured value is output via the respective current output:






The following selection possibilities are available:

- Percent
- Linearized percent
- Filling height
- Distance
- Scaled
- Measurement reliability
- Electronics temperature
- Measuring rate
- Operating voltage

#### Current output - Adjustment

Here you determine which heights of the output value belong to the current values 4 mA and 20 mA .



#### Note:

This menu item is only available if the following output values were selected for the current output:

- Measurement reliability
- Electronics temperature
- Measuring rate
- Operating voltage

### Current output - Output characteristics

In the menu item "Current output - Output characteristic" you select for 0 ... 100 % output value if the characteristic of the current output rises (4 ... 20 mA) or falls (20 ... 4 mA).

Current output Output value Current output - adjustment <b>Output characteristic</b> Current range Behaviour in case of failure	Output characteristic 0...100 % $\hat{=}$ 4...20 mA	Output characteristic <input checked="" type="checkbox"/> 0...100 % $\hat{=}$ 4...20 mA 0...100 % $\hat{=}$ 20...4 mA
--	--	---

### Current output - Current range

In the menu item "Current output - Current range" you determine the range of the current output as 4 ... 20 mA or 3.8 ... 20.5 mA.

Current output Output value Current output - adjustment Output characteristic <b>Current range</b> Behaviour in case of failure	Strombereich 3,8 ... 20,5 mA	Strombereich <input checked="" type="checkbox"/> 3,8 ... 20,5 mA 4 ... 20 mA
--	---------------------------------	--

### Current output - Reaction in case of fault

In the menu item "Current output - Behaviour in case of failure" you set the behaviour of the current output in case of failures as  $\leq 3.6$  mA or  $\geq 21$  mA resp. the last measured value.

Current output Output value Current output - adjustment Output characteristic Current range <b>Behaviour in case of failure</b>	Behaviour in case of failure $\leq 3,6$ mA	Behaviour in case of failure <input checked="" type="checkbox"/> $\leq 3,6$ mA $\geq 21$ mA Last valid measured value
--	---	--

### Linearisation

Linearisation is required for all vessels where the vessel volume does not increase linearly with the level and the display or output of the volume is desired. The same applies to flow measuring constructions and the relationship between flow and level.

Corresponding linearisation curves are stored for these measurement situations. They indicate the relationship between the percentage level and the vessel volume or flow rate. The selection depends on the selected linearisation type liquid or bulk solid.

Extended settings Damping Current output <b>Linearization</b> Scaling Display	Linearization <input checked="" type="checkbox"/> <b>Linear</b> Horiz. vessel Spherical tank Venturi Palmer-Bowllus Flume	Linearization <input checked="" type="checkbox"/> <b>Linear</b> Conical bottom Pyramid bottom Inclined bottom User programmable
--	--	--




#### Note:

The selected linearisation applies to the measured value indication and the signal output.

Depending on the medium and the vessel bottom, the intermediate height is also entered, see next menu item.


### Linearization - Intermediate height

The intermediate height is the beginning of the cylindrical area, e.g. for vessels with conical bottoms.




## Scaling

In the menu item "Scaling" you define the scaling variable and unit as well as the scaling format. By doing so, it is for example the indication of the level measured value for 0 % and 100 % on the display as volume in l is possible.



## Display - Menu language

This menu item enables the setting of the requested national language.




The following languages are available:

- German
- English
- French
- Spanish
- Portuguese
- Italian
- Dutch
- Russian
- Chinese
- Japanese
- Turkish

## Display - Presentation

With the [->] key you move between three different indication modes:

- Measured value in large font
- Measured value and corresponding bargraph presentation
- Measured value as well as second selectable value, e.g. electronics temperature






During the initial setup of an instrument shipped with factory settings, use the "OK" key to get to the menu "National language".

## Display - Displayed value 1, 2



In this menu item, you determine which measured values is displayed.





### Display - Lighting

The display and adjustment module has a backlight for the display. In this menu item you can switch the lighting on or off. You can find the required operating voltage in chapter " *Technical data*".



#### Note:

If the power supply is currently insufficient, the lighting is temporarily switched off (maintaining the device function).

### False signal suppression

The following circumstances cause interfering reflections and can influence the measurement:

- High mounting nozzles
- Vessel internals such as struts
- Agitators
- Buildup or welded joints on vessel walls

A false signal suppression detects, marks and saves these false signals to ensure that they are ignored in the level measurement.






#### Note:

The false signal suppression should be done with the lowest possible level so that all potential interfering reflections can be detected.

#### Create new:

Proceed as follows:

1. Select with **[>]** the menu item " *False signal suppression*" and confirm with **[OK]**.




2. Confirm 3-times with **[OK]** and enter the actual distance from the sensor to the product surface.
3. All interfering signals in this range are detected by the sensor and stored after being confirmed with **[OK]**.



#### Note:

Check the distance to the medium surface, because if an incorrect (too large) value is entered, the existing level will be saved as a false signal. The level would then no longer be detectable in this area.

If a false signal suppression has already been saved in the sensor, the following menu window appears when selecting " *False signal suppression*":

**Delete all:**


An already created false signal suppression will be completely deleted. This is useful if the saved false signal suppression no longer matches the metrological conditions in the vessel.

**Extend:**

Is used to extend an already created false signal suppression. This is useful if a false signal suppression was carried out with too high a level and not all false signals could be detected. When selecting "Extend", the distance to the product surface of the created false signal suppression is displayed. This value can now be changed and the false signal suppression can be extended to this range.

**Date/Time**

In this menu item, the internal clock of the sensor is set to the desired time.

**Note:**

The device is set to CET (Central European Time) at the factory.

**HART mode**

In this menu item you specify the HART mode and enter the address for multidrop mode.




**HART address 0:**

In the menu item "Output mode" the "Analogue current output" is displayed and a 4 ... 20 mA signal output.

**HART address deviation from 0:**

In the menu item "Output mode" "Fixed current (4 mA)" is displayed and independent of the actual level a fixed 4 mA signal output. The level is output digitally via the HART signal.


In the mode "Fixed current" up to 63 sensors can be operated on one two-wire cable (Multidrop operation). An address between 0 and 63 must be assigned to each sensor.

**Mode**

This menu item contains operational settings of the sensor.

**Mode:**

Country specific settings for the radar signals are determined via the operating mode.



- Mode 1: EU, Albania, Andorra, Azerbaijan, Australia, Belarus, Bosnia and Herzegovina, Canada, Liechtenstein, Moldavia, Monaco, Montenegro, New Zealand, Northern Macedonia, Norway, San Marino, Saudi Arabia, Serbia, Switzerland, Turkey, Ukraine, United Kingdom, USA
- Mode of operation 2: Brazil, Japan, South Korea, Taiwan, Thailand
- Mode of operation 3: India, Malaysia, South Africa
- Mode of operation 4: Russia, Kazakhstan




### Note:

Depending on the operating mode, metrological properties of the device can change (see chapter " *Technical data, input variable*").

### Voltage supply:

The power supply determines whether the sensor is in operation permanently or only in accordance with certain requirements.



### Copy instrument settings

The following functions are available:



### Load from sensor:

Store data from sensor in the display and adjustment module.

### Write to sensor:

Store data from display and adjustment module in the sensor

The following device settings are copied:

- Measurement loop name
- Application
- Units
- Adjustment
- Damping
- Current output
- Linearisation
- Special parameters
- Scaling
- Indication
- PV adjustment
- Mode
- Diagnostic behaviour

The copied data are permanently saved in an EEPROM memory in the display and adjustment module and remain there even in case of power failure. From there, they can be written into one or more sensors or kept as backup for a possible electronics exchange.




#### Note:

Before the data are saved in the sensor, a safety check is carried out to determine if the data match the sensor. In the process the sensor type of the source data as well as the target sensor are displayed. If the data do not match, a fault message is outputted or the function is blocked. The data are saved only after release.

## Special parameters

Special parameters are used to adapt the sensor to special requirements. However, this is only necessary in rare cases.

However, only change the special parameters after consulting our service staff.



The special parameters can be reset to factory settings with "Reset".




#### Note:

The special parameters are described in a separate section at the end of the chapter "Parameter adjustment".

## 8.4.4 Access protection

### Bluetooth access code

This menu item enables to change the factory-preset Bluetooth access code to your personal Bluetooth access code.



#### Note:

You can find the individual factory Bluetooth access code of the device on the information sheet supplied "PINs and Codes".


### Protection of the parameterization

This menu item allows you to protect the sensor parameters from unwanted or unintended changes. To activate the protection, you must define and enter a 6-digit device code.



#### Note:

For SIL devices, the protection of the parameterisation is activated ex works. These devices have an individual device code. You will find it in the information sheet supplied "PINs and Codes".



When protection is activated, the individual menu items can still be selected and displayed. However, the parameters can no longer be changed.

Releasing the sensor adjustment is also possible in any menu item by entering the device code.




**Note:**

With protected parameter adjustment, adjustment via the adjustment app as well as PACTware/DTM and other systems is also blocked.

**Device code**

This menu item allows you to change the device code. It is only displayed if the parameterisation protection has been activated beforehand.




**Note:**

The changed device code is also effective for adjustment via the adjustment app, PACTware/DTM and other systems.

**Reset access code**


This menu item allows you to reset the device and Bluetooth access code to the factory settings.



### 8.4.5 Reset

**Reset**

During a reset, parameter settings made by the user are reset to the values of the factory settings. You can find the values in chapter "Menu overview".



**Note:**

The language and Bluetooth access code are not reset, a currently running simulation however is aborted.

The following reset functions are available:

**Reset - Factory settings:**

Restores the factory parameters settings as well as the order-specific settings at the time of delivery. A user-set measuring range is reset to the recommended measuring range, see chapter "Technical data". A created false signal suppression, freely programmed linearization curve as well as measured value and echo curve memories are cleared. The event and parameter changes memories are retained.

**Reset - Restart:**

Is used to restart the device without switching off the supply voltage.

**Note:**




For the duration of the reset, the device changes its behaviour from the normal measuring operation. Therefore, observe for downstream systems:

- The current output outputs the set false signal
- The Asset-Management function outputs the message "Maintenance" aus




**8.4.6 Diagnostics****Diagnosis status**

The following is displayed in this menu item:

- Diagnosis status (device status OK or error messages)
- Change counter (number of the parameter changes)
- Current checksum CRC (checksum for plausibility of the set parameters) with date of the last change
- Checksum (CRC) of the last SIL locking with date

**Echo curve**

The "Echo curve" shows the signal strength of the echoes over the measuring range in dB. This enables an evaluation of the quality of the measurement.



The selected curve is continuously updated. A submenu with zoom functions is opened with the **[OK]** key:


- "X-Zoom": Zoom function for the meas. distance
- "Y-Zoom": 1, 2, 5 and 10x signal magnification in "dB"
- "Unzoom": Reset the presentation to the nominal measuring range without magnification

**Measured values/pointer function**

The following min./max. values saved by the sensor are displayed in the menu item "Measured values/Pointer function":

- Distance
- Measurement reliability
- Measuring rate
- Electronics temperature
- Operating voltage


The **[OK]** key opens a reset function in the respective pointer function window:



With the **[OK]** key, the peak values are reset to the actual measured values.

### Diagnostic behaviour


In this menu item, you define what the signal output outputs in the event of an echo loss. For this purpose, the time after an echo loss until a fault message is selected.



### Sensor information

In this menu item the following information of the instrument can be read out:

- Device name
- Order and serial number
- Hardware and software version
- Device Revision
- Factory calibration date




### Sensor characteristics

The menu item " *Sensor characteristics* " delivers sensor characteristics such as approval, process fitting, seal, measuring range etc.



### Simulation

In this menu item you can simulate measured values via the current output. This allows the signal path to be tested, e.g. through downstream indicating instruments or the input card of the control system.



Select the requested simulation variable and set the requested value.



#### Caution:


During simulation, the simulated value is output as 4 ... 20 mA current value and as digital HART signal. The status message within the context of the asset management function is " *Maintenance* ".



#### Note:


The sensor terminates the simulation automatically after 60 minutes.

To deactivate the simulation manually in advance, you have to push the **[ESC]** key and confirm the message with the **[OK]** key.



## Device memory

The menu item Device memory offers the following functions:



### Echo curve of the setup:

With the function "Echo curve of the setup" it is possible to store the echo curve at the time of the setup. Storage should be carried out at the lowest possible level.



### Note:

This is generally recommended, even mandatory, for using the asset management functionality.

### Echo curve memory:

The function "Echo curve memory" allows up to ten individual echo curves to be stored, for example to detect the measurement behaviour of the sensor in different operating conditions.

With the adjustment software PACTware and the PC, the stored echo curves can be displayed with high resolution and used to recognize signal changes over time. In addition, the echo curve saved during setup can also be displayed in the echo curve window and compared with the current echo curve.

## 8.4.7 Special parameters

### SP01 - Activate measuring range start limiting

Measuring range start limiting is activated here. The appropriate distance value is set by the special parameter SP02.

This can prevent measured value jumps to a changing false signal in the close range. But the activation also means that the level echo will no longer be accepted in case of overfilling beyond the measuring range start and a measured value jump to a multiple echo takes place.

### SP02 - Manual measuring range start limiting

Here, the measuring range start is limited individually independently of the 100 % adjustment. The entered value must always be smaller than the distance from the sensor reference point to the maximum level.

### SP03 - Echo detection below the 0 % adjustment

This is an additional distance value that is added to the special parameter SP24 to reliably detect the zero point in case of insufficient reflections at the bottom of the vessel.



The echo detection below the 0 % adjustment should support the reliable detection of an echo in a totally empty vessel, e. g. when the vessel height is not entered exactly.

**SP04 - Correction of the propagation speed**

This parameter serves as a correction factor for correcting the propagation speed, e. g. in case of running time errors in standpipes or a higher dielectric constant of the atmosphere in the vessel.

**SP05/06 - Factor for noise averaging rising/falling**

Noise averaging can be understood as a temporal, floating average value formation of all signals received by the sensor. The set factor determines the number of averaged echo curves as a Basis 2 exponent (example: factor 2 corresponds to the averaging of  $2^2 [= 4]$  echo curves).

Sporadically occurring echos, e. g. by agitator blades or level echos with fluctuating amplitude, can be influenced by these factors.

A higher factor for noise averaging can lead to a longer reaction time or a measured value update.

**SP07 - Deactivate filter function "Smooth raw value curve"**

This parameter is always switched on ex-factory and acts as a digital filter over the raw value curve depending on the selected application.

It usually improves the measurement reliability. Therefore, it is advisable to only switch it off in very special application cases to be clarified.

**SP08 - Offset detection curve for echo analysis**

Only echoes which exceed the detection curve are detected and processed as echoes. This parameter reduces the sensitivity of the echo detection and signal analysis by increasing the dB value.

This affects the level echo to the same extent. Therefore, the application is only used with very strong false signals and simultaneously good reflection properties of the medium.

**SP09 - Minimum measurement reliability for level echo selection**

This parameter defines the minimum signal strength of a reflection signal necessary for signal detection and output as a level signal.

By entering a minimum measurement certainty as a dB value, false signals below this value are not accepted as a level echo.

**SP10 - Additional reliability of false signal storage**

The amplitude of the false signal suppression is increased by the entered dB value. This prevents such a false signal from being accepted as a level echo.

An increase is useful for very heavily fluctuating or amplitude-increasing false signals. It is advised against reducing the value of the default setting.

**SP12 - Activate "Summarize echoes" function**

This parameter serves to activate and select the summary function of two closely adjacent echo signals.

This helps to suppress measured value jumps resulting from material cones or emptying hoppers in built material applications when filling and emptying.

**SP13 - Amplitude difference in "Summarize echoes" function**

The value entered here determines how great the maximum amplitude difference between two adjacent echoes may be in order to summarize them.

**SP14 - Echo distance for "Summarize echoes" function**

The value entered here determines how great the distance between the end of the first echo and the start of the second echo may be at the maximum in order for them to be summarized.

**SP15 - Activate "First large echo" function**

When this parameter is activated, the first echo not saved as a false echo with sufficiently great amplitude is selected as a product echo. This is useful for very large multiple reflections by e. g. a round vessel lid.

**SP16 - Minimum amplitude "First large echo"**

The value entered here determines the maximum difference between the large reflection signal and the reflection signal of the medium so that this is evaluated as the first large echo and thus as the product echo.

**SP17 - Wide focussing range**

This parameter determines the measuring window width around the currently measured level echo in which fast distance changes of the reflections are possible.

Very fast level changes e. g. due to gushing wakes or sudden filling/emptying are then accepted within a limited range.

**SP18 - Minimum measurement reliability outside focussing range**

The value entered here determines the necessary measurement reliability (difference between echo amplitude and detection curve) for echoes outside the measuring window.

This is useful to obtain the measured value also in case of sporadic loss of the level signal, e. B. with foam generation.

**SP19 - Time for opening the focussing range**

This parameter determines the time until opening the measuring window when no more reflection is detectable within the focussing range. This may be the case e.g. with a level change without an evaluable reflection signal or with an echo outside the focussing range with a great useful echo probability.

As a result, on reaching this echo with high useful echo probability, this is evaluated as a useful echo and output as the current level.

**SP22 - Measured value offset**

The measured value offset enables adaptation of the factory set sensor reference plane to later fitted assembly devices such as adapter flanges, threaded adapters, etc.

A possible offset error is then compensated by this entry.

**SP24 - Factor for additional reliability at the measuring range end**

This factor is a percentage, additional reliability below the 0% adjustment related to the measuring range end.

It is entered to reliably detect the zero point in case of inadequate reflections at the bottom of the vessel.

**SP HART - HART signal**

This parameter serves to activate/deactivate the HART signal in the output.

**SP SIL - Safety Integrity Level function**

This parameter serves to activate/deactivate the Safety Integrity Level function.

**On paper**

**8.5 Save parameter adjustment data**

We recommended writing down the adjustment data, e.g. in this operating instructions manual, and archiving them afterwards. They are thus available for multiple use or service purposes.

**In the display and adjustment module**

If the instrument is equipped with a display and adjustment module, the parameter adjustment data can be saved therein. The procedure is described in menu item "*Copy device settings*".

## 9 Set up with Smartphone/tablet

### 9.1 Preparations

#### System requirements

Make sure that your smartphone/tablet meets the following system requirements:

- Operating system: iOS 8 or newer
- Operating system: Android 5.1 or newer
- Bluetooth 4.0 LE or newer

Download the VEGA Tools app from the "Apple App Store", "Google Play Store" or "Baidu Store" to your smartphone or tablet.

Make sure that the Bluetooth function of the display and adjustment module is activated. For this, the switch on the bottom side must be set to "On".

Factory setting is "On".




Fig. 54: Activate Bluetooth

1 Switch

On = Bluetooth active

Off = Bluetooth not active

### 9.2 Connecting

#### Connecting

Start the adjustment app and select the function "Setup". The smartphone/tablet searches automatically for Bluetooth-capable instruments in the area.

The message "Connecting ..." is displayed.

The devices found are listed and the search is automatically continued.

Select the requested instrument in the device list.

#### Authenticate

When establishing the connection for the first time, the operating tool and the sensor must authenticate each other. After the first correct authentication, each subsequent connection is made without a new authentication query.

## Enter Bluetooth access code

For authentication, enter the 6-digit Bluetooth access code in the next menu window. You can find the code on the information sheet "*Pins and Codes*" in the device packaging.

For the very first connection, the adjustment unit and the sensor must authenticate each other.




Fig. 55: Enter Bluetooth access code



### Note:

If an incorrect code is entered, the code can only be entered again after a delay time. This time gets longer after each incorrect entry.

The message "*Waiting for authentication*" is displayed on the smartphone/tablet.

## Connected

After connection, the sensor adjustment menu is displayed on the respective adjustment tool.

If the Bluetooth connection is interrupted, e.g. due to a too large distance between the two devices, this is displayed on the adjustment tool. The message disappears when the connection is restored.

## Change device code

Parameter adjustment of the device is only possible if the parameter protection is deactivated. When delivered, parameter protection is deactivated by default and can be activated at any time.

It is recommended to enter a personal 6-digit device code. To do this, go to menu "*Extended functions*", "*Access protection*", menu item "*Protection of the parameter adjustment*".

## 9.3 Parameterization

### Enter parameters

The sensor adjustment menu is divided into two areas, which are arranged next to each other or one below the other, depending on the adjustment tool.

- Navigation section
- Menu item display

The selected menu item can be recognized by the colour change.




Fig. 56: Example of an app view - Setup measured values

Enter the requested parameters and confirm via the keyboard or the editing field. The settings are then active in the sensor.

Close the app to terminate connection.

## 10 Set up with PC/notebook

### 10.1 Preparations (Bluetooth)

#### System requirements

Make sure that your PC/notebook meets the following system requirements:

- Operating system Windows 10
- DTM Collection 10/2020 or newer
- Bluetooth 4.0 LE or newer

Make sure that the Bluetooth function of the display and adjustment module is activated. For this, the switch on the bottom side must be set to "On".

Factory setting is "On".




Fig. 57: Activate Bluetooth

1 Switch

On = Bluetooth active

Off = Bluetooth not active

#### Activate Bluetooth connection

Activate the Bluetooth connection via the project assistant.



#### Note:

Older systems do not always have an integrated Bluetooth LE. In these cases, a Bluetooth USB adapter is required. Activate the Bluetooth USB adapter using the Project Wizard.

After activating the integrated Bluetooth or the Bluetooth USB adapter, devices with Bluetooth are found and created in the project tree.

### 10.2 Connecting (Bluetooth)

#### Connecting

Select the requested device for the online parameter adjustment in the project tree.

#### Authenticate

When establishing the connection for the first time, the operating tool and the device must authenticate each other. After the first correct authentication, each subsequent connection is made without a new authentication query.

## Enter Bluetooth access code

For authentication, enter in the next menu window the 6-digit Bluetooth access code:

Fig. 58: Enter Bluetooth access code

You can find the code on the outside of the device housing and on the information sheet "PINs and Codes" in the device packaging.



### Note:

If an incorrect code is entered, the code can only be entered again after a delay time. This time gets longer after each incorrect entry.

The message "Waiting for authentication" is displayed on the PC/notebook.

## Connected

After connection, the device DTM appears.

If the connection is interrupted, e.g. due to a too large distance between device and adjustment tool, this is displayed on the adjustment tool. The message disappears when the connection is restored.

## Change device code

Parameter adjustment of the device is only possible if the parameter protection is deactivated. When delivered, parameter protection is deactivated by default and can be activated at any time.

It is recommended to enter a personal 6-digit device code. To do this, go to menu "Extended functions", "Access protection", menu item "Protection of the parameter adjustment".



### 10.3 Connect the PC (VEGACONNECT)

Via the interface adapter directly on the sensor




Fig. 59: Connection of the PC directly to the sensor via the interface adapter

- 1 USB cable to the PC
- 2 Interface adapter VEGACONNECT
- 3 Sensor

Via the interface adapter and HART




Fig. 60: Connecting the PC via HART to the signal cable

- 1 Sensor
- 2 HART resistance 250  $\Omega$  (optional depending on evaluation)
- 3 Connection cable with 2 mm pins and terminals
- 4 Processing system/PLC/Voltage supply
- 5 Interface adapter, for example VEGACONNECT 4



#### Note:

With power supply units with integrated HART resistance (internal resistance approx. 250  $\Omega$ ), an additional external resistance is not necessary. This applies, e.g. to the VEGA instruments VEGATRENN 149A, VEGAMET 381, VEGAMET 391. Common Ex separators are also usually equipped with a sufficient current limiting resistance. In such cases, the interface adapter can be connected parallel to the 4 ... 20 mA cable (dashed line in the previous illustration).

### 10.4 Parameterization

For parameter adjustment of the instrument via a Windows PC, the configuration software PACTware and a suitable instrument driver (DTM) according to FDT standard are required. The latest PACTware version as well as all available DTMs are compiled in a DTM Collec-

#### Prerequisites

tion. The DTMs can also be integrated into other frame applications according to FDT standard.



### Note:

To ensure that all instrument functions are supported, you should always use the latest DTM Collection. Furthermore, not all described functions are included in older firmware versions. You can download the latest instrument software from our homepage. A description of the update procedure is also available in the Internet.

Further setup steps are described in the operating instructions manual "DTM Collection/PACTware" attached to each DTM Collection and which can also be downloaded from the Internet. Detailed descriptions are available in the online help of PACTware and the DTMs.




Fig. 61: Example of a DTM view

## Standard/Full version

All device DTMs are available as a free-of-charge standard version and as a full version that must be purchased. In the standard version, all functions for complete setup are already included. An assistant for simple project configuration simplifies the adjustment considerably. Saving/printing the project as well as import/export functions are also part of the standard version.

In the full version there is also an extended print function for complete project documentation as well as a save function for measured value and echo curves. In addition, there is a tank calculation program as well as a multiviewer for display and analysis of the saved measured value and echo curves.

The standard version is available as a download under [www.vega.com/downloads](http://www.vega.com/downloads) and "Software". The full version is available on CD from the agency serving you.

## 10.5 Save parameter adjustment data

We recommend documenting or saving the parameterisation data via PACTware. That way the data are available for multiple use or service purposes.

## 11 Menu overview

### 11.1 Display and adjustment module

#### Lock/Unlock adjustment

Menu item	Parameter	Selection	Default setting
Lock/Unlock adjustment		Lock, unlock	Released

#### Setup

Menu item	Parameter	Selection	Default setting
Measurement loop name			Sensor
Distance unit	Distance unit	mm, m, in, ft	m
Type of medium	Type of medium	Liquid	Liquid <sup>7)</sup>
		Bulk solid	Bulk solid <sup>8)</sup>
Application	Application - liquid	Storage tank, agitator tank, dosing tank, standpipe, tank/collection basin, plastic tank (measurement through tank top), mobile plastic tank (IBC), level measurement in waters, flow measurement flume/overflow, pump station/pump shaft, combined sewer overflow, demonstration	Storage tank <sup>9)</sup>
	Application - bulk solid	Silo, bunker, crusher, heap, demonstration	Silo <sup>10)</sup>
Tube inner diameter	Tube inner diameter		-
Vessel height			Recommended meas. range, see chapter " <i>Technical data</i> "
Distance A (max. value)	Max. value		Max. adjustment 100 % corresponds to 0,000 m
Distance B (min. value)	Min. value		Min. adjustment 0 % corresponds to 120,000 m

#### Extended settings

Menu item	Parameter	Selection	Default setting
Temperature unit		°C, °F, K	°C

<sup>7)</sup> Plastic horn antenna, thread with integrated antenna system, flange with plastic plating

<sup>8)</sup> Flange with lens antenna

<sup>9)</sup> Plastic horn antenna, thread with integrated antenna system, flange with plastic plating

<sup>10)</sup> Flange with lens antenna

Menu item	Parameter	Selection	Default setting
Damping	Integration time	0 ... 999 s	1 s
Current output	Output value	Percent, linearized percent, filling height, distance, scaled, measurement reliability, electronics temperature, meas. rate, supply voltage	Percent
	Initial value characteristics	Initial value - characteristics (4 mA)	4 mA correspond to
	Final value characteristics	End value - characteristics (20 mA)	20 mA correspond to
	Output characteristics	0 ... 100 % correspond to 4 ... 20 mA	0 ... 100 % correspond to 4 ... 20 mA
		0 ... 100 % correspond to 20 ... 4 mA	
	Current range	4 ... 20 mA	4 ... 20 mA
		3.8 ... 20.5 mA	
	Reaction when malfunctions occur	≤ 3.6 mA, ≥ 21 mA, last valid measured value	≤ 3.6 mA
Linearisation	Linearization type - liquid	Linear, cylindrical tank, spherical tank, Venturi, trapezoidal weir, rectangular weir, Palmer-Bowlus flume, V-Notch, triangular overfall	Linear
	Linearization type - bulk solids	Linear, conical bottom, pyramid bottom, sloping bottom	Linear
	Intermediate height "h"		
Scaling	Scaling size	Scaling size (dimensionless, mass, volume, height, pressure, flow, others)	Dimensionless
		Scaling unit (unit selection depending on scaling size, user-defined)	-
	Scaling format	#, #.#, #.##, #.###, #.####, #.#####	#
	Scaling	Scaling	100 % correspond to 0 % correspond to
Indication	Menu language	German, English, French, Spanish, Portuguese, Italian, Dutch, Russian, Chinese, Japanese, Turkish, Polish	Order-specific
	Presentation	One measured value, measured value and bargraph, two measured values	One measured value
	Displayed values 1, 2	Percent, linearized percent, filling height, distance, scaled, measurement reliability, electronics temperature, current output, current output 2	Percent
	Backlight	On, Off	On
False signal suppression	False signal suppression	Create new, expand, delete all	-
Date/Time	Date/Time	Date	Actual date
		Format: 24 h, 12 h	24 h
		Time	Actual time

Menu item	Parameter	Selection	Default setting
HART mode	HART address	0 ... 63	0
	Output mode	Analogue current output with HART, fix current (4 mA) with HART	Analogue current output with HART
Mode	Mode	Mode 1: EU, Albania, Andorra, Azerbaijan, Australia, Belarus, Bosnia and Herzegovina, Canada, Liechtenstein, Moldavia, Monaco, Montenegro, New Zealand, Northern Macedonia, Norway, San Marino, Saudi Arabia, Serbia, Switzerland, Turkey, Ukraine, United Kingdom, USA Mode of operation 2: Brazil, Japan, South Korea, Taiwan, Thailand Mode of operation 3: India, Malaysia, South Africa Mode 4: Russia	Mode 1
		Permanent voltage supply	Permanent voltage supply
		Non-permanent voltage supply	
Copy instrument settings		Read from sensor, store in sensor	-
Special parameters	See separate menu overview at the end of the chapter "Menu overview" of the operating instructions.		

## Access protection

Menu item	Parameter	Selection	Default setting
Access protection	Bluetooth access code	Bluetooth access code	
	Protection of the parameterization	Protection of the parameterization	
	Device code	Device code	
	Reset access code	Reset device code and Bluetooth access code to factory settings	

## Reset

Menu item	Parameter	Selection	Default setting
Reset	Reset	Reset to factory settings, Restart	-

## Diagnostics

Menu item	Parameter	Selection/Display	Default setting
Diagnosis status	Diagnosis status	Diagnosis status	-
		Change counter	-
		Checksum (CRC) current	Date parameter adjustment
		Checksum (CRC) last SIL locking	Date last SIL locking

Menu item	Parameter	Selection/Display	Default setting
Echo curve		Echo curve	Indication of echo curve
Measured values/ pointer function	Distance	Current value, min. distance, max. distance	Actual value
	Measurement reliability	Current value, min. measurement reliability, max. measurement reliability	Actual value
	Measuring rate	Current value, min. meas. rate, max. meas. rate	Actual value
	Electronics temperature	Current value, min. electronics temperature, max. electronics temperature	Actual value
	Operating voltage	Current value, min. voltage supply, max. voltage supply	Actual value
Diagnostic behaviour	Behaviour with echo loss	Last measured value, maintenance message, fault signal	Last measured value
	Behaviour with echo loss	Maintenance message, fault message	Last measured value
	Time until fault signal	Time until fault signal	
Sensor information		Device name, serial number, hardware/software version, device revision, factory calibration date	-
Sensor characteristics			Configuration features
Simulation	Measured value	Percent, linearized percent, filling height, distance, scaled, measurement reliability, electronics temperature, measuring rate, operating voltage, current output, current output 2	Percent
Device memory	Echo curve of the setup	Save echo curve of setup	-
	Echo curve memory	Echo curve memory	

## 11.2 VEGA Tools app and PACTware/DTM

### Lock/Unlock adjustment

Menu item	Parameter	Selection	Default setting
Lock/Unlock adjustment		Lock, unlock	Released

### Setup

Menu item	Parameter	Selection	Default setting
Measurement loop name			Sensor
Distance unit	Distance unit	mm, m, in, ft	m

Menu item	Parameter	Selection	Default setting
Type of medium	Type of medium	Liquid	Liquid <sup>11)</sup>
		Bulk solid	Bulk solid <sup>12)</sup>
Application	Application - liquid	Storage tank, agitator tank, dosing tank, standpipe, tank/collection basin, plastic tank (measurement through tank top), mobile plastic tank (IBC), level measurement in waters, flow measurement flume/overflow, pump station/pump shaft, combined sewer overflow, demonstration	Storage tank <sup>13)</sup>
	Application - bulk solid	Silo, bunker, crusher, heap, demonstration	Silo <sup>14)</sup>
Tube inner diameter	Tube inner diameter		-
Vessel height			Recommended meas. range, see chapter " <i>Technical data</i> "
Distance A (max. value)	Max. value		Max. adjustment 100 % corresponds to 0,000 m
Distance B (min. value)	Min. value		Min. adjustment 0 % corresponds to 120,000 m

### Extended settings

Menu item	Parameter	Selection	Default setting
Damping	Integration time	0 ... 999 s	1 s

<sup>11)</sup> Plastic horn antenna, thread with integrated antenna system, flange with plastic plating

<sup>12)</sup> Flange with lens antenna

<sup>13)</sup> Plastic horn antenna, thread with integrated antenna system, flange with plastic plating

<sup>14)</sup> Flange with lens antenna



Menu item	Parameter	Selection	Default setting
Current output	Output value	Percent, linearized percent, filling height, distance, scaled, measurement reliability, electronics temperature, measuring rate, operating voltage	Percent
	Initial value - Characteristic	Initial value - characteristics (4 mA)	4 mA correspond to
	Final value - Characteristic	End value - characteristics (20 mA)	20 mA correspond to
	Output characteristics	0 ... 100 % correspond to 4 ... 20 mA	0 ... 100 % correspond to 4 ... 20 mA
		0 ... 100 % correspond to 20 ... 4 mA	
	Current range	4 ... 20 mA	4 ... 20 mA
		3.8 ... 20.5 mA	
	Reaction when malfunctions occur	≤ 3.6 mA, ≥ 21 mA, last valid measured value	≤ 3.6 mA
	Reaction when malfunctions occur	≤ 3.6 mA, ≥ 21 mA	≤ 3.6 mA
Linearisation	Linearization type - liquid	Linear, cylindrical tank, spherical tank, Venturi, trapezoidal weir, rectangular weir, Palmer-Bowlus flume, V-Notch, triangular overfall	Linear
	Linearization type - bulk solids	Linear, conical bottom, pyramid bottom, sloping bottom	Linear
	Intermediate height "h"		-
Scaling	Scaling size	Dimensionless, mass, volume, height, pressure, flow, others	Dimensionless
	Scaling unit	Unit selection depending on scaling size, user-defined	-
	Name of the unit		-
	Scaling format	#, #.#, #.##, #.###, #.####	#
	Scaling	100 % correspond to 0 % correspond to	100 L 0 L
Indication	Menu language (PLICSCOM)	German, English, French, Spanish, Portuguese, Italian, Dutch, Russian, Chinese, Japanese, Turkish, Polish	Order-specific
	Presentation	One measured value, measured value and bargraph, two measured values	One measured value
	Displayed values 1, 2	Percent, linearized percent, filling height, distance, scaled, measurement reliability, electronics temperature, current output, current output 2	Percent
	Backlight	On, Off	On
False signal suppression	False signal suppression	Create new, expand, delete all	-

Menu item	Parameter	Selection	Default setting
Date/Time	Date/Time	Date	Actual date
		Format: 24 h, 12 h	24 h
		Time	Actual time
HART variables	HART variables	Primary Value (PV)	Prozent, Lin Pro-
		Secondary Value (SV)	zent, Füllhöhe,
		Tertiary Value (TV)	Distanz, Skaliert,
		Quarternary Value (QV)	Messsickeit Ele- ktroniktemperatur, Messrate Betriebss- pannung
Mode	Mode	Mode 1: EU, Albania, Andorra, Azerbaijan, Australia, Belarus, Bosnia and Herzegovina, Canada, Liechtenstein, Moldavia, Monaco, Montenegro, New Zealand, Northern Mac- edonia, Norway, San Marino, Saudi Arabia, Serbia, Switzerland, Turkey, Ukraine, United Kingdom, USA  Mode of operation 2: Brazil, Japan, South Korea, Taiwan, Thailand  Mode of operation 3: India, Malaysia, South Africa  Mode 4: Russia	Mode 1
Special parameters	See separate menu overview at the end of the chapter " <i>Menu overview</i> "		

### Access protection

Menu item	Parameter	Selection	Default setting
Access protection	Bluetooth access code	Bluetooth access code	
	Protection of the parameterization	Protection of the parameterization	
	Device code	Device code	

### Reset




Menu item	Parameter	Selection	Default setting
Reset	Reset	Reset to factory settings, Restart	-











### Diagnostics


Menu item	Parameter	Selection/Display	Default setting
Diagnosis status	Diagnosis status	Diagnosis status	-
		Change counter	-
		Checksum (CRC) current	Date parameter adjustment
		Checksum (CRC) last SIL locking	Date last SIL locking

Menu item	Parameter	Selection/Display	Default setting
Echo curve		Echo curve	Indication of echo curve
Measured values/ pointer function	Distance	Current value, min. distance, max. distance	Actual value
	Measurement reliability	Current value, min. measurement reliability, max. measurement reliability	Actual value
	Measuring rate	Current value, min. meas. rate, max. meas. rate	Actual value
	Electronics temperature	Current value, min. electronics temperature, max. electronics temperature	Actual value
	Operating voltage	Current value, min. voltage supply, max. voltage supply	Actual value
Diagnostic behaviour	Behaviour with echo loss	Last measured value, maintenance message, fault signal	Last measured value
	Behaviour with echo loss	Maintenance message, fault message	Last measured value
	Time until fault signal	Time until fault signal	
Sensor information		Device name, serial number, hardware/software version, device revision, factory calibration date	-
Sensor characteristics			Configuration features
Simulation	Measured value	Percent, linearized percent, filling height, distance, scaled, measurement reliability, electronics temperature, measuring rate, operating voltage, current output, current output 2	Percent
Device memory	Echo curve of the setup	Save echo curve of setup	-
	Echo curve memory	Echo curve memory	

## 11.3 Special parameters

Parameter	Presentation	Selection	Default setting
SP1, SP2		Activate measuring range start limiting Manual limiting of measuring range start	
SP3		Echo detection below the 0 % adjustment	
SP4		Correction of the propagation speed	

Parameter	Presentation	Selection	Default setting
SP5, SP6		Factor for noise averaging rising Factor for noise averaging falling	
SP7		Deactivate filter function "Smooth raw value curve"	
SP8		Offset detection curve for echo analysis	
SP9		Minimum measurement reliability for level echo selection	
SP10		Additional reliability for false signal storage	
SP12		Activate "Summarize echoes" function	
SP13		Amplitude difference in "Summarize echoes" function	
SP14		Echo distance for "Summarize echoes" function	
SP15		Activate function measurement of the "first large echo"	
SP16		Minimum amplitude function "First large echo"	
SP17		Wide focussing range	
SP18		Minimum measurement reliability outside focussing range	
SP19		Time for opening the focussing range	
SP22		Measured value offset	

Parameter	Presentation	Selection	Default setting
SP24		Factor for additional reliability at measuring range end	
SP HART		Activate/deactivate HART signal	
SP SIL		Activate/deactivate Safety Integrity Level function	

## 12 Set up with other systems

### 12.1 DD adjustment programs

Device descriptions as Enhanced Device Description (EDD) are available for DD adjustment programs such as, for example, AMS™ and PDM.

The files can be downloaded at [www.vega.com/downloads](http://www.vega.com/downloads) under "*Software*".

### 12.2 Field Communicator 375, 475

Device descriptions for the instrument are available as EDD for parameterisation with Field Communicator 375 or 475.

Integrating the EDD into the Field Communicator 375 or 475 requires the "Easy Upgrade Utility" software, which is available from the manufacturer. This software is updated via the Internet and new EDDs are automatically accepted into the device catalogue of this software after they are released by the manufacturer. They can then be transferred to a Field Communicator.

In the HART communication, the Universal Commands and a part of the Common Practice Commands are supported.

## 13 Diagnosis, asset management and service

### 13.1 Maintenance

#### Maintenance

If the device is used properly, no special maintenance is required in normal operation.

#### Precaution measures against buildup



##### Information:

In some applications, product buildup on the antenna system can influence the measurement result.

Depending on the sensor and application, take measures to avoid heavy soiling of the antenna system. If necessary, clean the antenna system in certain intervals.

#### Cleaning

The cleaning helps that the type label and markings on the instrument are visible.



##### Note:

Unsuitable cleaning agents and methods can damage the device. To avoid this, observe the following:

- Use only cleaning agents which do not corrode the housings, type label and seals
- Use only cleaning methods corresponding to the housing protection rating

### 13.2 Measured value and event memory

The instrument has several memories available for diagnostic purposes. The data remain there even in case of voltage interruption.

#### Measured value memory

Up to 100,000 measured values can be stored in the sensor in a ring memory. Each entry contains date/time as well as the respective measured value. Storable values are for example:

- Distance
- Filling height
- Percentage value
- Lin. percent
- Scaled
- Current value
- Measurement reliability
- Electronics temperature

When the instrument is shipped, the measured value memory is active and stores distance, measurement reliability and electronics temperature every 3 minutes.

The requested values and recording conditions are set via a PC with PACTware/DTM or the control system with EDD. Data are thus read out and also reset.

#### Event memory

Up to 500 events are automatically stored with a time stamp in the sensor (non-deletable). Each entry contains date/time, event type, event description and value. Event types are for example:

- Modification of a parameter
- Switch-on and switch-off times
- Status messages (according to NE 107)
- Error messages (according to NE 107)

The data are read out via a PC with PACTware/DTM or the control system with EDD.

### Echo curve memory

The echo curves are stored with date and time and the corresponding echo data. The memory is divided into two sections:

**Echo curve of the setup:** This is used as reference echo curve for the measurement conditions during setup. Changes in the measurement conditions during operation or buildup on the sensor can thus be recognized. The echo curve of the setup is stored via:

- PC with PACTware/DTM
- Control system with EDD
- Display and adjustment module

**Further echo curves:** Up to 10 echo curves can be stored in a ring buffer in this memory section. Additional echo curves are stored via:

- PC with PACTware/DTM
- Control system with EDD

## 13.3 Asset Management function

The instrument features self-monitoring and diagnostics according to NE 107 and VDI/VDE 2650. In addition to the status messages in the following tables there are more detailed error messages available under the menu item "Diagnostics" via the respective adjustment module.

### Status messages

The status messages are divided into the following categories:

- Failure
- Function check
- Out of specification
- Maintenance required

and explained by pictographs:




Fig. 62: Pictographs of the status messages

- 1 Failure - red
- 2 Out of specification - yellow
- 3 Function check - orange
- 4 Maintenance required - blue

**Failure:** Due to a malfunction in the instrument, a fault signal is output.



This status message is always active. It cannot be deactivated by the user.

**Function check:** The instrument is being worked on, the measured value is temporarily invalid (for example during simulation).

This status message is inactive by default.

**Out of specification:** The measured value is unreliable because an instrument specification was exceeded (e.g. electronics temperature).

This status message is inactive by default.

**Maintenance required:** Due to external influences, the instrument function is limited. The measurement is affected, but the measured value is still valid. Plan in maintenance for the instrument because a failure is expected in the near future (e.g. due to buildup).

This status message is inactive by default.

## Failure

Code Text message	Cause	Rectification	DevSpec State in CMD 48
F013 no measured value available	Sensor does not detect an echo during operation Antenna system dirty or defective	Check or correct installation and/or parameter settings Clean or exchange process component or antenna	Byte 5, Bit 0 of Byte 0 ... 5
F017 Adjustment span too small	Adjustment not within specification	Change adjustment according to the limit values (difference between min. and max. $\geq 10$ mm)	Byte 5, Bit 1 of Byte 0 ... 5
F025 Error in the linearization table	Values are not continuously rising, for example illogical value pairs	Check linearization table Delete table/Create new	Byte 5, Bit 2 of Byte 0 ... 5
F036 No operable software	Failed or interrupted software update	Repeat software update Check electronics version Exchanging the electronics Send instrument for repair	Byte 5, Bit 3 of Byte 0 ... 5
F040 Error in the electronics	Hardware defect	Exchanging the electronics Send instrument for repair	Byte 5, Bit 4 of Byte 0 ... 5
F080 General software error	General software error	Disconnect operating voltage briefly	Byte 5, Bit 5 of Byte 0 ... 5
F105 Determine measured value	The instrument is still in the switch-on phase, the measured value could not yet be determined	Wait for the end of the switch-on phase Duration up to approx. 3 minutes depending on the version and parameter settings	Byte 5, Bit 6 of Byte 0 ... 5
F113 Communication error	EMC interference	Remove EMC influences	Byte 4, Bit 4 of Byte 0 ... 5

<b>Code</b> <b>Text message</b>	<b>Cause</b>	<b>Rectification</b>	<b>DevSpec</b> <b>State in CMD 48</b>
F125 Impermissible electronics temperature	Temperature of the electronics in the non-specified range	Check ambient temperature Insulate electronics Use instrument with higher temperature range	Byte 5, Bit 7 of Byte 0 ... 5
F260 Error in the calibration	Error in the calibration carried out in the factory Error in the EEPROM	Exchanging the electronics Send instrument for repair	Byte 4, Bit 0 of Byte 0 ... 5
F261 Error in the instrument settings	Error during setup False signal suppression faulty Error when carrying out a reset	Repeat setup Carry out a reset	Byte 4, Bit 1 of Byte 0 ... 5
F264 Installation/Setup error	Adjustment not within the vessel height/measuring range Max. measuring range of the instrument not sufficient	Check or correct installation and/or parameter settings Use an instrument with bigger measuring range	Byte 4, Bit 2 of Byte 0 ... 5
F265 Measurement function disturbed	Sensor no longer carries out a measurement Operating voltage too low	Check operating voltage Carry out a reset Disconnect operating voltage briefly	Byte 4, Bit 3 of Byte 0 ... 5
F267 No executable sensor software	Sensor cannot start	Exchanging the electronics Send instrument for repair	-

**Function check**

<b>Code</b> <b>Text message</b>	<b>Cause</b>	<b>Rectification</b>	<b>DevSpec</b> <b>State in CMD 48</b>
C700 Simulation active	A simulation is active	Finish simulation Wait for the automatic end after 60 mins.	"Simulation Active" in "Standardized Status 0"

**Out of specification**

<b>Code</b> <b>Text message</b>	<b>Cause</b>	<b>Rectification</b>	<b>DevSpec</b> <b>State in CMD 48</b>
S600 Impermissible electronics temperature	Temperature of the processing electronics in the non-specified section	Check ambient temperature Insulate electronics Use instrument with higher temperature range	Byte 23, Bit 0 of Byte 14 ... 24
S601 Overfilling	Level echo in the close range not available	Reduce level 100 % adjustment: Increase value Check mounting socket Remove possible interfering signals in the close range	Byte 23, Bit 1 of Byte 14 ... 24
S603 Impermissible operating voltage	Operating voltage below specified range	Check electrical connection If necessary, increase operating voltage	

## Maintenance

Code Text message	Cause	Rectification	DevSpec State in CMD 48
M500 Error during the re- set "delivery status"	The data could not be restored during the reset to delivery status	Repeat reset Load XML file with sensor data in- to the sensor	Byte 24, Bit 0 of Byte 14 ... 24
M501 Error in the non- active linearisation table	Hardware error EEPROM	Exchanging the electronics Send instrument for repair	Byte 24, Bit 1 of Byte 14 ... 24
M504 Error at a device in- terface	Hardware defect	Check connections Exchanging the electronics Send instrument for repair	Byte 24, Bit 4 of Byte 14 ... 24
M505 No echo available	Sensor does not detect an echo during operation Antenna dirty or defective	Clean the antenna Use a more suitable antenna/ sensor Remove possible false echoes Optimize sensor position and ori- entation	Byte 24, Bit 5 of Byte 14 ... 24
M506 Installation/Setup error	Error during setup	Check or correct installation and/ or parameter settings	Byte 24, Bit 6 of Byte 14 ... 24
M507 Error in the instru- ment settings	Error during setup Error when carrying out a reset False signal suppression faulty	Carry out reset and repeat setup	Byte 24, Bit 7 of Byte 14 ... 24

## 13.4 Rectify faults

### Reaction when malfunc- tion occurs

The operator of the system is responsible for taking suitable meas-  
ures to rectify faults.

### Fault rectification

The first measures are:

- Evaluation of fault messages
- Checking the output signal
- Treatment of measurement errors

A smartphone/tablet with the adjustment app or a PC/notebook with  
the software PACTware and the suitable DTM offer you further com-  
prehensive diagnostic possibilities. In many cases, the causes can be  
determined in this way and the faults eliminated.

### 4 ... 20 mA signal

Connect a multimeter in the suitable measuring range according to  
the wiring plan. The following table describes possible errors in the  
current signal and helps to eliminate them:

Error	Cause	Rectification
4 ... 20 mA signal not stable	Fluctuating measured value	Set damping

Error	Cause	Rectification
4 ... 20 mA signal missing	Electrical connection faulty	Check connection, correct, if necessary
	Voltage supply missing	Check cables for breaks; repair if necessary
	Operating voltage too low, load resistance too high	Check, adapt if necessary
Current signal greater than 22 mA, less than 3.6 mA	Sensor electronics defective	Replace device or send in for repair depending on device version

### Treatment of measurement errors

The below tables show typical examples of application-related measurement errors with liquids. The measurement errors are differentiated according to the following:

- Constant level
- Filling
- Emptying

The images in column "Error pattern" show the real level as a broken line and the level displayed by the sensor as a continuous line.




Fig. 63: Display of error images

1 Real level

2 Level displayed by the sensor






#### Note:

If the output level is constant, the cause could also be the fault setting of the current output to "Hold value".




If the level is too low, the reason could be a line resistance that is too high






### Measurement error with constant level

Fault description	Cause	Rectification
Measured value shows a too low or too high level 	Min./max. adjustment not correct	Adapt min./max. adjustment
	Incorrect linearization curve	Adapt linearization curve
	Installation in a bypass tube or standpipe, hence running time error (small measurement error close to 100 %/large error close to 0 %)	Check parameter "Application" with respect to vessel form, adapt if necessary (bypass, standpipe, diameter).





Fault description	Cause	Rectification
Measured value jumps towards 0 % (liquids only) 	Multiple echo (vessel top, medium surface) with amplitude higher than the level echo.	Check parameter "Application", especially vessel top, type of medium, dished bottom, high dielectric constant, and adapt if necessary.
Measured value jumps towards 100 % 	Due to the process, the amplitude of the level echo sinks A false signal suppression was not carried out	Carry out a false signal suppression
	Amplitude or position of a false signal has changed (e.g. condensation, buildup); false signal suppression no longer matches actual conditions.	Determine the reason for the changed false signals, carry out false signal suppression, e.g. with condensation.

## Measurement error during filling

Fault description	Cause	Rectification
Measured value remains unchanged during filling 	False signals in the close range too big or level echo too small Strong foam or vortex generation Max. adjustment not correct	Eliminate false signals in the close range Check measurement situation: Antenna must protrude out of the nozzle, installations Remove contamination on the antenna In case of interferences due to installations in the close range: Change polarisation direction Create a new false signal suppression Adapt max. adjustment
Measured value remains in the area of the bottom during filling 	Echo from the tank bottom larger than the level echo, for example, with products with $\epsilon_r < 2.5$ oil-based, solvents	Check parameters Medium, Vessel height and Floor form, adapt if necessary
Measured value remains momentarily unchanged during filling and then jumps to the correct level 	Turbulence on the medium surface, quick filling	Check parameters, change if necessary, e.g. in dosing vessel, reactor

Fault description	Cause	Rectification
Measured value jumps towards 0 % during filling 	Amplitude of a multiple echo (vessel top - medium surface) is larger than the level echo.	Check parameter "Application", especially vessel top, type of medium, dished bottom, high dielectric constant, and adapt if necessary.
	The level echo cannot be distinguished from the false signal at a false signal position (jumps to multiple echo).	In case of interferences due to installations in the close range: Change polarisation direction Chose a more suitable installation position
	Transverse reflection from an extraction funnel, amplitude of the transverse reflection larger than the level echo	Direct sensor to the opposite funnel wall, avoid crossing with the filling stream.
Measured value fluctuates around 10 ... 20 % (only bulk solids) 	Various echoes from an uneven medium surface, e.g. a material cone	Check parameter "Material Type" and adapt, if necessary Optimize installation position and sensor orientation
	Reflections from the medium surface via the vessel wall (deflection)	Select a more suitable installation position, optimize sensor orientation, e.g. with a swivelling holder
Measured value jumps towards 100 % during filling 	Due to strong turbulence and foam generation during filling, the amplitude of the level echo sinks. Measured value jumps to false signal.	Carry out a false signal suppression
Measured value jumps sporadically to 100 % during filling 	Varying condensation or contamination on the antenna.	Carry out a false signal suppression or increase false signal suppression with condensation/contamination in the close range by editing. Use radar sensor with flexible antenna cover for bulk materials.
Measured value jumps to $\geq 100$ % or 0 m distance 	Level echo is no longer detected at close range due to foam generation or interference signals at close range.	Check measuring point: Antenna should protrude out of the threaded mounting socket, possible false echoes through flange socket. Remove contamination on the antenna Use a sensor with a more suitable antenna

## Measurement error during emptying

Fault description	Cause	Rectification
<p>Measured value remains unchanged in the close range during emptying</p> 	<p>False signal larger than the level echo Level echo too small</p>	<p>Eliminate false signal in the close range. Check: Antenna must protrude from the nozzle.</p> <p>Remove contamination on the antenna</p> <p>In case of interferences due to installations in the close range: Change polarisation direction</p> <p>After eliminating the false signals, the false signal suppression must be deleted. Carry out a new false signal suppression.</p>
<p>Measured value jumps towards 0 % during emptying</p> 	<p>Echo from the tank bottom larger than the level echo, for example, with products with <math>\epsilon_r &lt; 2.5</math> oil-based, solvents</p>	<p>Check parameters Medium type, Vessel height and Floor form, adapt if necessary</p>
<p>Measured value jumps sporadically towards 100 % during emptying</p> 	<p>Varying condensation or contamination on the antenna</p>	<p>Carry out false signal suppression or increase false signal suppression in the close range by editing.</p> <p>With bulk solids, use radar sensor with purging air connection.</p>
<p>Measured value fluctuates around 10 ... 20 % (only bulk solids)</p> 	<p>Various echoes from an uneven medium surface, e.g. an extraction funnel</p> <p>Reflections from the medium surface via the vessel wall (deflection)</p>	<p>Check parameter "Type of medium" and adapt, if necessary.</p> <p>Optimize installation position and sensor orientation.</p>

### Reaction after fault rectification

Depending on the reason for the fault and the measures taken, the steps described in chapter "Setup" must be carried out again or must be checked for plausibility and completeness.

### 24 hour service hotline

Should these measures not be successful, please call in urgent cases the VEGA service hotline under the phone no. **+49 1805 858550**.

The hotline is also available outside normal working hours, seven days a week around the clock.

Since we offer this service worldwide, the support is provided in English. The service itself is free of charge, the only costs involved are the normal call charges.

## 13.5 Exchanging the electronics module

If the electronics module is defective, it can be replaced by the user.



In Ex applications, only instruments and electronics modules with appropriate Ex approval may be used.

If there is no electronics module available on site, the electronics module can be ordered through the agency serving you. The electronics modules are adapted to the respective sensor and differ in signal output or voltage supply.

The new electronics module must be loaded with the default settings of the sensor. These are the options:

- In the factory
- Or on site by the user

In both cases, the serial number of the sensor is needed. The serial numbers are stated on the type label of the instrument, on the inside of the housing as well as on the delivery note.

When loading on site, the order data must first be downloaded from the Internet (see operating instructions " *Electronics module*").



**Caution:**

All application-specific settings must be entered again. That's why you have to carry out a fresh setup after exchanging the electronics.

If you saved the parameter settings during the first setup of the sensor, you can transfer them to the replacement electronics module. A fresh setup is then not necessary.

## 13.6 Software update

The device software can be updated in the following ways:

- Interface adapter VEGACONNECT
- Bluetooth

Depending on the method, the following components are required:

- Instrument
- Voltage supply
- Interface adapter VEGACONNECT
- Display and adjustment module PLICSCOM with Bluetooth function
- PC with PACTware/DTM and Bluetooth USB adapter
- Current instrument software as file

You can find the current instrument software as well as detailed information on the procedure in the download area of our homepage: [www.vega.com](http://www.vega.com).

You can find information about the installation in the download file.



**Caution:**

Instruments with approvals can be bound to certain software versions. Therefore make sure that the approval is still effective after a software update is carried out.

You can find detailed information in the download area at [www.vega.com](http://www.vega.com).



### 13.7 How to proceed if a repair is necessary

You can find an instrument return form as well as detailed information about the procedure in the download area of our homepage. By doing this you help us carry out the repair quickly and without having to call back for needed information.

In case of repair, proceed as follows:

- Print and fill out one form per instrument
- Clean the instrument and pack it damage-proof
- Attach the completed form and, if need be, also a safety data sheet outside on the packaging
- Ask the agency serving you to get the address for the return shipment. You can find the agency on our homepage.

## 14 Dismount

### 14.1 Dismounting steps

**Warning:**

Before dismantling, be aware of dangerous process conditions such as e.g. pressure in the vessel or pipeline, high temperatures, corrosive or toxic media etc.

Take note of chapters "*Mounting*" and "*Connecting to voltage supply*" and carry out the listed steps in reverse order.

### 14.2 Disposal

The instrument consists of materials which can be recycled by specialised recycling companies. We use recyclable materials and have designed the electronics to be easily separable.

**WEEE directive:**

The instrument does not fall in the scope of the EU WEEE directive. Article 2 of this Directive exempts electrical and electronic equipment from this requirement if it is part of another instrument that does not fall in the scope of the Directive. These include stationary industrial plants.

Pass the instrument directly on to a specialised recycling company and do not use the municipal collecting points.

If you have no way to dispose of the old instrument properly, please contact us concerning return and disposal.

## 15 Certificates and approvals

### 15.1 Radio licenses

**Radar:**

The device has been tested and approved in accordance with the current edition of the applicable country-specific norms or standards.

The confirmations as well as regulations for use can be found in the document " *Radio licenses*" supplied or on our homepage.

### 15.2 Approvals for Ex areas

Approved versions for use in hazardous areas are available or in preparation for the device or the device series.

You can find the relevant documents on our homepage.

### 15.3 Approvals as overfill protection

Approved versions for use as part of an overfill protection system are available or in preparation for the device or the device series.

The corresponding approvals can be found on our homepage.

### 15.4 Food and pharmaceutical certificates

Versions for use in the food and pharmaceutical industries are available or in preparation for the device or the device series.

The corresponding certificates can be found on our homepage.

### 15.5 EU conformity

The device fulfils the legal requirements of the applicable EU directives. By affixing the CE marking, we confirm the conformity of the instrument with these directives.

The EU conformity declaration can be found on our homepage.

### 15.6 NAMUR recommendations

NAMUR is the automation technology user association in the process industry in Germany. The published NAMUR recommendations are accepted as the standard in field instrumentation.

The device fulfils the requirements of the following NAMUR recommendations:

- NE 21 – Electromagnetic compatibility of equipment
- NE 43 – Signal level for fault information from measuring transducers
- NE 53 – Compatibility of field devices and display/adjustment components
- NE 107 – Self-monitoring and diagnosis of field devices

For further information see [www.namur.de](http://www.namur.de).

### 15.7 IT - Security

The device is available as a version with IT security according to IEC 62443-4-2 or in preparation. To ensure that the staggered safety strategy of the device is effective as intended, the requirements from the VEGA " *Security Guidelines*" as well as the " *Component Requirements*" must be observed.

You can find the corresponding VEGA " *Security Guidelines*" as well as the certification on our homepage, the " *Component Requirements*" via " *myVEGA* ".

### 15.8 Safety Integrity Level (SIL)

The device is available as a version with SIL qualification according to IEC 61508 or in preparation.

The corresponding certificate can be found on our homepage.

### 15.9 Environment management system

Protection of the environment is one of our most important duties. That is why we have introduced an environment management system with the goal of continuously improving company environmental protection. The environment management system is certified according to DIN EN ISO 14001. Please help us fulfil this obligation by observing the environmental instructions in chapters " *Packaging, transport and storage*", " *Disposal*" of these operating instructions.

## 16 Supplement

### 16.1 Technical data

#### Note for approved instruments

The technical data in the respective safety instructions which are included in delivery are valid for approved instruments (e.g. with Ex approval). These data can differ from the data listed herein, for example regarding the process conditions or the voltage supply.

All approval documents can be downloaded from our homepage.

#### Materials and weights

##### Materials, wetted parts

###### Plastic horn antenna

- |                        |                                   |
|------------------------|-----------------------------------|
| – Adapter flange       | PP-GF30 black                     |
| – Seal, adapter flange | FKM (COG VI500), EPDM (COG AP310) |
| – Focussing lense      | PP                                |

###### Thread with integrated antenna system

- |                        |                   |
|------------------------|-------------------|
| – Process fitting      | 316L              |
| – Antenna              | PVDF              |
| – Seal, antenna system | FKM               |
| – Process seal         | Klingersil C-4400 |

###### Flange with plastic plating

- |   |      |
|---|------|
| – Flange plating, antenna encapsulation | PTFE |
|---|------|

###### Hygienic fitting

- |  |  |
|--|--|
| – Hygienic antenna encapsulation                         | PEEK   |
| – Surface roughness of the antenna encapsulation         | $R_a < 0.8 \mu\text{m}$                                  |
| – Additional process seal with certain hygienic fittings | FKM (SHS FPM 70C3 GLT), EPDM (A+P 70.10-02), Kalrez 6230 |

###### Flange with lens antenna

- |                        |   |
|------------------------|---|
| – Process fitting      | 316L  |
| – Antenna              | PEEK  |
| – Seal, antenna system | FKM (SHS FPM 70C3 GLT), FFKM (Kalrez 6375, G75B), EPDM (A+P 70.10-02) |

###### Rinsing air connection

- |                                       |  |
|---------------------------------------|--|
| – Flushing ring                       | PP-GFK                                   |
| – O-ring seal, purging air connection | FKM (SHS FPM 70C3 GLT), EPDM (COG AP310) |
| – Reflux valve                        | 316Ti                                    |
| – Sealing, reflux valve               | FKM (SHS FPM 70C3 GLT), EPDM (COG AP310) |

##### Materials, non-wetted parts

###### Mounting parts

- |  |           |
|--|-----------|
| – Antenna cone, plastic horn antenna, compression flange | PBT-GF 30 |
|--|-----------|

- Mounting strap, fixing screws mounting strap 316L
- Fixing screws, adapter flange 304

**Housing**

- Plastic housing Plastic PBT (Polyester)
- Aluminium die-cast housing Aluminium die-casting AlSi10Mg, powder-coated (Basis: Polyester)
- Stainless steel housing 316L
- Cable gland, blind plug cable gland PA, stainless steel, brass
- Sealing, cable gland NBR
- Inspection window housing cover Polycarbonate (UL-746-C listed), glass <sup>15)</sup>
- Ground terminal 316L

**Weights**

- Instrument (depending on housing, process fitting and antenna) approx. 2 ... 17.2 kg (4.409 ... 37.92 lbs)

**Torques****Max. torque, plastic horn antenna**

- Mounting screws, mounting strap on sensor housing 4 Nm (2.950 lbf ft)
- Flange screws, compression flange DN 80 5 Nm (3.689 lbf ft)
- Terminal screws, adapter flange - antenna 2.5 Nm (1.844 lbf ft)
- Flange screws, adapter flange DN 100 7 Nm (5.163 lbf ft)

**Max. torque, thread with integrated antenna system**

- G $\frac{3}{4}$  30 Nm (22.13 lbf ft)
- G1 $\frac{1}{2}$  200 Nm (147.5 lbf ft)
- G1 $\frac{1}{2}$  (with PTFE threaded adapter) 5 Nm (3.688 lbf ft)

**Torque, flange with plastic plating**

- Required torque of the flange screws for standard flanges 60 Nm (44.25 lbf ft)
- Recommended torque for tightening the flange screws of standard flanges 60 ... 100 Nm (44.25 ... 73.76 lbf ft)

**Max. torque, hygienic fittings**

- Flange screws DRD connection 20 Nm (14.75 lbf ft)

**Max. torque, version flange with lens antenna**

- Terminal screws for swivelling holder 8 Nm (5.9 lbf ft)

**Max. torque for NPT cable glands and Conduit tubes**

- Plastic housing 10 Nm (7.376 lbf ft)
- Aluminium/Stainless steel housing 50 Nm (36.88 lbf ft)

<sup>15)</sup> Glass with Aluminium and stainless steel housing

## Input variable

Measured variable

The measured quantity is the distance between the end of the sensor antenna and the medium surface. The reference plane for the measurement and the usable measuring range are dependent on the antenna system.




Fig. 64: Data of the input variable

- 1 Reference plane (depending on the antenna system)
- 2 Measured variable, max. measuring range
- 3 Utilisable measuring range (depending on the antenna version)

Max. measuring range 120 m (393.7 ft)

Recommended measuring range, depending on the antenna version and size <sup>16)17)</sup>

Antenna version	Size	Recommended measuring range up to
Thread with integrated antenna system	G¾, ¾ NPT	10 m (32.81 ft)
	G1, 1 NPT	20 m (65.62 ft)
	G1½, 1½ NPT	30 m (98.42 ft)
Plastic horn antenna	DN 80	120 m (393.7 ft)
Flange with plastic plating, hygienic fittings	≥ DN 25	20 m (65.62 ft)
	≥ DN 50, 2"	30 m (98.42 ft)
	≥ DN 80, 3"	120 m (393.7 ft)
Flange with lens antenna	≥ DN 50, 2"	30 m (98.42 ft)
	≥ DN 80, 3"	120 m (393.7 ft)

blocking distance <sup>18)</sup>

- Modes 1, 2, 4 0 mm (0 in)
- Mode 3 ≥ 250 mm (9.843 in)

## Switch-on phase

Run-up time  $t$  ( $U_B \geq 24$  V DC) ≤ 15 s <sup>19)</sup>

Starting current for run-up time ≤ 3.6 mA

<sup>16)</sup> With good reflection conditions, larger measuring ranges are also possible.

<sup>17)</sup> The specified values correspond to the default values on delivery

<sup>18)</sup> Depending on the operating conditions

<sup>19)</sup> Reference conditions:  $U_B = 24$  V DC, ambient temperature 20 °C (68 °F)

**Output variable**

Output signal	4 ... 20 mA/HART
Range of the output signal	3.8 ... 20.5 mA/HART (default setting)
Signal resolution	0.3 $\mu$ A
Resolution, digital	1 mm (0.039 in)
Fault signal, current output (adjustable)	$\leq 3.6$ mA, $\geq 21$ mA, last valid measured value
Max. output current	22 mA
Starting current	$\leq 3.6$ mA; $\leq 10$ mA for 5 ms after switching on
Load	See load resistance under Power supply
Damping (63 % of the input variable), adjustable	0 ... 999 s
HART output values according to HART 7.0 <sup>20)</sup>	
– PV (Primary Value)	Lin. percent
– SV (Secondary Value)	Distance
– TV (Third Value)	Measurement reliability
– QV (Fourth Value)	Electronics temperature
Fulfilled HART specification	7.6
Further information on Manufacturer ID, Device ID, Device Revision	See website of FieldComm Group

**Deviation (according to DIN EN 60770-1)**

Process reference conditions according to DIN EN 61298-1

– Temperature	+18 ... +30 °C (+64 ... +86 °F)
– Relative humidity	45 ... 75 %
– Air pressure	860 ... 1060 mbar/86 ... 106 kPa (12.5 ... 15.4 psig)

Installation reference conditions <sup>21)</sup>

– Min. distance to internal installations	> 200 mm (7.874 in)
– Reflector	Flat plate reflector
– False reflections	Biggest false signal, 20 dB smaller than the useful signal

Deviation with liquids  $\leq 1$  mm (meas. distance > 0.25 m/0.8202 ft)

Non-repeatability <sup>22)</sup>  $\leq 1$  mm

Deviation with bulk solids The values depend to a great extent on the application. Binding specifications are thus not possible.

<sup>20)</sup> Default values can be assigned individually.

<sup>21)</sup> In case of deviations from reference conditions, the offset due to installation can be up to  $\pm 4$  mm. This offset can be compensated by the adjustment.

<sup>22)</sup> Already included in the meas. deviation






Fig. 65: Deviation under reference conditions (example thread with integrated antenna system, applies accordingly to all versions except flange with lens antenna)

- 1 Reference plane
- 2 Antenna edge
- 3 Recommended measuring range




Fig. 66: Deviation under reference conditions (flange with lens antenna)

- 1 Reference plane
- 2 Recommended min. distance, specifications see below
- 3 Measuring range end

Recommended min. distance for typical bulk solids applications <sup>23)</sup>

- Plastic horn antenna, flange with lens antenna 250 mm (9.843 in)
- Thread with integrated antenna system 500 mm (19.69 in)
- blocking distance 150 mm (5.906 in)

## Variables influencing measurement accuracy <sup>24)</sup>

### Specifications apply to the digital measured value

<sup>23)</sup> Depending of the reflective properties of the measured media.

<sup>24)</sup> Determination of the temperature drift acc. to the limit point method

- Temperature drift - Digital output < 3 mm/10 K, max. 10 mm
- Additional deviation through electro-magnetic interference None

**Specifications apply also to the current output**

- Temperature drift - Current output < 0.03 %/10 K or max. 0.3 % relating to the 16.7 mA span
- Deviation in the current output due to digital/analogue conversion < 15 µA
- Additional deviation through electromagnetic interference
- According to NAMUR NE 21 < 80 µA
  - According to EN 61326-3-1 < 80 µA
  - According to IACS E10 (shipbuilding) < 80 µA

**Characteristics and performance data**

- Measuring frequency W-band (80 GHz technology)
- Measuring cycle time <sup>25)</sup> approx. 200 ms
- Step response time <sup>26)</sup> ≤ 3 s
- Beam angle <sup>27)</sup>

Version	Size	Beam angle
Thread with integrated antenna system	G¾, ¾ NPT	14°
	G1, 1 NPT	10°
	G1½, 1½ NPT (+250 °C)	10°
	G1½, 1½ NPT (+150 °C)	7°
Plastic horn antenna	DN 80	3°
Flange with plastic plating, hygienic fittings	≥ DN 25	10°
	≥ DN 50, 2"	6°
	≥ DN 80, 3"	3°
Flange with lens antenna		3°

- Emitted HF power (depending on the parameter setting) <sup>28)</sup>
- Average spectral transmission power density -3 dBm/MHz EIRP
  - Max. spectral transmission power density +34 dBm/50 MHz EIRP
  - Max. power density at a distance of 1 m < 3 µW/cm<sup>2</sup>

<sup>25)</sup> With operating voltage  $U_b \geq 24$  V DC

<sup>26)</sup> Time span after a sudden distance change from 1 m to 5 m until the output signal reaches 90 % of the final value for the first time (IEC 61298-2). Valid with operating voltage  $U_b \geq 24$  V DC

<sup>27)</sup> Outside the specified beam angle, the energy level of the radar signal is 50% (-3 dB) less.

<sup>28)</sup> EIRP: Equivalent Isotropic Radiated Power

## Ambient conditions

Ambient, storage and transport temperature -40 ... +80 °C (-40 ... +176 °F)  
ture

## Process conditions - thermal

For the process conditions, please also note the specifications on the type label. The lowest value (amount) always applies.

### Process temperature

Version	Antenna material	Process seal	Process temperature (measured on the process fitting)
Plastic horn antenna	PP		-40 ... +80 °C (-40 ... +176 °F)
Thread with integrated antenna system	PEEK	FKM (SHS FPM 70C3 GLT)	-40 ... +150 °C (-40 ... +302 °F)
			-40 ... +200 °C (-40 ... +392 °F)
		FFKM (Kalrez 6230)	-15 ... +150 °C (5 ... +302 °F)
			-15 ... +250 °C (5 ... +482 °F)
		FFKM (Kalrez 6375)	-20 ... +150 °C (-4 ... +302 °F)
			-20 ... +200 °C (-4 ... +392 °F)
		FFKM (Perlast G74S, G75B)	-15 ... +150 °C (5 ... +302 °F)
			-15 ... +250 °C (5 ... +482 °F)
		EPDM (A+P 70.10-02)	-55 ... +150 °C (-67 ... +302 °F)
Flange with plastic plating	PTFE, PTFE (8 mm)	PTFE	-40 ... +150 °C (-40 ... +302 °F)
			-40 ... +200 °C (-40 ... +392 °F)
			-196 ... +200 °C (-320.8 ... +392 °F)
	PFA (8 mm)	PFA	-40 ... +150 °C (-40 ... +302 °F)
Hygienic fittings	PEEK	PTFE (with Clamp connection)	-40 ... +150 °C (-40 ... +302 °F)
			-40 ... +200 °C (-40 ... +392 °F)
		FKM (SHS FPM 70C3 GLT)	-20 ... +150 °C (-4 ... +302 °F)
		EPDM (A+P 70.10-02)	-40 ... +150 °C (-40 ... +302 °F)
		FFKM (Kalrez 6230)	-15 ... +150 °C (5 ... +302 °F)
Flange with lens antenna	PEEK	FKM (SHS FPM 70C3 GLT)	-40 ... +150 °C (-40 ... +302 °F)
			-40 ... +200 °C (-40 ... +392 °F)
		FFKM (Kalrez 6375)	-20 ... +150 °C (-4 ... +302 °F)
			-20 ... +200 °C (-4 ... +392 °F)
		FFKM (Perlast G75B)	-15 ... +150 °C (5 ... +302 °F)
			-15 ... +250 °C (5 ... +482 °F)
		EPDM (A+P 70.10-02)	-40 ... +150 °C (-40 ... +302 °F)

**SIP process temperature** (SIP = Sterilization in place)

Applies to steam-suitable device configuration, i.e. flange with plastic plating or hygienic fitting.

Vapour stratification up to 2 h +150 °C (+302 °F)


**Derating, ambient temperature - plastic horn antenna**

Fig. 67: Derating, ambient temperature, plastic horn antenna

1 Ambient temperature

2 Process temperature


**Derating, ambient temperature - thread with integrated antenna system**

Fig. 68: Derating, ambient temperature, thread with integrated antenna system up to +150 °C (+302 °F)

A Ambient temperature

B Process temperature

1 Aluminium housing

2 Stainless steel housing (precision casting)

3 Plastic housing

4 Stainless steel housing (electropolished)




Fig. 69: Derating, ambient temperature, thread with integrated antenna system up to +200 °C (+392 °F)

- A Ambient temperature  
 B Process temperature  
 1 Aluminium housing  
 2 Stainless steel housing (precision casting)  
 3 Plastic housing  
 4 Stainless steel housing (electropolished)




Fig. 70: Derating, ambient temperature, thread with integrated antenna system up to +250 °C (+482 °F)

- A Ambient temperature  
 B Process temperature  
 1 Aluminium housing  
 2 Stainless steel housing (precision casting)  
 3 Plastic housing  
 4 Stainless steel housing (electropolished)

# Derating ambient temperature - Flange with plastic plating, hygienic fitting




Fig. 71: Derating ambient temperature, flange with plastic plating, hygienic fitting up to +150 °C (+302 °F)

- A Ambient temperature
- B Process temperature
- 1 Aluminium housing
- 2 Stainless steel housing (precision casting)
- 3 Plastic housing
- 4 Stainless steel housing (electropolished)




Fig. 72: Derating ambient temperature, flange with plastic plating up to +200 °C (+392 °F)

- A Ambient temperature
- B Process temperature
- 1 Aluminium housing
- 2 Stainless steel housing (precision casting)
- 3 Plastic housing
- 4 Stainless steel housing (electropolished)




Fig. 73: Derating ambient temperature, flange with plastic plating -196 ... +200 °C (-320.8 ... +392 °F)

- A Ambient temperature  
 B Process temperature  
 1 Aluminium housing  
 2 Stainless steel housing (precision casting)  
 3 Plastic housing  
 4 Stainless steel housing (electropolished)

#### Derating ambient temperature - Flange with lens antenna




Fig. 74: Derating, ambient temperature, flange with lens antenna up to +150 °C (+302 °F)

- A Ambient temperature  
 B Process temperature  
 1 Aluminium housing  
 2 Stainless steel housing (precision casting)  
 3 Plastic housing  
 4 Stainless steel housing (electropolished)




Fig. 75: Derating, ambient temperature, flange with lens antenna up to +200 °C (+392 °F)

- A Ambient temperature
- B Process temperature
- 1 Aluminium housing
- 2 Stainless steel housing (precision casting)
- 3 Plastic housing
- 4 Stainless steel housing (electropolished)




Fig. 76: Derating, ambient temperature, flange with lens antenna up to +250 °C (+482 °F)

- A Ambient temperature
- B Process temperature
- 1 Aluminium housing
- 2 Stainless steel housing (precision casting)
- 3 Plastic housing
- 4 Stainless steel housing (electropolished)



## Process conditions - mechanical

For the process conditions, please also note the specifications on the type label. The lowest value (amount) always applies.

### Process pressure

Process fitting	Version	Process pressure
Plastic horn antenna	Compression flange	-1 ... 2 bar (-100 ... 200 kPa/-14.5 ... 29.1 psig)
	Adapter flange	-1 ... 1 bar (-100 ... 100 kPa/-14.5 ... 14.5 psig)
Thread with integrated antenna system		-1 ... 40 bar (-100 ... 4000 kPa/-14.5 ... 580.2 psig)
Flange with plastic plating	PN 6	-1 ... 6 bar (-100 ... 600 kPa/-14.5 ... 87 psig)
	PN 16 (300 lb)	-1 ... 16 bar (-100 ... 1600 kPa/-14.5 ... 232 psig)
	PN 40 (600 lb)	-1 ... 25 bar (-100 ... 2500 kPa/-14.5 ... 362.6 psig)
	PN 64 (900 lb)	
	PN 40 (600 lb) Version -196 ... +200 °C (-320.8 ... +392 °F)	
	PN 64 (900 lb) Version -196 ... +200 °C (-320.8 ... +392 °F)	
Hygienic fitting	SMS	-1 ... 6 bar (-100 ... 600 kPa/-14.5 ... 87 psig)
	Varivent	-1 ... 10 bar (-100 ... 1000 kPa/-14.5 ... 145 psig)
	Clamp 3", 3½", 4"	-1 ... 16 bar (-100 ... 1600 kPa/-14.5 ... 232 psig)
	Remaining hygienic fittings	
Flange with lens antenna		-1 ... 3 bar (-100 ... 300 kPa/-14.5 ... 43.5 psig)

Vessel pressure relating to the flange nominal pressure stage

see supplementary instructions manual "Flanges according to DIN-EN-ASME-JIS"

### Vibration resistance<sup>29)</sup>

Antenna version	Housing	Vibration resistance
Plastic horn antenna	Plastic housing	4M6 (5 g), with mounting strap: 4M5 (1 g)
	Aluminium housing	
	Stainless steel housing	4M5 (1 g)
Thread with integrated antenna system	Plastic housing	4M8 (5 g)
	Aluminium housing	
	Stainless steel housing	4M6 (2 g)
Flange with plastic plating	Plastic housing	4M8 (5 g)
	Aluminium housing	
	Stainless steel housing	4M6 (2 g)

<sup>29)</sup> Test sequence acc. to IEC 60068-2-6 (5 ... 200 Hz), classification acc. to IEC 60721-3-4

Antenna version	Housing	Vibration resistance
Hygienic fitting	Plastic housing	4M8 (5 g) <sup>30)</sup>
	Aluminium housing	
	Stainless steel housing	
Flange with lens antenna	Plastic housing	4M8 (5 g)
	Aluminium housing	
	Stainless steel housing	4M6 (2 g)

**Schock resistance<sup>31)</sup>**

Antenna version	Housing	Shock resistance
Plastic horn antenna	Plastic housing	6M4 (10 g/11 ms, 30 g/6 ms, 50 g/2.3 ms)
	Aluminium housing	
	Stainless steel housing	6M1 (5 g/11 ms, 10 g/11 ms)
Thread with integrated antenna system, flange with plastic plating, hygienic fitting, flange with lens antenna	Plastic housing	6M4 (10 g/11 ms, 30 g/6 ms, 50 g/2.3 ms) <sup>32)</sup>
	Aluminium housing	
	Stainless steel housing	

**Data on rinsing air connection**

Recommended max. pressure with continuous rinsing 1 bar (14.50 psig)

Max. permissible pressure 6 bar (87.02 psig)

Air quality Filtered

Air volume, depending on pressure

Plastic horn antenna	Air volume	
Pressure	Without reflux valve	With reflux valve
0.2 bar (2.9 psig)	3.3 m³/h	-
0.4 bar (5.8 psig)	5 m³/h	-
0.6 bar (8.7 psig)	6 m³/h	1 m³/h
0.8 bar (11.6 psig)	-	2.1 m³/h
1 bar (14.5 psig)	-	3 m³/h
1.2 bar (17.4 psig)	-	3.5 m³/h
1.4 bar (20.3 psig)	-	4.2 m³/h
1.6 bar (23.2 psig)	-	4.4 m³/h
1.8 bar (20.3 psig)	-	4.8 m³/h
2 bar (23.2 psig)	-	5.1 m³/h

<sup>30)</sup> For hygienic fittings with clamp connection, use suitable, stable tension clamps.

<sup>31)</sup> Tested acc. to IEC 60068-2-27, classification acc. to IEC 60721-3-6

<sup>32)</sup> For hygienic fittings with clamp connection, use suitable, stable tension clamps.

Flange with lens antenna	Air volume	
	Without reflux valve	With reflux valve
0.2 bar (2.9 psig)	1.7 m³/h	-
0.4 bar (5.8 psig)	2.5 m³/h	-
0.6 bar (8.7 psig)	2.9 m³/h	0.8 m³/h
0.8 bar (11.6 psig)	3.3 m³/h	1.5 m³/h
1 bar (14.5 psig)	3.6 m³/h	2 m³/h
1.2 bar (17.4 psig)	3.9 m³/h	2.3 m³/h
1.4 bar (20.3 psig)	4 m³/h	2.7 m³/h
1.6 bar (23.2 psig)	4.3 m³/h	3 m³/h
1.8 bar (20.3 psig)	4.5 m³/h	3.5 m³/h
2 bar (23.2 psig)	4.6 m³/h	4 m³/h

#### Connection

- Thread G $\frac{1}{8}$
- Seal at flange with lens antenna Threaded plug of 316Ti

#### Reflux valve (optional, is absolutely necessary for Ex applications)

- Material 316Ti
- Thread G $\frac{1}{8}$
- Seal FKM (SHS FPM 70C3 GLT), EPDM (COG AP310)
- For connection G $\frac{1}{8}$
- Opening pressure 0.5 bar (7.25 psig)
- Nominal pressure stage PN 250

#### Electromechanical data - version IP66/IP67 and IP66/IP68 (0.2 bar)

##### Options of the cable entry

- Cable entry M20 x 1.5;  $\frac{1}{2}$  NPT
- Cable gland M20 x 1.5;  $\frac{1}{2}$  NPT (cable  $\varnothing$  see below table)
- Blind plug M20 x 1.5;  $\frac{1}{2}$  NPT
- Closing cap  $\frac{1}{2}$  NPT

Material cable gland	Material seal insert	Cable diameter				
		4.5 ... 8.5 mm	5 ... 9 mm	6 ... 12 mm	7 ... 12 mm	10 ... 14 mm
PA	NBR	-	●	●	-	●
Brass, nickel-plated	NBR	●	●	●	-	-
Stainless steel	NBR	-	●	●	-	●

#### Wire cross-section (spring-loaded terminals)

- Massive wire, stranded wire 0.2 ... 2.5 mm² (AWG 24 ... 14)
- Stranded wire with end sleeve 0.2 ... 1.5 mm² (AWG 24 ... 16)

**Electromechanical data - version IP66/IP68 (1 bar)****Options of the cable entry**

- Cable gland with integrated connection cable M20 x 1.5 (cable ø 5 ... 9 mm)
- Cable entry ½ NPT
- Blind plug M20 x 1.5; ½ NPT

**Connection cable**

- Wire cross-section 0.5 mm<sup>2</sup> (AWG 20)
- Wire resistance < 0.036 Ω/m
- Tensile strength < 1200 N (270 lbf)
- Standard length 5 m (16.4 ft)
- Max. length 180 m (590.6 ft)
- Min. bending radius (at 25 °C/77 °F) 25 mm (0.984 in)
- Diameter approx. 8 mm (0.315 in)
- Colour - Non-Ex version Black
- Colour - Ex-version Blue

**Interface to the external display and adjustment unit**Data transmission Digital (I<sup>2</sup>C-Bus)

Connection cable Four-wire

Sensor version	Configuration, connection cable	
	Max. cable length	Shielded
4 ... 20 mA/HART	50 m	●

**Integrated clock**

Date format Day.Month.Year

Time format 12 h/24 h

Time zone, factory setting CET

Max. rate deviation 10.5 min/year

**Additional output parameter - Electronics temperature**

Range -40 ... +85 °C (-40 ... +185 °F)

Resolution &lt; 0.1 K

Deviation ± 3 K

**Availability of the temperature values**

- Indication Via the display and adjustment module
- Output Via the respective output signal

**Voltage supply, sensor**Operating voltage U<sub>B</sub> 12 ... 35 V DCOperating voltage U<sub>B</sub> with lighting switched on 18 ... 35 V DC

Reverse voltage protection	Integrated
Permissible residual ripple	
– for $12\text{ V} < U_B < 18\text{ V}$	$\leq 0.7 V_{\text{eff}}$ (16 ... 400 Hz)
– for $18\text{ V} < U_B < 35\text{ V}$	$\leq 1 V_{\text{eff}}$ (16 ... 400 Hz)
Load resistor	
– Calculation	$(U_B - U_{\text{min}})/0.022\text{ A}$
– Example - $U_B = 24\text{ V DC}$	$(24\text{ V} - 12\text{ V})/0.022\text{ A} = 545\ \Omega$

### Potential connections and electrical separating measures in the instrument

Electronics	Not non-floating
Reference voltage <sup>33)</sup>	$500 V_{\text{eff}}$
Conductive connection	Between ground terminal and metallic process fitting

### Electrical protective measures

Housing material	Version	Protection acc. to IEC 60529	Protection acc. to NEMA
Plastic	Single chamber	IP66/IP67	Type 4X
	Double chamber	IP66/IP67	Type 4X
Aluminium	Single chamber	IP66/IP68 (0.2 bar) IP68 (1 bar)	Type 6P -
	Double chamber	IP66/IP68 (0.2 bar) IP68 (1 bar)	Type 6P -
Stainless steel (electro-polished)	Single chamber	IP66/IP68 (0.2 bar)	Type 6P
		IP69K	Type 6P
Stainless steel (precision casting)	Single chamber	IP66/IP68 (0.2 bar) IP68 (1 bar)	Type 6P -
	Double chamber	IP66/IP68 (0.2 bar) IP68 (1 bar)	Type 6P -

Connection of the feeding power supply unit      Networks of overvoltage category III

Altitude above sea level

- by default      up to 2000 m (6562 ft)
- with connected overvoltage protection      up to 5000 m (16404 ft)

Pollution degree (with fulfilled housing protection)      4

Protection rating (IEC 61010-1)      III

## 16.2 Radio astronomy stations

Certain restrictions on the use of VEGAPULS 6X outside closed vessels result from the radio license. You can find these restrictions in chapter "Radio license for Europe". Some of these restrictions have to do radio astronomy stations. The following table states the geographic positions of

<sup>33)</sup> Galvanic separation between electronics and metal housing parts

radio astronomy stations in Europe:

Country	Name of the Station	Geographic Latitude	Geographic Longitude
Finland	Metsähovi	60°13'04" N	24°23'37" E
France	Plateau de Bure	44°38'01" N	05°54'26" E
Germany	Effelsberg	50°31'32" N	06°53'00" E
Italy	Sardinia	39°29'50" N	09°14'40" E
Spain	Yebes	40°31'27" N	03°05'22" W
	Pico Veleta	37°03'58" N	03°23'34" W
Sweden	Onsala	57°23'45" N	11°55'35" E

16.3 Dimensions

The listed drawings represent only an excerpt of the available process fittings. You can find more drawings at [www.vega.com](http://www.vega.com) via the configurator of VEGAPULS 6X.

Plastic housing




Fig. 77: Housing versions in protection IP66/IP67 (with integrated display and adjustment module the housing is 9 mm/0.35 in higher)

- 1 Plastic single chamber
- 2 Plastic double chamber

## Aluminium housing




Fig. 78: Housing versions with protection rating IP66/IP68 (0.2 bar), (with integrated display and adjustment module the housing is 18 mm/0.71 in higher)

- 1 Aluminium - single chamber
- 2 Aluminium - double chamber

## Aluminium housing with protection rating IP66/IP68, 1 bar




Fig. 79: Housing version with protection rating IP66/IP68 (1 bar), (with integrated display and adjustment module the housing is 18 mm/0.71 in higher)

- 1 Aluminium - single chamber

## Stainless steel housing




Fig. 80: Housing versions with protection rating IP66/IP68 (0.2 bar), (with integrated display and adjustment module the housing is 18 mm/0.71 in higher)

- 1 Stainless steel single chamber (electropolished)
- 2 Stainless steel single chamber (precision casting)
- 3 Stainless steel double chamber housing (precision casting)

## Stainless steel housing with protection rating IP66/IP68, 1 bar




Fig. 81: Housing version with protection rating IP66/IP68 (1 bar), (with integrated display and adjustment module the housing is 18 mm/0.71 in higher)

- 1 Stainless steel single chamber (electropolished)
- 2 Stainless steel single chamber (precision casting)
- 3 Stainless steel double chamber housing (precision casting)



# VEGAPULS 6X, plastic horn antenna with compression flange




Fig. 82: Radar sensor with compression flange suitable for 3" 150 lbs, DN 80 PN 16

1 Compression flange

# VEGAPULS 6X, plastic horn antenna with compression flange and purging air connection




Fig. 83: Radar sensor with compression flange and purging air connection suitable for 3" 150 lbs, DN 80 PN 16

1 Compression flange  
2 Reflux valve  
3 Rinsing air connection


**VEGAPULS 6X, plastic horn antenna with adapter flange**

Fig. 84: Radar sensor with adapter flange DN 100 PN 6

- 1 Adapter flange
- 2 Process seal


**VEGAPULS 6X, plastic horn antenna mit adapter flange und purging air connection**

Fig. 85: VEGAPULS 6X, adapter flange and purging air connection DN 100 PN 6

- 1 Rinsing air connection
- 2 Reflux valve
- 3 Adapter flange

VEGAPULS 6X, plastic horn antenna with mounting strap





Fig. 86: VEGAPULS 6X, plastic horn antenna, mounting strap in 170 or 300 mm length

**VEGAPULS 6X, thread with integrated antenna system up to +150 °C (+302 °F)****Fig. 87: VEGAPULS 6X, thread with integrated antenna system up to +150 °C (+302 °F)****XF** G $\frac{3}{4}$  (DIN 3852-E)**XJ**  $\frac{3}{4}$  NPT (ASME B1.20.1)**XG** G 1 (DIN 3852-A)**XK** 1 NPT (ASME B1.20.1)**XA** G $1\frac{1}{2}$  (DIN 3852-A)**XB**  $1\frac{1}{2}$  NPT (ASME B1.20.1)

**VEGAPULS 6X, thread with integrated antenna system up to +250 °C (+482 °F)**




Fig. 88: VEGAPULS 6X, thread with integrated antenna system up to +250 °C (+482 °F)

- XF G 3/4 (DIN 3852-E)
- XJ 3/4 NPT (ASME B1.20.1)
- XG G 1 (DIN 3852-A)
- XK 1 NPT (ASME B1.20.1)
- XA G 1 1/2 (DIN 3852-A)
- XB 1 1/2 NPT (ASME B1.20.1)

**VEGAPULS 6X, flange with plastic plating**




Fig. 89: VEGAPULS 6X, encapsulated antenna system DN 25 PN 40

- 1 Version up to +150 °C (+302 °F)
- 2 Version up to +200 °C (+392 °F)




Fig. 90: VEGAPULS 6X, encapsulated antenna system DN 50 PN 40

- 1 Version up to +150 °C (+302 °F)
- 2 Version up to +200 °C (+392 °F)




Fig. 91: VEGAPULS 6X, encapsulated antenna system DN 80 PN 40

1 Version up to +150 °C (+302 °F)

2 Version up to +200 °C (+392 °F)

## VEGAPULS 6X, hygienic fitting




Fig. 92: VEGAPULS 6X, hygienic fitting

CA Clamp 2" PN 16 (DIN 32676, ISO 2852)

RA Slotted nut DN 50 PN 16 (DIN 11851)

LA Hygienic connection with compression nut F 40 PN 16

LB Hygienic fitting with tension flange DN 32 PN 16

DC Slotted nut DN 50 PN 16 (DIN 11854-1)

VA For Variline Form F DN 25 (1")



# VEGAPULS 6X, flange with lens antenna




Fig. 93: VEGAPULS 6X, flange with lens antenna (flange thickness acc. to drawing, flange dimensions acc. to DIN, ASME, JIS)

1 Version up to +150 °C (+302 °F)

2 Version up to +250 °C (+482 °F)

# VEGAPULS 6X, flange with lens antenna and purging air connection




Fig. 94: VEGAPULS 6X, flange with lens antenna and purging air connection

1 Version up to +150 °C (+302 °F)

2 Version up to +250 °C (+482 °F)

3 Blind plug

4 90° angle joint

5 Reflux valve


**VEGAPULS 6X, flange with lens antenna and swivelling holder**

Fig. 95: VEGAPULS 6X, flange with lens antenna and swivelling holder

- 1 Version up to +150 °C (+302 °F)
- 2 Version up to +250 °C (+482 °F)


**VEGAPULS 6X, flange with lens antenna, swivelling holder and purging air connection**

Fig. 96: VEGAPULS 6X, flange with lens antenna, swivelling holder and purging air connection

- 1 Version up to +150 °C (+302 °F)
- 2 Version up to +250 °C (+482 °F)
- 3 Blind plug
- 4 90° angle joint
- 5 Reflux valve

## 16.4 Industrial property rights

VEGA product lines are global protected by industrial property rights. Further information see [www.vega.com](http://www.vega.com).

VEGA Produktfamilien sind weltweit geschützt durch gewerbliche Schutzrechte.

Nähere Informationen unter [www.vega.com](http://www.vega.com).

Les lignes de produits VEGA sont globalement protégées par des droits de propriété intellectuelle. Pour plus d'informations, on pourra se référer au site [www.vega.com](http://www.vega.com).

VEGA lineas de productos están protegidas por los derechos en el campo de la propiedad industrial. Para mayor información revise la pagina web [www.vega.com](http://www.vega.com).

Линии продукции фирмы ВЕГА защищаются по всему миру правами на интеллектуальную собственность. Дальнейшую информацию смотрите на сайте [www.vega.com](http://www.vega.com).

VEGA系列产品在全球享有知识产权保护。

进一步信息请参见网站 < [www.vega.com](http://www.vega.com)。

## 16.5 Licensing information for open source software

Open source software components are also used in this device. A documentation of these components with the respective license type, the associated license texts, copyright notes and disclaimers can be found on our homepage.

## 16.6 Trademark

All the brands as well as trade and company names used are property of their lawful proprietor/originator.

Printing date:

# VEGA

All statements concerning scope of delivery, application, practical use and operating conditions of the sensors and processing systems correspond to the information available at the time of printing.

Subject to change without prior notice

© VEGA Grieshaber KG, Schiltach/Germany 2022



66190-EN-220117

VEGA Grieshaber KG  
Am Hohenstein 113  
77761 Schiltach  
Germany

Phone +49 7836 50-0  
E-mail: [info.de@vega.com](mailto:info.de@vega.com)  
[www.vega.com](http://www.vega.com)