

Operating Instructions

External display and adjustment unit

VEGADIS 82

4 ... 20 mA



Document ID: 46591



VEGA

Contents

1	About this document	4
1.1	Function	4
1.2	Target group	4
1.3	Symbols used.....	4
2	For your safety	5
2.1	Authorised personnel	5
2.2	Appropriate use.....	5
2.3	Warning about incorrect use.....	5
2.4	General safety instructions	5
2.5	EU conformity.....	6
2.6	NAMUR recommendations	6
2.7	Installation and operation in the USA and Canada	6
2.8	Environmental instructions	6
3	Product description	7
3.1	Configuration.....	7
3.2	Principle of operation.....	8
3.3	Packaging, transport and storage.....	9
3.4	Accessories and replacement parts	10
4	Mounting	11
4.1	General instructions	11
4.2	Mounting instructions	11
5	Connecting to power supply	14
5.1	Preparing the connection	14
5.2	Connection technology and steps	15
5.3	Wiring plan	17
5.4	Connection signal conditioning instrument.....	17
5.5	Connection example	19
5.6	Switch-on phase.....	19
6	Set up with the display and adjustment module	20
6.1	Insert display and adjustment module	20
6.2	Adjustment system	21
6.3	Measured value indication - Selection of national language	21
6.4	Parameter adjustment - VEGADIS 82.....	22
7	Setup via PACTware	27
7.1	Connect the PC.....	27
7.2	Parameter adjustment	27
7.3	Saving the parameterisation data.....	28
8	Diagnostics and servicing	29
8.1	Maintenance	29
8.2	Asset Management function.....	29
8.3	Rectify faults.....	30
8.4	Exchanging the electronics module.....	30
8.5	Software update	30
8.6	How to proceed if a repair is necessary.....	31
9	Dismount	32

9.1	Dismounting steps.....	32
9.2	Disposal	32
10	Supplement	33
10.1	Technical data	33
10.2	Dimensions	36
10.3	Industrial property rights.....	39
10.4	Trademark	39



Safety instructions for Ex areas

Take note of the Ex specific safety instructions for Ex applications. These instructions are attached as documents to each instrument with Ex approval and are part of the operating instructions manual.

Editing status: 2018-07-12

1 About this document

1.1 Function

This operating instructions manual provides all the information you need for mounting, connection and setup as well as important instructions for maintenance, fault rectification, the exchange of parts and the safety of the user. Please read this information before putting the instrument into operation and keep this manual accessible in the immediate vicinity of the device.

1.2 Target group

This operating instructions manual is directed to trained personnel. The contents of this manual must be made available to the qualified personnel and implemented.

1.3 Symbols used



Document ID

This symbol on the front page of this instruction refers to the Document ID. By entering the Document ID on www.vega.com you will reach the document download.



Information, tip, note

This symbol indicates helpful additional information.



Caution: If this warning is ignored, faults or malfunctions can result.
Warning: If this warning is ignored, injury to persons and/or serious damage to the instrument can result.



Danger: If this warning is ignored, serious injury to persons and/or destruction of the instrument can result.



Ex applications

This symbol indicates special instructions for Ex applications.



List

The dot set in front indicates a list with no implied sequence.



Action

This arrow indicates a single action.



Sequence of actions

Numbers set in front indicate successive steps in a procedure.



Battery disposal

This symbol indicates special information about the disposal of batteries and accumulators.

2 For your safety

2.1 Authorised personnel

All operations described in this documentation must be carried out only by trained specialist personnel authorised by the plant operator. During work on and with the device, the required personal protective equipment must always be worn.

2.2 Appropriate use

The VEGADIS 82 is suitable for measured value indication in 4 ... 20 mA signal current circuits.

You can find detailed information about the area of application in chapter "*Product description*".

Operational reliability is ensured only if the instrument is properly used according to the specifications in the operating instructions manual as well as possible supplementary instructions.

For safety and warranty reasons, any invasive work on the device beyond that described in the operating instructions manual may be carried out only by personnel authorised by the manufacturer. Arbitrary conversions or modifications are explicitly forbidden.

2.3 Warning about incorrect use

Inappropriate or incorrect use of this product can give rise to application-specific hazards, e.g. vessel overflow through incorrect mounting or adjustment. Damage to property and persons or environmental contamination can result. Also, the protective characteristics of the instrument can be impaired.

2.4 General safety instructions

This is a state-of-the-art instrument complying with all prevailing regulations and directives. The instrument must only be operated in a technically flawless and reliable condition. The operator is responsible for the trouble-free operation of the instrument. When measuring aggressive or corrosive media that can cause a dangerous situation if the instrument malfunctions, the operator has to implement suitable measures to make sure the instrument is functioning properly.

During the entire duration of use, the user is obliged to determine the compliance of the necessary occupational safety measures with the current valid rules and regulations and also take note of new regulations.

The safety instructions in this operating instructions manual, the national installation standards as well as the valid safety regulations and accident prevention rules must be observed by the user.

For safety and warranty reasons, any invasive work on the device beyond that described in the operating instructions manual may be carried out only by personnel authorised by the manufacturer. Arbitrary conversions or modifications are explicitly forbidden. For safety

reasons, only the accessory specified by the manufacturer must be used.

To avoid any danger, the safety approval markings and safety tips on the device must also be observed and their meaning read in this operating instructions manual.

2.5 EU conformity

The device fulfils the legal requirements of the applicable EU directives. By affixing the CE marking, we confirm the conformity of the instrument with these directives.

You can find the EU conformity declaration on our website under www.vega.com/downloads.

2.6 NAMUR recommendations

NAMUR is the automation technology user association in the process industry in Germany. The published NAMUR recommendations are accepted as the standard in field instrumentation.

The device fulfils the requirements of the following NAMUR recommendations:

- NE 21 – Electromagnetic compatibility of equipment
- NE 53 – Compatibility of field devices and display/adjustment components

For further information see www.namur.de.

2.7 Installation and operation in the USA and Canada

This information is only valid for USA and Canada. Hence the following text is only available in the English language.

Installations in the US shall comply with the relevant requirements of the National Electrical Code (ANSI/NFPA 70).

Installations in Canada shall comply with the relevant requirements of the Canadian Electrical Code.

2.8 Environmental instructions

Protection of the environment is one of our most important duties. That is why we have introduced an environment management system with the goal of continuously improving company environmental protection. The environment management system is certified according to DIN EN ISO 14001.

Please help us fulfil this obligation by observing the environmental instructions in this manual:

- Chapter "*Packaging, transport and storage*"
- Chapter "*Disposal*"

3 Product description

3.1 Configuration

Type label

The type label contains the most important data for identification and use of the instrument:




Fig. 1: Layout of the type label (example)

- 1 Instrument type
- 2 Product code
- 3 Field for approvals
- 4 Electronics/Voltage supply
- 5 Protection rating
- 6 Hardware/software version
- 7 Order number
- 8 Serial number of the instrument
- 9 Reminder to observe the instrument documentation
- 10 Device protection class
- 11 ID numbers, instrument documentation

Serial number - Instrument search

The type label contains the serial number of the instrument. With it you can find the following instrument data on our homepage:

- Article number (HTML)
- Delivery date (HTML)
- Order-specific instrument features (HTML)
- Operating instructions at the time of shipment (PDF)

Go to "www.vega.com", "*Instrument search (serial number)*". Enter the serial number.

As an alternative, you can access these data via your smartphone:

- Download the VEGA Tools app from the "Apple App Store" or the "Google Play Store"
- Scan the Data Matrix code on the type label of the instrument or
- Enter the serial number manually in the app

Instrument versions

The VEGADIS 82 is available in different housing materials, see chapter "*Technical data*".

The instrument is optionally available with or without display and adjustment module.

Scope of this operating instructions manual

This operating instructions manual applies to the following instrument versions:

- Software from 1.10.00
- Hardware from 1.00.00

Scope of delivery

The scope of delivery encompasses:

- VEGADIS 82
- Display and adjustment module (optional)
- Mounting accessories (optional)
- Documentation
 - This operating instructions manual
 - Ex-specific "*Safety instructions*" (with Ex versions)
 - If necessary, further certificates

**Information:**

In this operating instructions manual, the optional instrument features are also described. The actual range of functions is determined by the order specification.

3.2 Principle of operation**Application area**

The VEGADIS 82 is suitable as measured value indication with 4 ... 20 mA current loops. The instrument can be connected at any point to the 4 ... 20 mA signal cable. Separate, external energy is not required.

The VEGADIS 82 is also suitable for use in a 4 ... 20 mA/HART current loop. The HART signal is not influenced, however a sensors parameter adjustment is not possible.

The measured value indication is carried out in the VEGADIS 82 integrated in the display and adjustment module.

**Note:**

The operation of a display and adjustment module with integrated Bluetooth function is not supported by VEGADIS 82.

Sensors

The VEGADIS 82 is suitable for connection to any 4 ... 20 mA sensor.

The instrument is particularly designed for:

- VEGAPULS WL 61
- VEGAWELL 52

The housing of VEGADIS 82 contains a filter element for ventilation. The instrument is thus also used for atmospheric pressure compensation for a submersible pressure transmitter.

The VEGADIS 82 can also be used as an external indicating device for any four-wire sensor or a VEGAMET signal conditioning instrument with active 4 ... 20 mA output.

Connection




Fig. 2: Connection of VEGADIS 82 to the sensor

- 1 Voltage supply/Signal output sensor
- 2 VEGADIS 82
- 3 Display and adjustment module
- 4 4 ... 20 mA signal cable
- 5 Sensor

3.3 Packaging, transport and storage

Packaging

Your instrument was protected by packaging during transport. Its capacity to handle normal loads during transport is assured by a test based on ISO 4180.

The packaging of standard instruments consists of environment-friendly, recyclable cardboard. For special versions, PE foam or PE foil is also used. Dispose of the packaging material via specialised recycling companies.

Transport

Transport must be carried out in due consideration of the notes on the transport packaging. Nonobservance of these instructions can cause damage to the device.

Transport inspection

The delivery must be checked for completeness and possible transit damage immediately at receipt. Ascertained transit damage or concealed defects must be appropriately dealt with.

Storage

Up to the time of installation, the packages must be left closed and stored according to the orientation and storage markings on the outside.

Unless otherwise indicated, the packages must be stored only under the following conditions:

- Not in the open
- Dry and dust free
- Not exposed to corrosive media
- Protected against solar radiation
- Avoiding mechanical shock and vibration

Storage and transport temperature

- Storage and transport temperature see chapter "Supplement - Technical data - Ambient conditions"
- Relative humidity 20 ... 85 %

Lifting and carrying

With instrument weights of more than 18 kg (39.68 lbs) suitable and approved equipment must be used for lifting and carrying.

3.4 Accessories and replacement parts

PLICSCOM

The display and adjustment module PLICSCOM is used for measured value indication, adjustment and diagnosis. It can be inserted into the sensor or the external display and adjustment unit and removed at any time.

You can find further information in the operating instructions "*Display and adjustment module PLICSCOM*" (Document-ID 36433).

VEGACONNECT

The interface adapter VEGACONNECT enables the connection of communication-capable instruments to the USB interface of a PC. For parameter adjustment of these instruments, the adjustment software PACTware with VEGA-DTM is required.

You can find further information in the operating instructions "*Interface adapter VEGACONNECT*" (Document-ID 32628).

Electronics module

The electronics module is a replacement part for the display and adjustment instrument VEGADIS 82. A separate version is available for each type of signal output.

You can find further information in the operating instructions "*Electronics module VEGADIS 82*" (Document-ID 46804).

4 Mounting

4.1 General instructions

Installation position

VEGADIS 82 functions in any installation position.

Protection against moisture

Protect your instrument against moisture ingress through the following measures:

- Use a suitable connection cable (see chapter "Connecting to power supply")
- Tighten the cable gland or plug connector
- When mounting horizontally, turn the housing so that the cable gland or plug connector point downward
- Lead the connection cable downward in front of the cable entry or plug connector.

This applies mainly to outdoor installations, in areas where high humidity is expected (e.g. through cleaning processes) and on cooled or heated vessels.

To maintain the housing protection, make sure that the housing lid is closed during operation and locked, if necessary.

Make sure that the degree of contamination specified in chapter "Technical data" meets the existing ambient conditions.

4.2 Mounting instructions

Wall mounting

The VEGADIS 82 in all available housing materials is suitable for wall mounting.




Fig. 3: Drilling dimensions for VEGADIS 82 for wall mounting

Carrier rail mounting

The VEGADIS 82 with plastic housing is suitable for direct carrier rail mounting according to EN 50022.




Fig. 4: VEGADIS 82 with plastic housing for carrier rail mounting

- 1 Base
- 2 Carrier rail

The versions with aluminium or stainless steel housing for carrier rail mounting according to EN 50022 are supplied with unassembled mounting accessories. The kit consists of an adapter plate and four mounting screws M6 x 12.

The adapter plate is screwed to the base of VEGADIS 82 by the user.




Fig. 5: VEGADIS 82 with aluminium and stainless steel housing for carrier rail mounting

- 1 Base
- 2 Adapter plate with screws M6 x 12
- 3 Carrier rail

Tube mounting

The VEGADIS 82 for tube mounting is supplied with unassembled mounting accessories. The kit consists of two pairs of mounting brackets and four mounting screws M6 x 100.

The mounting brackets are screwed to the base of VEGADIS 82 by the user.




Fig. 6: VEGADIS 82 for tube mounting

- 1 4 screws M6 x 100
- 2 Mounting brackets
- 3 Tube (diameter 1" to 2")

Front panel mounting

The VEGADIS 82 is also available with a plastic housing for panel mounting. The housing is fastened to the rear of the panel by means of the supplied screw clamps.




Fig. 7: VEGADIS 82 for panel mounting

- 1 Inspection window
- 2 Front panel
- 3 Screw clamp
- 4 Housing
- 5 Plug connector

5 Connecting to power supply

5.1 Preparing the connection

Safety instructions

Always keep in mind the following safety instructions:

- Carry out electrical connection by trained personnel authorised by the plant operator
- If overvoltage surges are expected, overvoltage arresters should be installed



Warning:

Connect only in the complete absence of line voltage.

Voltage supply

Power supply and current signal are carried on the same two-wire cable. The voltage supply range can differ depending on the sensor. The data for power supply are specified in chapter "*Technical data*".

Make sure that the supply circuits are separated from the mains circuits and of an energy-limited voltage supply, e.g. of "*Class 2*" (acc. to UL 1310, NEC 725 or CAN/CSA C22.2 No. 223), according to internationally harmonized standard IEC 61010-1.

Keep in mind the following additional factors that influence the operating voltage:

- Output voltage of the power supply unit can be lower under nominal load (with a sensor current of 20.5 mA resp. 22 mA in case of fault message)
- Voltage loss on the VEGADIS 82 (see supply circuit in chapter "*Technical data*")

You can find information on the load resistance in chapter "*Technical data*", (voltage supply of the respective sensor)

Connection cable

The instrument is connected with standard two-wire cable without screen. If electromagnetic interference is expected which is above the test values of EN 61326-1 for industrial areas, screened cable should be used.

Use cable with round cross-section. To ensure the seal effect of the cable gland (IP protection rating), find out which cable outer diameter the cable gland is suitable for. Use a cable gland fitting the cable diameter.

You can find an overview of the cable glands in chapter "*Technical data*".

Cable glands

Metric threads

In the case of instrument housings with metric thread, the cable glands are screwed in at the factory. They are sealed with plastic plugs as transport protection.

You have to remove these plugs before electrical connection.

NPT thread

In the case of instrument housings with self-sealing NPT threads, it is not possible to have the cable entries screwed in at the factory. The

free openings for the cable glands are therefore covered with red dust protection caps as transport protection.

Prior to setup you have to replace these protective caps with approved cable glands or close the openings with suitable blind plugs.

On plastic housings, the NPT cable gland or the Conduit steel tube must be screwed into the threaded insert without grease.

Max. torque for all housings, see chapter "*Technical data*".

Cable screening and grounding

If screened cable is necessary, we recommend connecting the cable screen on both ends to ground potential. In the VEGADIS 82, the screen should be connected directly to the internal ground terminal.



In Ex systems it must be ensured that the grounding complies with the installation regulations.

In electroplating plants as well as plants for cathodic corrosion protection it must be taken into account that significant potential differences exist. This can lead to unacceptably high currents in the cable screen if it is grounded at both ends.

5.2 Connection technology and steps

Connection technology

The voltage supply and signal output are connected via the spring-loaded terminals in the housing.

Connection to the display and adjustment module or to the interface adapter is carried out via contact pins in the housing.



Information:

The terminal block is pluggable and can be removed from the electronics. To do this, lift the terminal block with a small screwdriver and pull it out. When reinserting the terminal block, you should hear it snap in.

Connection procedure

Proceed as follows:

1. Unscrew the housing lid
2. If a display and adjustment module is installed, remove it by turning it slightly to the left
3. Loosen compression nut of the cable gland and remove blind plug
4. Remove approx. 10 cm (4 in) of the cable mantle, strip approx. 1 cm (0.4 in) of insulation from the ends of the individual wires
5. Insert the cable into the sensor through the cable entry



Fig. 8: Connection steps 5 and 6

6. Insert the wire ends into the terminals according to the wiring plan



Information:

Solid cores as well as flexible cores with wire end sleeves are inserted directly into the terminal openings. In case of flexible cores without end sleeves, press the terminal from above with a small screwdriver, the terminal opening is then free. When the screwdriver is released, the terminal closes again.

You can find further information on the max. wire cross-section under "*Technical data - Electromechanical data*".

7. Check the hold of the wires in the terminals by lightly pulling on them
8. Connect the screen to the internal ground terminal, connect the external ground terminal to potential equalisation
9. Tighten the compression nut of the cable entry gland. The seal ring must completely encircle the cable
10. Reinsert the display and adjustment module, if one was installed
11. Screw the housing lid back on

5.3 Wiring plan

Wiring plan




Fig. 9: Wiring plan VEGADIS 82 for 4 ... 20 mA sensors

- 1 To the sensor
- 2 Terminal for connection of the cable screen
- 3 For power supply

Wiring plan - Panel mounting




Fig. 10: Wiring plan VEGADIS 82 for 4 ... 20 mA sensors - panel mounting

- 1 To the sensor
- 2 Ground terminal in the switching cabinet for connection of the cable screen
- 3 For power supply

5.4 Connection signal conditioning instrument

The following illustrations show the simplified connection of VEGADIS 82 to a signal conditioning instrument VEGAMET or a four-wire sensor with active 4 ... 20 mA output.




Fig. 11: Connection of the VEGADIS 82 as external indication to signal conditioning instrument or four-wire sensor

- 1 Sensor
- 2 Signal conditioning instrument
- 3 VEGADIS 82

For this, terminals 1 and 2 on VEGADIS 82 must be bridged.




Fig. 12: Bridge on terminals 1 and 2 on the VEGADIS 82

- 1 Bridge
- 2 VEGADIS 82
- 3 Signal conditioning instrument

5.5 Connection example




Fig. 13: Connection example 4 ... 20 mA

- 1 Voltage supply
- 2 VEGADIS 82
- 3 Connection cable
- 4 Sensor

5.6 Switch-on phase

After connecting the instrument to power supply or after a voltage recurrence, the instrument carries out a self-check for approx. 10 s:

- Internal check of the electronics
- Indication of the instrument type, hardware and software version, measurement loop name on the display or PC
- Indication of a status message on the display or PC

The duration of the warm-up phase depends on the connected sensor.

Then the actual measured value is displayed. You can find further information on the display in chapter "Measured value indication - Selection national language".

6 Set up with the display and adjustment module

Mount/dismount display and adjustment module

6.1 Insert display and adjustment module

The display and adjustment module can be inserted into the VEGADIS 82 and removed again at any time. It is not necessary to interrupt the power supply.



Note:

The operation of a display and adjustment module with integrated Bluetooth function is not supported by VEGADIS 82.

Proceed as follows for mounting the display and adjustment module:

1. Unscrew the housing lid
2. Place the display and adjustment module in the desired position on the electronics (you can choose any one of four different positions - each displaced by 90°)
3. Press the display and adjustment module onto the electronics and turn it to the right until it snaps in
4. Screw housing lid with inspection window tightly back on

Disassembly is carried out in reverse order.



Fig. 14: Mounting of the display and adjustment module

6.2 Adjustment system




Fig. 15: Display and adjustment elements

- 1 LC display
- 2 Adjustment keys

Key functions

- **[OK]** key:
 - Move to the menu overview
 - Confirm selected menu
 - Edit parameter
 - Save value
- **[->]** key:
 - Change measured value presentation
 - Select list entry
 - Select menu items in the quick setup menu
 - Select editing position
- **[+]** key:
 - Change value of the parameter
- **[ESC]** key:
 - Interrupt input
 - Jump to next higher menu

Adjustment system

The instrument is operated via the four keys of the display and adjustment module. The individual menu items are shown on the LC display. You can find the function of the individual keys in the previous illustration.

Time functions

When the **[+]** and **[->]** keys are pressed quickly, the edited value, or the cursor, changes one value or position at a time. If the key is pressed longer than 1 s, the value or position changes continuously.

When the **[OK]** and **[ESC]** keys are pressed simultaneously for more than 5 s, the display returns to the main menu. The menu language is then switched over to "English".

Approx. 60 minutes after the last pressing of a key, an automatic reset to measured value indication is triggered. Any values not confirmed with **[OK]** will not be saved.


6.3 Measured value indication - Selection of national language

With the **[->]** key you can move between two different views:

Measured value indication

First view: Display value 1 in big lettering, TAG number

Second view: Display value 1, a bargraph corresponding to the 4 ... 20 mA value, TAG number



During the initial setup of an instrument shipped with factory settings, use the "OK" key to get to the menu "National language".

Selection of national language

This menu item is used to select the national language for further parameter adjustment. You can change the selection via the menu item "Setup - Display, Menu language".




With the "OK" key you move to the main menu.

6.4 Parameter adjustment - VEGADIS 82

Main menu

The main menu is divided into four areas with the following functions:



Setup: Settings, e.g. to measurement loop name, damping, scaling

Diagnostics: Information on the device status

Additional adjustments: Reset, copy display settings

Info: Instrument name, instrument version, date of manufacture, instrument features

For optimum adjustment of the instrument, the individual submenu items should be selected one after the other in the main menu item "Setup" and provided with the correct parameter values.

Setup - Measurement loop name

In the menu item "Measurement loop name" you edit a twelve digit measurement loop designation label.

You can enter an unambiguous designation for the measured value, e.g. the measurement loop name or the tank or product designation. In digital systems and in the documentation of larger plants, a singular designation must be entered for exact identification of individual measuring points.

The character set comprises the following ASCII signs with extension according to ISO 8859-1:

- Letters from A ... Z
- Numbers from 0 ... 9
- Special characters such as +, -, /, - etc.



Setup - Display, menu language

This menu item allows a change of the national language.




The following languages are available:

- German
- English
- French
- Spanish
- Russian
- Italian
- Dutch
- Portuguese
- Turkish
- Polish
- Czech

Setup - Display, indication value

In this menu item you can define the way measured values are indicated on the display.



The default setting for the display value is "Current".

Setup - Display, lighting

The display and adjustment module has a backlight for the display. In this menu item you can switch on the lighting. You can find the required operating voltage in chapter "Technical data".



The lighting is switched off in delivery status.



Note:

The lighting switches off automatically when the current in the signal circuit is lower than 4 mA.

It switches on automatically when the current in the signal circuit is 4 mA or higher.

Setup - Damping

To damp process-dependent measured value fluctuations, set an integration time of 0 ... 999 s in this menu item. The increment is 0.1 s.

The entered integration time influences the current value and the display. The HART value remains unaffected.




Factory setting is 0 s.

Setup - Scaling

In the menu item "*Scaling variable*" you define the scaling variable and unit of the measured value on the display, e.g. volume in l.

In addition to the offered standard units, there is the possibility, to create a user-defined unit.



Furthermore, via menu item "*Scaling format*" you define the position of the comma and the assignment of the measured value for 0 % and 100 %.



Lock/unlock setup - Adjustment

In the menu item "*Lock/unlock adjustment*", you can protect the instrument parameters against unauthorized modification. The PIN is activated/deactivated permanently.

With active PIN, only the following adjustment functions are possible without entering a PIN:

- Select menu items and show data
- Read data from the sensor into the display and adjustment module



Caution:

When the PIN is active, adjustment via PACTware/DTM as well as other systems is also blocked.

The PIN number is entered while locking.

Diagnostics - Device status

In this menu item, the device status is displayed.



In case of instrument failure, an error code with text message is displayed. You can find information on cause and rectification in chapter "Diagnosis and service".

Additional settings - Reset

After a reset, certain parameter adjustments made by the user are reset.



The following table shows the default values of the instrument. Depending on the instrument version or application, all menu items may not be available or some may be differently assigned:

Reset - Setup

Menu item	Parameter	Default value
Measurement loop name		Display
Display	Language	English Order-specific
	Displayed value	Signal current
	Backlight	Switched off
Damping	Integration time	0 s
Scaling	Scaling size	%
	Scaling format	20 mA correspond to 100.00 % 4 mA correspond to 0.00 %
Lock adjustment		Released

Additional adjustments - Copy display settings

This function copies the following display settings. The following parameters or settings are saved:

- All parameters of the menu "Setup"



The copied data are permanently saved in the display and adjustment module. They remain even in case of voltage loss.




Note:


Before the data are stored in the instrument, they are checked to make sure they match the instrument. For this purpose, the instrument type of the source data as well as the target instrument are displayed. Storage takes place only after approval.

Info - Instrument name


In this menu item, you can read out the instrument name and the instrument serial number:



Info - Instrument version In this menu item, the hardware and software version of the sensor is displayed.



Info - Factory calibration date In this menu item, the date of the factory calibration of the instrument as well as the date of the last change of sensor parameters is displayed via the PC.



Info - Instrument features In this menu item, instrument features such as approvals, electronics, housing as well as others are displayed.



7 Setup via PACTware

7.1 Connect the PC

Via the interface adapter on VEGADIS 82

The PC is connected via the interface adapter VEGACONNECT to VEGADIS 82.

Parameter adjustment options:

- VEGADIS 82




Fig. 16: Connection of the PC via interface adapter

- 1 USB cable to the PC
- 2 Interface adapter VEGACONNECT
- 3 VEGADIS 82

7.2 Parameter adjustment

Prerequisites

For parameter adjustment of the instrument via a Windows PC, the configuration software PACTware and a suitable instrument driver (DTM) according to FDT standard are required. The latest PACTware version as well as all available DTMs are compiled in a DTM Collection. The DTMs can also be integrated into other frame applications according to FDT standard.



Note:

To ensure that all instrument functions are supported, you should always use the latest DTM Collection. Furthermore, not all described functions are included in older firmware versions. You can download the latest instrument software from our homepage. A description of the update procedure is also available in the Internet.

Further setup steps are described in the operating instructions manual "DTM Collection/PACTware" attached to each DTM Collection and

which can also be downloaded from the Internet. Detailed descriptions are available in the online help of PACTware and the DTMs.




Fig. 17: Example of a DTM view

Standard/Full version

All device DTMs are available as a free-of-charge standard version and as a full version that must be purchased. In the standard version, all functions for complete setup are already included. An assistant for simple project configuration simplifies the adjustment considerably. Saving/printing the project as well as import/export functions are also part of the standard version.

In the full version there is also an extended print function for complete project documentation as well as a save function for measured value and echo curves. In addition, there is a tank calculation program as well as a multiviewer for display and analysis of the saved measured value and echo curves.

The standard version is available as a download under www.vega.com/downloads and "Software". The full version is available on CD from the agency serving you.

7.3 Saving the parameterisation data

We recommend documenting or saving the parameterisation data via PACTware. That way the data are available for multiple use or service purposes.

8 Diagnostics and servicing

8.1 Maintenance

Maintenance

If the device is used properly, no special maintenance is required in normal operation.

Cleaning

The cleaning helps that the type label and markings on the instrument are visible.

Take note of the following:

- Use only cleaning agents which do not corrode the housings, type label and seals
- Use only cleaning methods corresponding to the housing protection rating

8.2 Asset Management function

Sensors

The instrument supports the self-monitoring and diagnosis of the connected sensor. Status or failure messages are displayed according to the sensor via display and adjustment module, PACTware/DTM and EDD.

You can find a detailed overview of this function in the operating instructions of the respective sensor.

VEGADIS 82

Code Text message	Cause	Rectification
S003 CRC-error	● CRC error during self-check	● Carry out a reset ● Send instrument for repair
F014 Sensor input: Short-circuit	● Short-circuit or sensor current > 21 mA	● Check cable ● Check sensor
F015 Sensor input: Line break	● Line break or sensor current < 3.6 mA	● Check cable ● Check sensor, probably already in the run-in period
S021 Scaling: Span too small	● Scaling span too small	● Carry out a fresh scaling, increase the distance between min. and max. scaling.
S022 Scaling: Value too high	● Scaling value too high	● Check scaling values and correct, if necessary
F034 EEPROM: CRC error	● EEPROM: CRC error	● Switch the instrument off and on ● Carry out reset to default setting ● Send instrument for repair
F035 ROM: CRC error	● ROM: CRC error	● Switch the instrument off and on ● Carry out reset to default setting ● Send instrument for repair
F037 RAM defective	● Error of the RAM in the internal data memory	● Switch the instrument off and on ● Carry out reset to default setting ● Send instrument for repair
F040 General hardware error	● Hardware error	● Switch the instrument off and on ● Carry out reset to default setting ● Send instrument for repair

Tab. 2: Error codes and text messages, information on causes as well as corrective measures

8.3 Rectify faults

Reaction when malfunction occurs

The operator of the system is responsible for taking suitable measures to rectify faults.

Check the 4 ... 20 mA signal

Connect a multimeter in the suitable measuring range according to the wiring plan. The following table describes possible errors in the current signal and helps to eliminate them:

Error	Cause	Rectification
4 ... 20 mA signal not stable	● Fluctuating measured value	● Set damping
4 ... 20 mA signal missing	● Electrical connection faulty	● Check connection, correct, if necessary
	● Voltage supply missing	● Check cables for breaks; repair if necessary
	● Operating voltage too low, load resistance too high	● Check, adapt if necessary
Current signal greater than 22 mA, less than 3.6 mA	● Sensor electronics defective	● Exchange the instrument or send it in for repair

Reaction after fault rectification

Depending on the reason for the fault and the measures taken, the steps described in chapter "Setup" must be carried out again or must be checked for plausibility and completeness.

24 hour service hotline

Should these measures not be successful, please call in urgent cases the VEGA service hotline under the phone no. **+49 1805 858550**.

The hotline is also available outside normal working hours, seven days a week around the clock.

Since we offer this service worldwide, the support is provided in English. The service itself is free of charge, the only costs involved are the normal call charges.

8.4 Exchanging the electronics module

In case of a defect, the user can replace the electronics module with another one of identical type.



In Ex applications, only instruments and electronics modules with appropriate Ex approval may be used.

If there is no electronics module available on site, one can be ordered from the agency serving you.

8.5 Software update

The following components are required to update the instrument software:

- Instrument
- Voltage supply
- Interface adapter VEGACONNECT

- PC with PACTware
- Current instrument software as file

You can find the current instrument software as well as detailed information on the procedure in the download area of our homepage: www.vega.com.

**Caution:**

Instruments with approvals can be bound to certain software versions. Therefore make sure that the approval is still effective after a software update is carried out.

You can find detailed information in the download area at www.vega.com.

8.6 How to proceed if a repair is necessary

You can find an instrument return form as well as detailed information about the procedure in the download area of our homepage: www.vega.com. By doing this you help us carry out the repair quickly and without having to call back for needed information.

In case of repair, proceed as follows:

- Print and fill out one form per instrument
- Clean the instrument and pack it damage-proof
- Attach the completed form and, if need be, also a safety data sheet outside on the packaging
- Ask the agency serving you to get the address for the return shipment. You can find the agency on our home page www.vega.com.

9 Dismount

9.1 Dismounting steps

**Warning:**

Before dismantling, be aware of dangerous process conditions such as e.g. pressure in the vessel or pipeline, high temperatures, corrosive or toxic products etc.

Take note of chapters "*Mounting*" and "*Connecting to power supply*" and carry out the listed steps in reverse order.

9.2 Disposal

The instrument consists of materials which can be recycled by specialised recycling companies. We use recyclable materials and have designed the electronics to be easily separable.

WEEE directive 2002/96/EG

This instrument is not subject to the WEEE directive 2002/96/EG and the respective national laws. Pass the instrument directly on to a specialised recycling company and do not use the municipal collecting points. These may be used only for privately used products according to the WEEE directive.

Correct disposal avoids negative effects on humans and the environment and ensures recycling of useful raw materials.

Materials: see chapter "*Technical data*"

If you have no way to dispose of the old instrument properly, please contact us concerning return and disposal.

10 Supplement

10.1 Technical data

Materials and weights

Materials

- | | |
|--|---|
| – Plastic housing | Plastic PBT (Polyester) |
| – Aluminium housing | Aluminium die-casting AlSi10Mg, powder-coated (Basis: Polyester) |
| – Stainless steel housing | 316L precision casting, blasted |
| – Seal between housing and housing lid | NBR (stainless steel housing), silicone (Aluminium/plastic housing) |
| – Inspection window in housing cover (in version with display and adjustment module) | Polycarbonate, coated |
| – Cable gland/Seal insert | PA/NBR |
| – Ground terminal | 316L |

Deviating materials - Ex-d version

- | | |
|--|--------------------------|
| – Inspection window in housing cover (in version with display and adjustment module) | Single-pane safety glass |
| – Cable gland/Seal insert | Brass nickel-plated/NBR |

Materials for carrier rail mounting

- | | |
|------------------------------------|------------------|
| – Adapter plate, housing side | 316 |
| – Adapter plate, carrier rail side | Zinc die casting |
| – Mounting screws | 316 |

Materials for tube mounting

- | | |
|-------------------|------|
| – Brackets | StSt |
| – Mounting screws | StSt |

Materials for panel mounting

- | | |
|---------------------|-------------------|
| – Housing | PPE |
| – Transparent cover | PS |
| – Screw clamps | St, nickel plated |

Weights without mounting elements approx.

- | | |
|---------------------------|---------------------|
| – Plastic housing | 0.35 kg (0.772 lbs) |
| – Aluminium housing | 0.7 kg (1.543 lbs) |
| – Stainless steel housing | 2.0 kg (4.409 lbs) |

Mounting elements approx.

- | | |
|---|--------------------|
| – Brackets for tube mounting | 0.4 kg (0.882 lbs) |
| – Adapter plate for carrier rail mounting | 0.5 kg (1.102 lbs) |

Torques

Max. torque for NPT cable glands and Conduit tubes

- Plastic housing 10 Nm (7.376 lbf ft)
- Aluminium/Stainless steel housing 50 Nm (36.88 lbf ft)

Signal and supply circuit

Operating voltage max.	35 V DC
Voltage drop with current value 4 ... 20 mA	
– Without lighting max.	1.7 V
– With lighting max.	3.2 V
Current range	3.5 ... 22.5 mA ¹⁾
Overcurrent resistance	100 mA
Fuse	Power supply side
Reverse voltage protection	Available
Functional safety	SIL non-reactive

Current measurement (reference temperature 20 °C)

Measuring range loop current	3.5 ... 22.5 mA
Deviation	±0.1 % of 20 mA
Temperature coefficient	±0.1 % of the span/10 K
Interval	250 ms

Display and adjustment module

Display element	Display with backlight
Measured value indication	
– Number of digits	5
Adjustment elements	
– 4 keys	<i>[OK], [->], [+], [ESC]</i>
Protection rating	
– unassembled	IP 20
– mounted in the housing without lid	IP 40
Materials	
– Housing	ABS
– Inspection window	Polyester foil
Functional safety	SIL non-reactive

Ambient conditions

Storage and transport temperature	-40 ... +80 °C (-40 ... +176 °F)
Ambient temperature	
– without display and adjustment module	-40 ... +80 °C (-40 ... +176 °F)

¹⁾ If the loop current is not sufficient for operation, the display remains dark. When the measured values are outside the measuring range, a message is displayed instead of the measured value.

– With display and adjustment module -20 ... +70 °C (-4 ... +158 °F)

Process conditions

Vibration resistance	4 g at 5 ... 200 Hz according to EN 60068-2-6 (vibration with resonance)
Vibration resistance with carrier rail mounting	1 g at 5 ... 200 Hz according to EN 60068-2-6 (vibration with resonance)
Shock resistance	100 g, 6 ms according to EN 60068-2-27 (mechanical shock)

Electromechanical data

Options of the cable entry

– Cable entry	M20 x 1.5, ½ NPT
– Cable gland	M20 x 1.5, ½ NPT
– Blind plug	M20 x 1.5; ½ NPT
– Closing cap	½ NPT

Connection terminals

– Type	Spring-loaded terminal
– Stripping length	8 mm

Wire cross-section of the connection cable (according to IEC 60228)

– Massive wire, stranded wire	0.2 ... 2.5 mm ² (AWG 24 ... 14)
– Stranded wire with end sleeve	0.2 ... 1.5 mm ² (AWG 24 ... 16)

Electromechanical data - Panel mounting

Terminals, plug connector

– Type	Spring-loaded terminal
– Stripping length	8 mm

Wire cross-section of the connection cable (according to IEC 60228)

– Massive wire, stranded wire	0.2 ... 1.5 mm ² (AWG 24 ... 16)
– Stranded wire with end sleeve	0.25 ... 0.75 mm ² (AWG 24 ... 18)

Electrical protective measures

Protection rating

– Plastic housing	IEC 60529 IP 66/IP 67, NEMA Type 4X
– Housing for panel mounting (mounted)	IEC 60529 IP 40, NEMA Type 1
– Aluminium/Stainless steel housing	IEC 60529IP 66/IP 68 (0.2 bar), NEMA Type 6P

Connection of the feeding power supply unit Networks of overvoltage category III

Altitude above sea level

– by default	up to 2000 m (6562 ft)
– with connected overvoltage protection	up to 5000 m (16404 ft)

Pollution degree ²⁾	4
Protection class	II

10.2 Dimensions

VEGADIS 82, plastic housing




Fig. 18: VEGADIS 82 with plastic housing

VEGADIS 82, Plastic housing (Panel mounting)




Fig. 19: VEGADIS 82 with plastic housing for panel mounting

²⁾ When used with fulfilled housing protection

VEGADIS 82, aluminium housing




Fig. 20: VEGADIS 82 with Aluminium housing

VEGADIS 82, Stainless steel housing (precision casting)




Fig. 21: VEGADIS 82, with stainless steel housing (precision casting)

Mounting elements




Fig. 22: Adapter plate for carrier rail mounting of VEGADIS 82




Fig. 23: Brackets for tube mounting of VEGADIS 82

10.3 Industrial property rights

VEGA product lines are global protected by industrial property rights. Further information see www.vega.com.

VEGA Produktfamilien sind weltweit geschützt durch gewerbliche Schutzrechte.

Nähere Informationen unter www.vega.com.

Les lignes de produits VEGA sont globalement protégées par des droits de propriété intellectuelle. Pour plus d'informations, on pourra se référer au site www.vega.com.

VEGA líneas de productos están protegidas por los derechos en el campo de la propiedad industrial. Para mayor información revise la página web www.vega.com.

Линии продукции фирмы ВЕГА защищаются по всему миру правами на интеллектуальную собственность. Дальнейшую информацию смотрите на сайте www.vega.com.

VEGA系列产品在全球享有知识产权保护。

进一步信息请参见网站www.vega.com。

10.4 Trademark

All the brands as well as trade and company names used are property of their lawful proprietor/originator.

INDEX**A**

- Adjustment
 - System 21
- Adjustment menu 22
- Application area 8

C

- Change the language 23
- Check output signal 30
- Connection
 - Cable 14
 - Steps 15
 - Technology 15
- Copy display settings 25

D

- Damping 23
- Display lighting 23

E

- Error codes 29

G

- Grounding 15

I

- Instrument versions 7

L

- Lock adjustment 24

M

- Mounting
 - Carrier rail 11
 - Front panel 13
 - Position 11
 - Tube 12

R

- Recycling 32
- Repair 31
- Reset 25

S

- Scaling 24
- Service hotline 30
- Set display parameters 23

T


- Type label 7


V


- Voltage supply 14

W

- WEEE directive 32







Printing date:

VEGA

All statements concerning scope of delivery, application, practical use and operating conditions of the sensors and processing systems correspond to the information available at the time of printing.

Subject to change without prior notice

© VEGA Grieshaber KG, Schiltach/Germany 2018



46591-EN-180717

VEGA Grieshaber KG
Am Hohenstein 113
77761 Schiltach
Germany

Phone +49 7836 50-0
Fax +49 7836 50-201
E-mail: info.de@vega.com
www.vega.com