

VEGATOR 121/122

Version, available since	Description
1.3.0, 04/2018	New functions (exclusive for VEGATOR 121:**S****): <ul style="list-style-type: none"> – Switching over possibility of output 2 between fail safe and function relay.
1.2.0, 11/2014	Error corrections: <ul style="list-style-type: none"> – Relay type 24 V changed to 18 V pull-in voltage Downward compatibility given (the middle index was incremented by mistake)
1.1.1, 08/2014	Error corrections: <ul style="list-style-type: none"> – Preventative measure to avoid problems through batch variation of components in the measured value processing.
1.1.0, 07/2014	New functions: <ul style="list-style-type: none"> – SIL available – Switching on impulse monitoring of the measured value decoupled
1.0.1, 06/2014	Error corrections: <ul style="list-style-type: none"> – Preventative measure to avoid problems through batch variation of components in the measured value processing.
1.0.0, 02/2014	First version

Overview of the hardware versions

Legend:

Name	Description
Version	<p>xx.yy.zz</p> <p>xx: Compatibility version. Will be increased when the compatibility to the previous version is no longer given. Value range 0 ... 99.</p> <p>yy: Function extension version. Will be increased when new functions or function changes were carried out on the previous version. Also errors can have been corrected with a function change. Value range 0 ... 99.</p> <p>zz: Error correction version. Will be increased when only errors were corrected on the previous version. Value range 0 ... 99.</p>
available since	Month/Year