

Overview of the hardware versions

VEGATOR 141/142

Version, available since	Description
1.1.1, 11/2014	Error corrections: <ul style="list-style-type: none"> – Relay type 24 V changed to 18 V pull-in voltage

Version, available since	Description
1.1.0, 08/2014	Error corrections: <ul style="list-style-type: none"> – Preventative measure to avoid problems through batch variation of components in the measured value processing. – Downward compatibility given (the middle index was incremented by mistake)

Version, available since	Description
1.0.1, 06/2014	Error corrections: <ul style="list-style-type: none"> – Preventative measure to avoid problems through batch variation of components in the measured value processing.

Version, available since	Description
1.0.0, 04/2014	First version

Legend:

Name	Description
Version	xx.yy.zz xx: Compatibility version.. Will be increased when the compatibility to the previous version

Overview of the hardware versions

Name	Description
	<p>is no longer given. Value range 0 ... 99.</p> <p>yy: Function extension version. Will be increased when new functions or function changes were carried out on the previous version. Also errors can have been corrected with a function change. Value range 0 ... 99.</p> <p>zz: Error correction version. Will be increased when only errors were corrected on the previous version. Value range 0 ... 99.</p>
available since	Month/Year