

## Overview of the hardware versions

### VEGABAR 2x, 3x

Version, available since	Description
<b>1.0.3, 01/2023</b>	<b>Error correction:</b> <ul style="list-style-type: none"> <li>– Interruption of IO-Link communication when lowering and then increasing the supply voltage</li> </ul>
<b>1.0.2, 04/2022</b>	<b>Error correction:</b> <ul style="list-style-type: none"> <li>- Batch variations of an electronic component detected in the electronic test field and replaced by alternative component</li> </ul>
<b>1.0.0, 05/2019</b>	<b>First version</b> <b>New functions:</b> <ul style="list-style-type: none"> <li>– Functionality: <ul style="list-style-type: none"> <li>– 3-wire with switching outputs and/or active 4 ... 20 mA</li> <li>– IO-Link communication output</li> </ul> </li> </ul>

#### Legend:

Name	Description
Version	xx.yy.zz xx: Compatibility version. Will be increased when the compatibility to the previous version is no longer given. Value range 0 ... 99. yy: Function extension version. Will be increased when new functions or function changes were carried out on the previous version. Also errors can have been corrected with a function change. Value range 0 ... 99. zz: Error correction version. Will be increased when only errors were corrected on the previous version. Value range 0 ... 99.
available since	Month/Year