Supplementary instructions

Mounting bracket KV 31

For tubes with ø 50 … 100 mm 30° diagnonal irradiation





Document ID: 41863







Contents

1	Proc	duct description	
2	Mou	Inting with source container VEGASOURCE 31, 35	5
3	Mou	Inting with source container VEGASOURCE 81, 82	12
4	Sup	plement	
	4.1	Technical data	
	4.2	Dimensions	
	4.3	Industrial property rights	
	4.4	Trademark	



1 Product description

The KV 31 is a mounting bracket for the radiometric measuring system MINITRAC. It is suitable for pipes of 50 \dots 100 mm (1.97 \dots 3.94 in) diameter.

With source holder VEGASOURCE 31, 35



Fig. 1: Mounting bracket with 30° diagonal irradiation (with VEGASOURCE 31, 35)

With source holder





Fig. 2: Mounting bracket with 30° diagonal irradiation (with VEGASOURCE 81, 82)

Scope of delivery	The mounting bracket KV 31 contains all necessary parts for fasten- ing a radiometric measuring system to tubes with a diameter of 50 100 mm (1.97 3.94 in).
	The two halves of the mounting bracket are already premounted.
	Check the completeness of the mounting backet according to the as- sembly drawings of chapter " <i>Mounting</i> ".
Collimator (optional)	A collimator can be mounted on the sensor side, the source holder side or on both sides of the mounting bracket.
	A collimator directs the radiation directly to the sensor and absorbs the undirected scattered radiation.



2 Mounting with source container VEGASOURCE 31, 35

Operating instructions

Mounting bracket for 30° inclined irradiation

Mounting - Mounting

bracket, sensor side

Take note of the operating instructions of the corresponding sensor MINITRAC and the source holder.

Take note of the following mounting instructions:

- Mount the bracket first, then the sensor and the source holder
- The marking arrow on the console (source holder side) and the transport lug of the source holder must point in the same direction after mounting.
- Make sure that the two clamps of the bracket are parallel to each other. Do this by measuring the lateral distances between the clamps
- To avoid injuries, shorten the threaded rods of the brackets to the suitable length after mounting

This half of the mounting bracket is already premounted when being shipped.

When retrofitting a collimator etc., mount the sensor side of the mounting bracket according to the following assembly drawing.

To facilitate mounting, mount the bracket first, then the sensor and the source holder.





Fig. 3: Mounting brackets, sensor side (MINITRAC)

- 1 Hexagon screw M8 (2 pieces)
- 2 Washer for M8 (2 pieces)
- 3 Console, sensor side (MINITRAC)
- 4 Hexagon screw M8 (4 pieces)
- 5 Seal, collimator (sensor side)
- 6 Washer for M8 (4 pieces), (optional)
- 7 Hexagon nut M8 (8 pieces), (optional)
- 8 Washer for M8 (4 pieces)
- 9 Seal, collimator (sensor side), (optional)
- 10 Hexagon screw M8 (4 pieces)
- 11 Console, sensor side (MINITRAC)
- 12 Hexagon screw M10 (4 pieces)
- 13 Washer for M10 (4 pieces)
- 14 Seal, bracket (sensor side)
- 15 Cover plate
- 16 Bracket, sensor side (MINITRAC)
- 17 Washer for M10 (4 pieces)
- 18 Spring rings for M10 (4 pieces)
- 19 Hexagon nut M10 (4 pieces)
- 20 Threaded rod M10 x 360 mm (4 pieces)
- 21 Washer for M10 (4 pieces)
- 22 Hexagon nut/Counter nut M10 (8 pieces)
- 23 Collimator, Sensor side (MINITRAC), (optional)

Mounting - Mounting bracket, radiator side

This half of the mounting bracket is already premounted when being shipped.

When retrofitting a collimator etc., mount the sensor side of the mounting bracket according to the following assembly drawing.

To facilitate mounting, mount the bracket first, then the sensor and the source holder.





Note:

Mount the components in such a way that the marking arrows of the console (3) and the collimator (1) point in the same direction.

Note the following illustrations.



Fig. 4: Mounting bracket, source container side (with VEGASOURCE 31, 35)

- 1 Collimator. source holder side (optional)
- 2 Seal, collimator (source holder side), (optional)
- 3 Console, source holder side
- 4 Hexagon screw M10 (4 pieces)
- 5 Washer for M10 (4 pieces)
- 6 Seal, bracket (sensor side)
- 7 Cover plate
- 8 Clamp, source holder side
- 9 Hexagon nut M10 (4 pieces)
- 10 Spring rings for M10 (4 pieces)
- 11 Washer for M10 (4 pieces)
- 12 Washer for M10 (4 pieces)
- 13 Hexagon nut/Counter nut M10 (8 pieces)
- 14 Washer for M16 (4 pieces), (optional)
- 15 Distance bolt M16 (4 pieces), (optional)
- 16 Washer for M16 (4 pieces)
- 17 Hexagon nut M16 (4 pieces)

Note marking arrows

The marking arrows on the console and the collimator must point in the same direction. After mounting, the transport lug of the source holder must point in the same direction.





Fig. 5: The marking arrows of the console and the collimator point in the same direction.

- 1 Collimator, source holder side
- 2 Console, source holder side

Adjust mounting bracket

Note:

Т

Adjust both sides of the mounting bracket to the respective tube diameter before mounting the mounting bracket to the tube. This facilitates the adjustment.

A later adjustment is difficult due to the weight of the mounting bracket.

- 1. Loosen the four screw connections until the console can be shifted.
- 2. Adjust the consoles on the sensor side and the source holder side according to your tube diameter.

Take note of the marking lines on the bracket. The edge of the console must be exactly on the corresponding marking line.





Fig. 6: Adjust mounting bracket

- 1 Console
- 2 Bracket, sensor or source holder side
- 3 Screw connections
- 4 Markings (different tube diameters)

Installation of the mounting bracket

Tip:

The mounting bracket is very heavy. We recommend using a support, eg of wood, as a mounting aid to hold the mounting bracket at the proper height during installation.

Mount the bracket according to the following assembly drawing:

- Before mounting, check if the adjustment with respect to the tube diameter is correct on both sides of the mounting bracket and if the marking arrows of the console and the collimator (optional) point in the same direction.
- 2. Make sure that the two clamps of the bracket are parallel to each other. Do this by measuring the lateral distances between the clamps.
- Tighten the nuts of the threaded rod evenly. Keep the tube diameter and the stability of the tube material in mind. Avoid deformation of the tube through an overtightening of the mounting bracket.

If you have the impression that the tube cannot permanently carry the weight of the mounting bracket, sensor and source container, mount a suitable support below the mounting bracket.

4. Shorten the threaded rods after mounting to avoid injuries.





Fig. 7: Mounting bracket for 30° diagonal irradiation (with VEGASOURCE 31, 35)

- 1 Source holder
- 2 Collimator, source holder side (optional)
- 3 Console, source holder side
- 4 Clamp, source holder side
- 5 Sensor (MINITRAC)
- 6 Console, sensor side (MINITRAC)
- 7 Collimator, sensor side (optional)
- 8 Detector console, sensor side (MINITRAC)
- 9 Bracket, sensor side (MINITRAC)
- 10 Tube ø 50 ... 100 mm (1.97 ... 3.94 in)
- *x* Brackets in parallel, distances on both sides the same
- A The marking arrow and the eye-bolt in the same direction

Mount the sensor and source holder

Once the mounting bracket is installed, you can mount the sensor and the source holder.

You can find the torque in the "Technical data".

41863-EN-240814





Danger:

When mounting, make sure that the source holder is reliably switched off.

- 1. First of all fasten the sensor.
- 2. Mount the source holder. Use a suitable lifting device and note the respective safety regulations for lifting loads.



Operating instructions

Mounting bracket for 30° inclined irradiation

3 Mounting with source container VEGASOURCE 81, 82

Take note of the operating instructions of the corresponding sensor MINITRAC and the source holder.

Take note of the following mounting instructions:

- Mount the bracket first, then the sensor and the source holder
- The marking arrow on the console (source holder side) and the transport lug of the source holder must point in the same direction after mounting.
- Make sure that the two clamps of the bracket are parallel to each other. Do this by measuring the lateral distances between the clamps
- To avoid injuries, shorten the threaded rods of the brackets to the suitable length after mounting

Mounting - MountingThis half of the mounting bracket is already premounted when being
shipped.

When retrofitting a collimator etc., mount the sensor side of the mounting bracket according to the following assembly drawing.

To facilitate mounting, mount the bracket first, then the sensor and the source holder.





Fig. 8: Mounting brackets, sensor side (MINITRAC)

- 1 Hexagon screw M8 (2 pieces)
- 2 Washer for M8 (2 pieces)
- 3 Console, sensor side (MINITRAC)
- 4 Hexagon screw M8 (4 pieces)
- 5 Seal, collimator (sensor side)
- 6 Washer for M8 (4 pieces), (optional)
- 7 Hexagon nut M8 (8 pieces), (optional)
- 8 Washer for M8 (4 pieces)
- 9 Seal, collimator (sensor side), (optional)
- 10 Hexagon screw M8 (4 pieces)
- 11 Console, sensor side (MINITRAC)
- 12 Hexagon screw M10 (4 pieces)
- 13 Washer for M10 (4 pieces)
- 14 Seal, bracket (sensor side)
- 15 Cover plate
- 16 Bracket, sensor side (MINITRAC)
- 17 Washer for M10 (4 pieces)
- 18 Spring rings for M10 (4 pieces)
- 19 Hexagon nut M10 (4 pieces)
- 20 Threaded rod M10 x 360 mm (4 pieces)
- 21 Washer for M10 (4 pieces)
- 22 Hexagon nut/Counter nut M10 (8 pieces)
- 23 Collimator, Sensor side (MINITRAC), (optional)

Mounting - Mounting bracket, radiator side This half of the mounting bracket is already premounted when being shipped.

When retrofitting a collimator etc., mount the sensor side of the mounting bracket according to the following assembly drawing.

To facilitate mounting, mount the bracket first, then the sensor and the source holder.





Note:

Mount the components in such a way that the marking arrows of the console (3) and the collimator (1) point in the same direction.

Note the following illustrations.



Fig. 9: Mounting bracket, source container side (with VEGASOURCE 81, 82)

- 1 Console, source holder side
- 2 Hexagon screw M10 (4 pieces)
- 3 Washer for M10 (4 pieces)
- 4 Seal, bracket (sensor side)
- 5 Cover plate
- 6 Clamp, source holder side
- 7 Hexagon nut M10 (4 pieces)
- 8 Spring rings for M10 (4 pieces)
- 9 Washer for M10 (4 pieces)
- 10 Washer for M10 (4 pieces)
- 11 Hexagon nut/Counter nut M10 (8 pieces)
- 12 Washer for M16 (4 pieces)
- 13 Hexagon nut M16 (4 pieces)

Adjust mounting bracket

Note:

Adjust both sides of the mounting bracket to the respective tube diameter before mounting the mounting bracket to the tube. This facilitates the adjustment.

A later adjustment is difficult due to the weight of the mounting bracket.

- 1. Loosen the four screw connections until the console can be shifted.
- 2. Adjust the consoles on the sensor side and the source holder side according to your tube diameter.

Take note of the marking lines on the bracket. The edge of the console must be exactly on the corresponding marking line.







Fig. 10: Adjust mounting bracket

- 1 Console
- 2 Bracket, sensor or source holder side
- 3 Screw connections
- 4 Markings (different tube diameters)

Installation of the mounting bracket

Tip:

The mounting bracket is very heavy. We recommend using a support, eg of wood, as a mounting aid to hold the mounting bracket at the proper height during installation.

Mount the bracket according to the following assembly drawing:

- Before mounting, check if the adjustment with respect to the tube diameter is correct on both sides of the mounting bracket and if the marking arrows of the console and the collimator (optional) point in the same direction.
- 2. Make sure that the two clamps of the bracket are parallel to each other. Do this by measuring the lateral distances between the clamps.
- Tighten the nuts of the threaded rod evenly. Keep the tube diameter and the stability of the tube material in mind. Avoid deformation of the tube through an overtightening of the mounting bracket.

If you have the impression that the tube cannot permanently carry the weight of the mounting bracket, sensor and source container, mount a suitable support below the mounting bracket.

4. Shorten the threaded rods after mounting to avoid injuries.





Fig. 11: Mounting bracket for 30° diagonal irradiation (with VEGASOURCE 81, 82)

- 1 Source holder
- 2 Console, source holder side
- 3 Clamp, source holder side
- 4 Sensor (MINITRAC)
- 5 Collimator, sensor side (optional)
- 6 Console, sensor side (MINITRAC)
- 7 Bracket, sensor side (MINITRAC)
- 8 Tube ø 50 ... 100 mm (1.97 ... 3.94 in)
- *x* Brackets in parallel, distances on both sides the same
- A The marking arrow and the lug point in the same direction

Mount the sensor and source holder Once the mounting bracket is installed, you can mount the sensor and the source holder.

You can find the torque in the "Technical data".





Danger:

When mounting, make sure that the source holder is reliably switched off.

- 1. First of all fasten the sensor.
- 2. Mount the source holder. Use a suitable lifting device and note the respective safety regulations for lifting loads.



4 Supplement

4.1 Technical data

General data

Take note of the information in the operating instructions manual of the installed MINITRAC level sensor and the source holder

316L

Material 316L corresponds to 1.4404 or 1.4435

Materials

6L

Threaded rods

Weight (without sensor and source holder)

- Mounting bracket without collimator 47.6 kg (105 lbs)
- Mounting bracket with collimator sen-57.8 kg (127.4 lbs) sor side

Torques

 Screws, Sensor mounting (M8) 	15 Nm (11.06 lbf ft)
- Nuts (M16)	20 Nm (14.75 lbf ft)
- Threaded rods (M10)	Dependent on the tube material



4.2 Dimensions

4.2.1 Dimensions with source container VEGASOURCE 31, 35

KV 31, without collimator



Fig. 12: Mounting bracket without collimator (with VEGASOURCE 31, 35)

- A Total width
- AD Tube diameter
- B Total length
- C Adjustment
- D Height Radiator side
- E Height Sensor side

Tube DN (in)	Tube diame-	Total width	Total length	Adjustment	Height - Radi-	Height - Sen-		
	ter (AD)	(A)	(B)	(C)	ator side (D)	sor side (E)		
DN 50 (2 in)	ø 60.3 mm	706 mm	1116 mm	275 mm	304 mm	326 mm		
	(2.37 in)	(27.8 in)	(44 in)	(10.8 in)	(12 in)	(12.9 in)		
DN 65 (2.5 in)	ø 73 mm	728 mm	1154 mm	295 mm	315 mm	338 mm		
	(2.9 in)	(28.7 in)	(45.5 in)	(11.7 in)	(12.5 in)	(13.4 in)		
DN 80 (3 in)	ø 88.9 mm	746 mm	1186 mm	310 mm	324 mm	347 mm		
	(3.5 in)	(29.4 in)	(46.7 in)	(12.2 in)	(12.8 in)	(13.7 in)		
DN 100 (4 in)	ø 114.3 mm	782 mm	1248 mm	342 mm	342 mm	365 mm		
	(4.5 in)	(30.8 in)	(49.2 in)	(13.5 in)	(13.5 in)	(14.4 in)		



KV 31, collimator on the sensor side



Fig. 13: Mounting bracket with collimator on the sensor side (with VEGASOURCE 31, 35)

- A Total width
- AD Tube diameter
- B Total length
- C Adjustment
- D Height Radiator side
- E Height Sensor side

Tube DN (in)	Tube diame-	Total width	Total length	Adjustment	Height - Radi-	Height - Sen-
	ter (AD)	(A)	(B)	(C)	ator side (D)	sor side (E)
DN 50 (2 in)	ø 60.3 mm	734 mm	1167 mm	275 mm	304 mm	357 mm
	(2.37 in)	(29 in)	(46 in)	(10.8 in)	(12 in)	(14.1 in)
DN 65 (2.5 in)	ø 73 mm	758 mm	1206 mm	295 mm	315 mm	368 mm
	(2.9 in)	(29.9 in)	(47.5 in)	(11.7 in)	(12.5 in)	(14.5 in)
DN 80 (3 in)	ø 88.9 mm	775 mm	1238 mm	310 mm	324 mm	377 mm
	(3.5 in)	(30.6 in)	(48.8 in)	(12.2 in)	(12.8 in)	(14.9 in)
DN 100 (4 in)	DN 100 (4 in) Ø 114.3 mm		1300 mm	342 mm	342 mm	395 mm
	(4.5 in)		(51.2 in)	(13.5 in)	(13.5 in)	(15.6 in)



KV 31, collimator on the source holder side



Fig. 14: Mounting bracket with collimator on the source container side (with VEGASOURCE 31, 35)

- A Total width
- AD Tube diameter
- B Total length
- C Adjustment
- D Height Radiator side
- E Height Sensor side

Tube DN (in)	Tube diame-	Total width	Total length	Adjustment	Height - Radi-	Height - Sen-
	ter (AD)	(A)	(B)	(C)	ator side (D)	sor side (E)
DN 50 (2 in)	ø 60.3 mm	734 mm	1165 mm	275 mm	332 mm	327 mm
	(2.37 in)	(29 in)	(45.8 in)	(10.8 in)	(13 in)	(12.9 in)
DN 65 (2.5 in)	ø 73 mm	757 mm	1204 mm	295 mm	343 mm	338 mm
	(2.9 in)	(29.8 in)	(47.4 in)	(11.7 in)	(13.5 in)	(13.4 in)
DN 80 (3 in)	ø 88.9 mm	775 mm	1235 mm	310 mm	352 mm	347 mm
	(3.5 in)	(30.6 in)	(48.7 in)	(12.2 in)	(13.9 in)	(13.7 in)
DN 100 (4 in)	ø 114.3 mm	811 mm	1297 mm	342 mm	370 mm	365 mm
	(4.5 in)	(32 in)	(51.1 in)	(13.5 in)	(14.6 in)	(14.4 in)



KV 31, collimators on both sides



Fig. 15: Mounting bracket with collimator on the sensor and source container side (with VEGASOURCE 31, 35)

- A Total width
- AD Tube diameter
- B Total length
- C Adjustment
- D Height Radiator side
- E Height Sensor side

Tube DN (in)	Tube diame-	Total width	Total length	Adjustment	Height - Radi-	Height - Sen-
	ter (AD)	(A)	(B)	(C)	ator side (D)	sor side (E)
DN 50 (2 in)	ø 60.3 mm	764 mm	1217 mm	275 mm	340 mm	364 mm
	(2.37 in)	(30 in)	(47.9 in)	(10.8 in)	(13.4 in)	(14.4 in)
DN 65 (2.5 in)	ø 73 mm	787 mm	1256 mm	294.4 mm	343 mm	367 mm
	(2.9 in)	(31 in)	(49.5 in)	(11.6 in)	(13.5 in)	(14.5 in)
DN 80 (3 in)	ø 88.9 mm	805 mm	1287 mm	310 mm	352 mm	376 mm
	(3.5 in)	(31.7 in)	(50.7 in)	(12.2 in)	(13.9 in)	(14.8 in)
DN 100 (4 in)	ø 114.3 mm	841 mm	1349 mm	341.2 mm	370 mm	394 mm
	(4.5 in)	(33.1 in)	(53.2 in)	(13.5 in)	(10.8 in)	(15.5 in)

4.2.2 Dimensions with source container VEGASOURCE 81, 82

• Note: When

When calculating the length, also take into account optional attachment parts such as the pneumatic changeover, cooling devices, etc.

Depending on the version of the source container, the dimension "L" is extended.



For dimensional information on the versions, please refer to the operating instructions of the source container.

KV 31, without collimator



Fig. 16: Mounting bracket without collimator (with VEGASOURCE 81, 82)

- A Total width
- AD Tube diameter
- B Total length
- C Adjustment
- D Height Radiator side

E Height - Sensor side

Tube DN (in)	Tube diame-	Total width	Total length	Adjustment	Height - Radi-	Height - Sen-		
	ter (AD)	(A)	(B)	(C)	ator side (D)	sor side (E)		
DN 50 (2 in)	ø 60.3 mm	706 mm	1116 mm	275 mm	304 mm	326 mm		
	(2.37 in)	(27.8 in)	(44 in)	(10.8 in)	(12 in)	(12.9 in)		
DN 65 (2.5 in)	ø 73 mm	728 mm	1154 mm	295 mm	315 mm	338 mm		
	(2.9 in)	(28.7 in)	(45.5 in)	(11.7 in)	(12.5 in)	(13.4 in)		
DN 80 (3 in)	ø 88.9 mm	746 mm	1186 mm	310 mm	324 mm	347 mm		
	(3.5 in)	(29.4 in)	(46.7 in)	(12.2 in)	(12.8 in)	(13.7 in)		
DN 100 (4 in)	ø 114.3 mm	782 mm	1248 mm	342 mm	342 mm	365 mm		
	(4.5 in)	(30.8 in)	(49.2 in)	(13.5 in)	(13.5 in)	(14.4 in)		



KV 31, collimator on the sensor side



Fig. 17: Mounting bracket with collimator on the sensor side (with VEGASOURCE 81, 82)

- A Total width
- AD Tube diameter
- B Total length
- C Adjustment
- D Height Radiator side
- E Height Sensor side

Tube DN (in)	Tube diame-	Total width	Total length	Adjustment	Height - Radi-	Height - Sen-		
	ter (AD)	(A)	(B)	(C)	ator side (D)	sor side (E)		
DN 50 (2 in)	ø 60.3 mm	734 mm	1167 mm	275 mm	304 mm	357 mm		
	(2.37 in)	(29 in)	(46 in)	(10.8 in)	(12 in)	(14.1 in)		
DN 65 (2.5 in)	ø 73 mm	758 mm	1206 mm	295 mm	315 mm	368 mm		
	(2.9 in)	(29.9 in)	(47.5 in)	(11.7 in)	(12.5 in)	(14.5 in)		
DN 80 (3 in)	ø 88.9 mm	775 mm	1238 mm	310 mm	324 mm	377 mm		
	(3.5 in)	(30.6 in)	(48.8 in)	(12.2 in)	(12.8 in)	(14.9 in)		
DN 100 (4 in)	ø 114.3 mm	811 mm	1300 mm	342 mm	342 mm	395 mm		
	(4.5 in)	(32 in)	(51.2 in)	(13.5 in)	(13.5 in)	(15.6 in)		



4.3 Industrial property rights

VEGA product lines are global protected by industrial property rights. Further information see <u>www.vega.com</u>.

VEGA Produktfamilien sind weltweit geschützt durch gewerbliche Schutzrechte.

Nähere Informationen unter www.vega.com.

Les lignes de produits VEGA sont globalement protégées par des droits de propriété intellectuelle. Pour plus d'informations, on pourra se référer au site <u>www.vega.com</u>.

VEGA lineas de productos están protegidas por los derechos en el campo de la propiedad industrial. Para mayor información revise la pagina web <u>www.vega.com</u>.

Линии продукции фирмы ВЕГА защищаются по всему миру правами на интеллектуальную собственность. Дальнейшую информацию смотрите на сайте <u>www.vega.com</u>.

VEGA系列产品在全球享有知识产权保护。

进一步信息请参见网站<<u>www.vega.com</u>。

4.4 Trademark

All the brands as well as trade and company names used are property of their lawful proprietor/ originator.







Printing date:



All statements concerning scope of delivery, application, practical use and operating conditions of the sensors and processing systems correspond to the information available at the time of printing. Subject to change without prior notice

© VEGA Grieshaber KG, Schiltach/Germany 2024

VEGA Grieshaber KG Am Hohenstein 113 77761 Schiltach Germany

Phone +49 7836 50-0 E-mail: info.de@vega.com www.vega.com